480F and 480F LL Construction King Loader Backhoe

Parts Catalog

8-6221

CASE CONSTRUCTION

MidWestTech | Case 480F, 480F LL Construction King Loader Landscaper Backhoe Parts Catalog | Publication 8-6221

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX

















GENERAL 1

ENGINE 2

FUEL 3

ELECTRICAL 4

TRACK/STEER. 5

POWER TRAIN 6

BRAKES 7

HYDRAULICS 8

CHASSIS/MTD. EQUIP. 9

NUMERICAL INDEX 10

B891422

MidWestTech | Case 480F, 480F LL Construction King Loader Landscaper Backhoe Parts C... Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	4

MidWestTech | Case 480F, 480F LL Construction King Loader Landscaper Backhoe Parts C... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner 2-7,2-9
Alarm - backup 4-43
Alternator
  Assembly 4-3,4-3B
  Mounting 4-9
Antirollback - loader 9-7
Axle - front, 2WD 5-17
Axle - front, 4WD ..... 6-27 - 6-39
Axle - rear 6-61

B

Backhoe
  Boom ..... 9-43 - 9-47
  Buckets ..... 9-63 - 9-67
  Control Tower 9-21,9-23
  Controls ..... 9-25 - 9-31
  Dipper 9-51,9-55
  Extendable Dipper 9-59,9-61
  Frame and Mounting Parts 9-39
  Hydraulic Circuits ..... 8-19 - 8-47
  Stabilizers 9-41
  Swing Tower 9-43,9-45
Backup Alarm 4-43
Battery 4-11,4-13
Battery Compartment 9-95,9-97
Beacon - rotating ..... 4-45 - 4-47B
Bearings - engine
  Camshaft 2-31
  Main 2-37
  Rod 2-41
Belts
  Fan and Alternator 2-5,4-9
  Seat ..... 9-109 - 9-111B
  Water Pump 2-17
Blade - loader 9-19
Block Heater 2-35,2-35D
Boom Latch 9-49
Boom Lock 8-47,9-33
Box - tool 9-91,9-93
Brake - parking 7-19
Brake Master Cylinder 7-17
Brake System 7-13,7-15
Buckets - backhoe ..... 9-63 - 9-67
Buckets - loader 9-15,9-17

C

Cab
  Doors and Windows ..... 9-125 - 9-137
  Electrical and Lighting ..... 4-23 - 4-39
  Frame 9-125
  Glass and Moldings 9-135,9-137
  Heater and Defroster ..... 9-139 - 9-147

C

Cab-Cont.
  Mounting Parts 9-123
  Panels - closure 9-119,9-121
  Windshield Wipers ..... 9-149 - 9-153
Canopy - ROPS 9-155,9-157
Chassis - tractor 9-85
Clutch Cutout - power shuttle 4-21
Cold Start System 2-11
Column - steering 5-3
Connecting Rods 2-41
Control Tower 9-21,9-23
Controls
  Axle - front drive,4WD 6-41
  Backhoe ..... 9-25 - 9-31
  Boom Latch 9-49
  Boom Lock 9-33
  Brake 7-11
  Clutch Cutout 4-21
  Engine Speed - throttle 3-5,3-7
  Extendable Dipper 9-35,9-37
  Hitch - three-point 9-69
  Loader 9-3,9-5
  Loader - antirollback 9-7
  Loader - return-to-dig 9-13
  Power Shuttle 6-21
  Steering 5-3
  Transmission 6-51
Converter - torque 6-5
Cooling Systems
  Engine 2-3
  Engine Oil 2-23
  Power Shuttle 6-7
  PTO 8-55
Counterweights ..... 9-79 - 9-83
Couplings
  Hydraulic Line Disconnect 8-121
  Hydraulic Pump to Engine 8-3
Crankshaft 2-37
Cylinder - brake master 7-17
Cylinder Block ..... 2-33 - 2-35D
Cylinder Head ..... 2-27 - 2-29B
Cylinders - hydraulic
  Boom - backhoe 8-133
  Bucket - backhoe 8-139,8-141
  Bucket - loader 8-125
  Clam - loader 8-127,8-127B
  Dipper - backhoe 8-135,8-137
  Dipper Extension - backhoe 8-143
  Lift - hitch, three-point 8-145
  Lift - loader 8-123
  Pitch - three-point hitch 8-149
  Stabilizer - backhoe 8-129

MidWestTech | Case 480F, 480F LL Construction King Loader Landscaper Backhoe Parts C... Order the manual at mid-west-tech.com >