PARTS CATALOG

LM410
LM420
LM430
LM630
LM640
TELEHANDLER

86576309NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.0001		MAIN SECTIONS
0.0002		SECTION LIST 1
0.0003		SECTION LIST 2
0.0004		SECTION LIST 3
0.0005		SECTION LIST 4
0.0006		SECTION LIST 5
0.0007		SECTION LIST 6
0.0008		SECTION LIST 7
0.0009		SECTION LIST 8
0.0010		SECTION LIST 9
0.0011		SECTION LIST 10
0.0012		SECTION LIST 11
0.0013		SECTION LIST 12
0.0014		MAINTENANCE PARTS
01.02.1		ENGINE - TURBO
01.02.1/ 1		ENGINE - NATURALLY ASPIRATED
01.04.0		CRANKCASE - NATURALLY ASPIRATED
01.04.0/ A		CRANKCASE AND CYLINDER - TURBO
01.04.0/ B		CRANKCASE AND CYLINDER - TURBO
01.04.0/ C		CRANKCASE AND CYLINDER - TURBO
01.04.2		OIL SUMP
01.04.3/ A		COVERS
01.04.3/ B		COVERS
01.04.3/ C		COVERS
01.04.5		ENGINE BREATHERS - NATURALLY ASPIRATED
01.06.0/ A	01	CYLINDER HEAD - NATURALLY ASPIRATED
01.06.0/ A	02	CYLINDER HEAD - TURBO
01.06.0/ B	01	CYLINDER HEAD - NATURALLY ASPIRATED
01.06.0/ B	02	CYLINDER HEAD - TURBO
01.06.0/ C		CYLINDER HEAD - TURBO
01.07.1	01	INTAKE MANIFOLD - NATURALLY ASPIRATED
01.07.1	02	INTAKE MANIFOLD - TURBO
01.07.7		EXHAUST MANIFOLD - TURBO
01.07.7/1		EXHAUST MANIFOLD - NATURALLY ASPIRATED
01.08.0	01	CRANKSHAFT - NATURALLY ASPIRATED
01.08.0	02	CRANKSHAFT - TURBO
01.08.1	01	CONNECTING ROD - NATURALLY ASPIRATED
01.08.1	02	CONNECTING ROD - TURBO
01.08.2	01	PISTONS - NATURALLY ASPIRATED
01.08.2	02	PISTONS - TURBO
01.08.3		FLYWHEEL
01.08.4		DAMPER
01.10.0		TIMING GEARS
01.12.0		CAMSHAFT
01.14.0	01	INJECTION PUMP - NATURALLY ASPIRATED
01.14.0	02	INJECTION PUMP - TURBO
01.14.0/ A	01	INJECTION PUMP, COMPONENTS - NATURALLY ASPIRATED
01.14.0/ A	02	INJECTION PUMP, COMPONENTS - TURBO
01.14.0/ B	01	INJECTION PUMP, COMPONENTS - NATURALLY ASPIRATED
01.14.0/ B	02	INJECTION PUMP, COMPONENTS - TURBO
01.14.0/ C		INJECTION PUMP, COMPONENTS - TURBO

MidWestTech | New Holland LM410, LM420, LM430, LM630, LM640 Telehandler Parts Cata... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01.14.0/ D		INJECTOR, EXTERNAL - NATURALLY ASPIRATED
01.14.0/ E	02	INJECTOR, EXTERNAL - TURBO
01.14.0/ E1	01	INJECTOR, INTERNAL - NATURALLY ASPIRATED
01.14.0/ F		INJECTOR, INTERNAL - TURBO
01.14.0/ 1		INJECTION PUMP, DRIVE
01.14.9		LINES
01.20.0		FUEL FILTER
01.20.1		FUEL PUMP
01.20.3		FUEL LINES
01.20.6	01	LINES, THERMOSTARTER - TURBO
01.20.6	02	THERMOSTARTER LINES - NATURALLY ASPIRATED
01.24.0		TURBOCHARGING - TURBO
01.24.1		TURBOCHARGER - TURBO
01.30.0	01	OIL PUMP - NATURALLY ASPIRATED
01.30.0	02	OIL PUMP - TURBO
01.30.2		OIL FILTER - OIL LEVEL GAUGE
01.30.5	01	TUBES, OIL PUMP - TURBO
01.30.5	02	TUBES, OIL PUMP - NATURALLY ASPIRATED
01.31.0	01	HEAT EXCHANGER - NATURALLY ASPIRATED
01.31.0	02	HEAT EXCHANGER - TURBO
01.32.0		WATER PUMP
01.32.3	01	ENGINE COOLING PIPING - NATURALLY ASPIRATED
01.32.3	02	ENGINE COOLING PIPING - TURBO
01.32.6		TEMPERATURE CONTROL
01.34.7		FAN
01.36.0		STARTER MOTOR
01.36.5		THERMOSTARTER AUXILIARY DEVICE
01.39.0	01	AIR COMPRESSOR
01.39.0	02	AIR COMPRESSOR
01.40.0		ALTERNATOR
02.04.2		FUEL LINES AND FUEL INDICATOR
02.16.0	01	AIR CLEANER, PRE-CLEANER AND HEAT SHIELD
02.16.0	02	AIR CLEANER, PRE-CLEANER AND HEAT SHIELD
02.16.0/ 1	01	MUFFLER
02.16.0/ 1	02	MUFFLER - TURBO
02.16.0/ 1	03	MUFFLER - NATURALLY ASPIRATED
02.17.0		RADIATOR
02.26.0		ENGINE INSTALLATION
03.28.0		GEARBOX, COUPLING BLOCK - POWERSHUTTLE
03.28.0/ 0A		GEARBOX - POWERSHUTTLE
03.28.0/ 0B		ELECTRICAL CONTROL VALVE
03.28.0/ 0C		GEARBOX - POWERSHUTTLE
03.28.0/ 1		GEARBOX - POWERSHIFT
03.28.0/ 1A		GEARBOX, COUPLING BLOCK - POWERSHIFT
03.28.0/ 1B		GEARBOX, HOUSING - POWERSHIFT
03.28.0/ 1C		GEARBOX, COUPLING BLOCK - POWERSHIFT
03.28.0/ 1D		GEARBOX, PUMP GEARS - POWERSHIFT
03.28.0/ 1E		GEARBOX, PUMP AND FILTER - POWERSHIFT
03.28.0/ 1F		GEARBOX, DRIVE GEARING - POWERSHIFT
03.28.0/ 1G		GEARBOX, COMPONENTS - POWERSHIFT
03.28.0/ 1H		GEARBOX, COMPONENTS (3RD AND 4TH) - POWERSHIFT

MidWestTech | New Holland LM410, LM420, LM430, LM630, LM640 Telehandler Parts Cata... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03.28.0/ 1I		GEARBOX, COMPONENTS (1ST AND 2ND) - POWERSHIFT
03.28.0/ 1J		GEARBOX, ELECTRONIC CONTROL - POWERSHIFT
04.38.1		POWER TAKE-OFF, FRONT AXLE - POWERSHIFT
04.38.1/ 1		POWER TAKE-OFF, FRONT AXLE - POWERSHUTTLE
04.40.0	01	STEERING CYLINDER, FRONT AXLE - POWERSHUTTLE
04.40.0	02	STEERING CYLINDER, FRONT AXLE - POWERSHUTTLE
04.40.0	03	STEERING CYLINDER, FRONT AXLE - POWERSHUTTLE
04.40.0	04	STEERING CYLINDER, FRONT AXLE - POWERSHUTTLE
04.40.0/0A	01	CASING, FRONT AXLE - POWERSHUTTLE
04.40.0/0A	02	CASING, FRONT AXLE - POWERSHUTTLE
04.40.0/0A	03	CASING, FRONT AXLE - POWERSHUTTLE
04.40.0/0A	04	CASING, FRONT AXLE - POWERSHUTTLE
04.40.0/0B	01	DIFFERENTIAL, FRONT AXLE - POWERSHUTTLE
04.40.0/0B	02	DIFFERENTIAL, FRONT AXLE - POWERSHUTTLE
04.40.0/0B	03	DIFFERENTIAL, FRONT AXLE - POWERSHUTTLE
04.40.0/0B	04	DIFFERENTIAL, FRONT AXLE - POWERSHUTTLE
04.40.0/0C	01	REDUCTION, FRONT AXLE - POWERSHUTTLE
04.40.0/0C	02	REDUCTION, FRONT AXLE - POWERSHUTTLE
04.40.0/0C	03	REDUCTION, FRONT AXLE - POWERSHUTTLE
04.40.0/0C	04	REDUCTION, FRONT AXLE - POWERSHUTTLE
04.40.0/0D	01	BRAKES, FRONT AXLE
04.40.0/0D	02	BRAKES, FRONT AXL
04.40.0/0D	03	BRAKES, FRONT AXLE
04.40.0/0D	04	BRAKES, FRONT AXL
04.40.0/1	01	FRONT AXLE - POWERSHIFT
04.40.0/1	02	STEERING CYLINDER, FRONT AXLE - POWERSHIFT
04.40.0/1	03	STEERING CYLINDER, FRONT AXLE - POWERSHIFT
04.40.0/1A	01	FRONT AXLE CASING - POWERSHIFT
04.40.0/1A	03	FRONT AXLE CASING - POWERSHIFT
04.40.0/1A	04	FRONT AXLE CASING - POWERSHIFT
04.40.0/1B	01	DIFFERENTIAL, FRONT AXLE - POWERSHIFT
04.40.0/1B	02	DIFFERENTIAL, FRONT AXLE - POWERSHIFT
04.40.0/1B	03	DIFFERENTIAL, FRONT AXLE - POWERSHIFT
04.40.0/1B	04	DIFFERENTIAL, FRONT AXLE - POWERSHIFT
04.40.0/1C	01	REDUCTION, FRONT AXLE - POWERSHIFT
04.40.0/1C	02	REDUCTION, FRONT AXLE - POWERSHIFT
04.40.0/1C	03	REDUCTION, FRONT AXLE - POWERSHIFT
04.40.0/1C	04	REDUCTION, FRONT AXLE - POWERSHIFT
04.40.0/1D	01	BRAKES, FRONT AXL
04.40.0/1D	02	BRAKES, FRONT AXL
04.40.0/1D	03	BRAKES, FRONT AXL
04.40.0/1D	04	BRAKES, FRONT AXL
05.38.3		POWER TAKE-OFF, REAR AXLE
05.44.0/0	01	REAR AXLE - POWERSHUTTLE
05.44.0/0	02	REAR AXLE - POWERSHUTTLE
05.44.0/0A	01	CASING, REAR AXLE - POWERSHUTTLE
05.44.0/0A	02	CASING, REAR AXLE - POWERSHUTTLE
05.44.0/0A	03	CASING, REAR AXLE - POWERSHUTTLE
05.44.0/0B	01	DIFFERENTIAL, REAR AXLE
05.44.0/0B	02	DIFFERENTIAL, REAR AXLE
05.44.0/0B	03	DIFFERENTIAL, REAR AXLE

MidWestTech | New Holland LM410, LM420, LM430, LM630, LM640 Telehandler Parts Cata... Order the manual at mid-west-tech.com >