# PARTS CATALOG

## LV80
## TRACTOR LOADER

Issued03-2002
Revised08-2004
Revised05-2005

86634756-02NA

NEW HOLLAND
CONSTRUCTION



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 02 -01 | RADIATOR - MOUNTING (MODELS WITHOUT AIR CONDITIONING) |
| 02 -01A | RADIATOR - MOUNTING (MODELS WITH AIR CONDITIONING) |
| 02 -02 | RADIATOR ASSY (MODELS WITHOUT AIR CONDITIONING) |
| 02 -02A | RADIATOR ASSY (MODELS WITH AIR CONDITIONING) |
| 02 -03 | AIR CLEANER - AIR INTAKE PARTS |
| 02 -04 | MUFFLER - EXHAUST SYSTEM (WITH TURBOCHARGER) |
| 02 -05 | MUFFLER - EXHAUST SYSTEM (WITHOUT TURBOCHARGER) |
| 02 -06 | COLD START SYSTEM |
| 02 -07 | ENGINE - MOUNTING |
| 02 -08 | WATER PUMP SYSTEM |
| 02 -09 | FRONT GEAR COVER |
| 02 -10 | MANIFOLDS |
| 02 -11 | TURBOCHARGER SYSTEM |
| 02 -12 | TURBOCHARGER ASSY |
| 02 -13 | OIL FILTER AND COOLER |
| 02 -14 | OIL PUMP AND OIL PAN |
| 02 -15 | CYLINDER HEAD COVERS |
| 02 -16 | CYLINDER HEAD AND VALVE MECHANISM - 4-390 |
| 02 -17 | CYLINDER HEAD AND VALVE MECHANISM - 4T-390 |
| 02 -18 | CAMSHAFT |
| 02 -19 | CYLINDER BLOCK (WITH TURBOCHARGER) |
| 02 -19A | CYLINDER BLOCK (WITHOUT TURBOCHARGER) |
| 02 -20 | CRANKSHAFT |
| 02 -21 | FLYWHEEL AND HOUSING |
| 02 -22 | PISTONS AND CONNECTING RODS (WITH TURBOCHARGER) |
| 02 -22A | PISTONS AND CONNECTING RODS (WITHOUT TURBOCHARGER) |
| 02 -23 | GASKET KIT, VALVE GRIND |
| 02 -24 | GASKET KIT, CYLINDER BLOCK |
| 02 -25 | GASKET KIT, BASIC SERVICE ENGINE |
| 03 -01 | FUEL LINES, RESERVOIR - FILTER, IN-LINE FUEL |
| 03 -02 | CONTROLS - THROTTLE, HAND |
| 03 -03 | CONTROLS - THROTTLE, FOOT |
| 03 -04 | FUEL INJECTION SYSTEM |
| 03 -05 | FUEL FILTER |
| 03 -06 | FUEL INJECTION PUMP AND DRIVE |
| 03 -07 | FUEL INJECTION NOZZLE |
| 04 -01 | STARTER |
| 04 -02 | ALTERNATOR |
| 04 -03 | STARTER MOUNTING - ALTERNATOR MOUNTING |
| 04 -04 | HARNESS, ENGINE - MOUNTING AND CONNECTIONS |
| 04 -05 | BATTERY - CABLES AND CUTOFF SWITCH |
| 04 -06 | BATTERY, DUAL - COLD START |
| 04 -07 | HARNESS, FRONT CONSOLE - SWITCHES |
| 04 -08 | HARNESS, SIDE CONSOLE - MOUNTING AND CONNECTIONS |
| 04 -09 | HARNESS, SIDE CONSOLE - SWITCHES |
| 04 -10 | INSTRUMENT PANEL, FRONT - COVERS |
| 04 -11 | INSTRUMENT PANEL, SIDE - SWITCHES AND COVERS |
| 04 -12 | INSTRUMENT CLUSTER |
| 04 -13 | ELECTRICAL - LAMPS, ROPS CANOPY |
| 04 -13A | ELECTRICAL - LAMPS, ROPS CAB |
| 04 -13B | LAMP ASSY - CAB MODELS |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 04 -14 | HORN - ALARM, BACKUP |
| 04 -15 | BEACON, ROTATING |
| 05 -01 | STEERING WHEEL - COLUMN |
| 05 -02 | HYDRAULICS - STEERING (MODELS WITHOUT HUSCO LOADER VALVE) |
| 05 -02A | HYDRAULICS - STEERING (MODELS WITH HUSCO LOADER VALVE) |
| 05 -03 | STEERING COLUMN |
| 05 -04 | CYLINDER ASSY - STEERING |
| 05 -05 | AXLE, FRONT - SPINDLES |
| 05 -06 | HUB AND BEARINGS, FRONT WHEEL |
| 05 -07 | AXLE - MOUNTING |
| 05 -08 | AXLE, FRONT - HOUSING |
| 05 -09 | AXLE, FRONT - HOUSING, SWIVEL |
| 05 -10 | AXLE, FRONT - CYLINDER, STEERING |
| 05 -11 | AXLE, FRONT - HUB AND BEARINGS |
| 05 -12 | WHEELS, FRONT - TIRES |
| 06 -01 | AXLE, FRONT DRIVE - MOUNTING |
| 06 -02 | AXLE, FRONT DRIVE - HOUSING |
| 06 -03 | AXLE, FRONT DRIVE - HOUSING, SWIVEL |
| 06 -04 | AXLE, FRONT DRIVE - CYLINDER, STEERING |
| 06 -05 | AXLE, FRONT DRIVE - SHAFTS, AXLE |
| 06 -06 | AXLE, FRONT DRIVE - PLANETARY |
| 06 -07 | AXLE, FRONT DRIVE - DIFFERENTIAL |
| 06 -08 | AXLE, FRONT DRIVE - RING AND PINION |
| 06 -09 | DRIVE SHAFT, FRONT AXLE |
| 06 -10 | COOLING SYSTEM - TRANSMISSION (MODELS WITHOUT AIR CONDITIONING) |
| 06 -10A | COOLING SYSTEM - TRANSMISSION (MODELS WITH AIR CONDITIONING) |
| 06 -11 | TRANSMISSION - MOUNTING |
| 06 -12 | TRANSMISSION ASSY - FILTER, OIL |
| 06 -13 | TRANSMISSION ASSY (2WD) - HOUSING |
| 06 -14 | TRANSMISSION ASSY (4WD) - HOUSING |
| 06 -15 | TRANSMISSION ASSY - PUMP, OIL |
| 06 -16 | TRANSMISSION ASSY - SHIFTER MECHANISM |
| 06 -17 | TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY |
| 06 -18 | TRANSMISSION ASSY - SHAFT, INPUT |
| 06 -19 | TRANSMISSION ASSY - SHAFT, SECONDARY |
| 06 -20 | TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT |
| 06 -21 | TRANSMISSION ASSY (329081A3 OR 329082A3) - VALVE, CONTROL |
| 06 -21A | TRANSMISSION ASSY (87456845 OR 87456846) - VALVE, CONTROL |
| 06 -22 | TRANSMISSION ASSY (4WD) - VALVE, SOLENOID |
| 06 -23 | WHEELS, REAR - TIRES |
| 06 -24 | AXLE, REAR DRIVE - MOUNTING |
| 06 -25 | AXLE, REAR - DIFFERENTIAL LOCK |
| 06 -26 | AXLE, REAR DRIVE - HOUSING |
| 06 -27 | AXLE, REAR DRIVE - DIFFERENTIAL (86981746 AXLE/ 2 SPIDER DIFFERENTIAL) |
| 06 -27A | AXLE, REAR DRIVE - DIFFERENTIAL (87447233 AXLE/ 4 SPIDER DIFFERENTIAL) |
| 06 -28 | AXLE, REAR DRIVE - RING AND PINION |
| 06 -29 | AXLE, REAR DRIVE - DIFFERENTIAL LOCK |
| 06 -30 | AXLE, REAR DRIVE - PLANETARY |
| 06 -31 | DRIVE SHAFT, REAR AXLE |
| 07 -01 | AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL |
| 07 -02 | AXLE, REAR DRIVE - BRAKE, PARKING |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 07 -03 | BRAKE - PEDALS |
| 07 -04 | HYDRAULICS - BRAKE MASTER CYLINDER |
| 07 -05 | CYLINDER ASSY - BRAKE MASTER |
| 07 -06 | CONTROLS - BRAKE, PARKING |
| 08 -01 | HYDRAULICS - PUMP, FILTER AND LOADER VALVE (MODELS WITHOUT HUSCO LOADER VALVE) |
| 08 -01A | HYDRAULICS - PUMP, FILTER AND LOADER VALVE (WITH HUSCO LOADER VALVE W/SEPARATE PRIORITY VALVE) |
| 08 -01B | HYDRAULICS - PUMP, FILTER AND LOADER VALVE (WITH HUSCO LOADER VALVE W/BUILT-IN PRIORITY VALVE) |
| 08 -02 | HYDRAULICS - COOLER, RETURN LINES AND FILTER |
| 08 -03 | HYDRAULICS - CYLINDER, LOADER LIFT |
| 08 -04 | HYDRAULICS - CYLINDER, LOADER BUCKET |
| 08 -05 | HYDRAULICS - CYLINDER, LOADER CLAM |
| 08 -06 | HYDRAULICS - CYLINDER, LOADER CLAM |
| 08 -07 | HYDRAULICS - GLIDE RIDE CONTROL |
| 08 -07A | HYDRAULICS - RIDE CONTROL (87433240 SOLENOID VALVE)(MODELS WITH HUSCO LOADER VALVE) |
| 08 -08 | HYDRAULICS - COUPLER, LOADER TOOL QUICK |
| 08 -08A | HYDRAULICS - COUPLER, LOADER TOOL QUICK (MODELS WITH HUSCO LOADER VALVE) |
| 08 -09 | HYDRAULICS - COUPLER, LOADER TOOL QUICK |
| 08 -09A | VALVE, COUPLER (87435909) - LOADER TOOL |
| 08 -10 | HYDRAULICS - HITCH, THREE POINT |
| 08 -11 | HYDRAULICS - HITCH LOCK VALVE, THREE POINT |
| 08 -12 | HYDRAULICS - VALVE, LASER CONTROL |
| 08 -13 | PUMP, EQUIPMENT HYDRAULIC |
| 08 -14 | VALVE ASSY - LOADER CONTROL, TWO SPOOL |
| 08 -15 | VALVE ASSY - LOADER CONTROL, THREE SPOOL |
| 08 -16 | VALVE SECTION - INLET |
| 08 -17 | VALVE SECTION - LOADER BUCKET |
| 08 -18 | VALVE SECTION - LOADER LIFT |
| 08 -19 | VALVE SECTION - OUTLET |
| 08 -20 | VALVE SECTION - LOADER CLAM |
| 08 -21 | VALVE ASSY - RELIEF, CIRCUIT |
| 08 -21A | VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - USED WITH SEPARATE PRIORITY VALVE) |
| 08 -21B | VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - USED WITH SEPARATE PRIORITY VALVE) |
| 08 -21C | VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE) |
| 08 -21D | VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE) |
| 08 -22 | VALVE ASSY - HITCH, THREE POINT |
| 08 -23 | VALVE ASSY - HITCH, THREE POINT |
| 08 -24 | VALVE SECTION - HITCH INLET |
| 08 -25 | VALVE SECTION - HITCH LIFT |
| 08 -26 | VALVE SECTION - HITCH LIFT |
| 08 -27 | VALVE SECTION - HITCH PITCH, TILT AND IMPLEMENT |
| 08 -28 | VALVE, FLOW CONTROL - HITCH, THREE POINT |
| 08 -29 | VALVE, LOCK - HITCH, THREE POINT |



Order the manual at mid-west-tech.com >

## HYDRAULICS - CYLINDER, LOADER CLAM

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | 358237A1 | | 1 | VALVE Loader Control Valve, Three Spool, See Figure 08-15, For Mounting, See Figure 09-01 |
| 2 | | 325059 | | 2 | CONNECTOR, HYD. 7/8 fl x Or, Incl. Ref 3 |
| 3 | | 167269 | | 1 | O-RING 90 Duro, .755" ID x .097" Thk |
| 6 | | 120068 | | 2 | SCREW M10 x 40 |
| 7 | | D138055 | | 2 | CLAMP |
| 8 | | 120303A1 | | 2 | SPACER |
| 9 | | 140028 | | 2 | WASHER M10 |
| 10 | | 86500689 | | 2 | NUT M10; 10.9 |
| 11 | | 138467A1 | | 2 | HOSE 680 mm (26-3/4 in) |
| 12 | | 196824A1 | | 1 | PIPE Upper Clam Port |
| 13 | | 196821A1 | | 1 | PIPE Lower Clam Port |
| 14 | | D138055 | | 4 | CLAMP |
| 15 | | 86500689 | | 4 | NUT M10; 10.9 |
| 16 | | 140028 | | 4 | WASHER M10 |
| 17 | | 86513050 | | 2 | PLUG 7/8 fl, Not Used On Models With Clam Bucket |
| 19 | | 232945A1 | | 1 | PIPE Lower Clam Port |
| 20 | | 86511517 | | 1 | CONNECTOR, HYD. |
| 22 | | 360937A1 | | 1 | TUBE ASSY. Lower Clam Port |
| 23 | | 360916A1 | | 1 | TUBE ASSY. Upper Clam Port; Models Without Husco Loader Valve |
| 23 | | 87447352 | | 1 | TUBE ASSY. Upper Clam Port; Models With Husco Loader Valve |
| 24 | | 360918A1 | | 1 | TUBE ASSY. Lower Clam Port, For Service, Order 19, 20, 22; Models Without Husco Loader Valve |
| 24 | | 87447350 | | 1 | TUBE ASSY. Lower Clam Port; Models With Husco Loader Valve; For Service Order Ref 20, 22 & 87313507 Tube at Loader Valve |
| 25 | | 378970 | | 1 | CONNECTOR, HYD. 1-5/16 fl x Or, Incl. Ref 26 |
| 26 | | 167268 | | 1 | O-RING 90 Duro, 1.171" ID x .116" Thk |
| 27 | | 429149A1 | | 1 | HOSE ASSY. 725 mm, Power Beyond, Loader Valve To Flow Control Valve |



MidWestTech | New Holland LV80 Tractor Loader Parts Catalog | Publication 86634756-02 Order the manual at mid-west-tech.com >

## CYLINDER ASSY - HITCH TILT, THREE POINT

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | 86982482 | | 1-2 | CYLINDER ASSY. Three-Point Hitch Tilt, 64 ID x 160 mm strk, Incl. Ref 2- 19 |
| 2 | | 137913A1 | | 1 | SLEEVE, HYD' CYL' Incl. Ref 3 |
| 3 | | D34359 | | 2 | BUSHING |
| | | NSS | | 1 | NOT SERVICED SEPARATELY Gland, Cylinder, Incl. Ref 4 - 8 |
| 4 | | 118115A2 | | 1 | GLAND |
| 5 | | D95141 | | 1 | SEALRING |
| 6 | | D36968 | | 1 | GASKET |
| 7 | | G109297 | | 1 | BACK-UP RING |
| 8 | | 510185 | | 1 | O-RING 2.234" ID x .139" Thk |
| 9 | | 86642312 | | 1 | SCREW No. 8 x 3/8 |
| 10 | | 137917A1 | | 1 | ROD, PISTON 32 mm (1-1/4 in) dia, Incl. Ref 11, 12 |
| 11 | | D22200 | | 1 | BEARING |
| 12 | | 271429 | | 2 | RING, SNAP No. 162 |
| 13 | | 137528A1 | | 1 | PISTON |
| 14 | | G102289 | | 1 | SEAL |
| 15 | | G100713 | | 1 | SEAL |
| 16 | | G100714 | | 1 | RING |
| 17 | | 88344 | | 1 | SCREW 3/4 NF x 2; 8; No Longer Used, Order 86982434 Bolt With Washer |
| 18 | | G32317 | | 1 | WASHER No Longer Used, Order 86982434 Bolt With Washer |
| 19 | | 80710 | | 1 | NIPPLE, LUBE 1/8 PT x 21/32 |
| 20 | | 86982434 | | 1 | BOLT, SPECIAL Bolt With Washer, 3/4 x 2 |
| | | 86982384 | | 1 | KIT, SEALS Incl. Ref 5 - 8, 14 - 16 |



MidWestTech | New Holland LV80 Tractor Loader Parts Catalog | Publication 86634756-02 Order the manual at mid-west-tech.com >

CAB - DOORS, INTERIOR

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | | | | LEFT-HAND AND RIGHT-HAND CAB DOORS - INTERIOR |
| 1 | | 137868A3 | | 1 | DOOR ASSY. Left-Hand Door Frame; Incl. Ref 2 |
| 1A | | 137869A3 | | 1 | DOOR ASSY. Right-Hand Door Frame; Incl. Ref 2; Not Illustrated |
| 2 | | R53562 | | 1 | BRACKET Cable Bracket; Welded to Door Frame |
| 3 | | 281069A1 | | 2 | HANDLE Door Window Handle |
| 4 | | 281068A1 | | 2 | HANDLE Push Type Latch |
| 5 | | 140-107 | | 4 | SCREW Screw, No. 10 x 3/4 |
| 6 | | F45165 | | 8 | SAFETY NUT Nut, No. 10 |
| 7 | | 142-104 | | 4 | SCREW Screw, No. 10 x 1 |
| 8 | | F64198 | | 4 | BUSHING Black Nylon Spacer; Glass to Bracket |
| 9 | | 195-81023 | | 8 | WASHER Washer, 1/4 x 9/16 x 3/64 |
| 10 | | F44881 | | 2 | CYLINDER ASSY. Door Cylinder, Left-Hand and Right-Hand |
| 11 | | 1340345C1 | | 2 | BALL JOINT Cylinder Ball Stud |
| 12 | | 230-4215 | | 2 | NUT Nut, 5/16 |
| 13 | | 108938A2 | | 1 | PANEL Left-Hand Door Panel |
| 13A | | 108936A2 | | 1 | PANEL Right-Hand Door Panel; Not Illustrated |
| 14 | | 260-16524 | | 4 | SCREW Screw, No. 10 x 1-1/2, Black; Left-Hand and Right-Hand |
| 15 | | R53000 | | 4 | NUT Screw Retainer; Left-Hand and Right-Hand |
| 16 | | 1958970C1 | | 2 | HANDLE Inner Door Handle; Left-Hand and Right-Hand |
| 17 | | 165-129 | | 8 | SCREW Bolt, 1/4 x 3/4, Black; Left-Hand and Right-Hand |
| 18 | | 1971368C1 | | 2 | PLATE ASSY. Retainer Plate; Left-Hand and Right-Hand |
| 19 | | 1977399C1 | | 2 | SUPPORT ASSY. Cylinder Bracket |
| 20 | | 413-48 | | 4 | BOLT 1/4 x 1/2 |
| 21 | | 492-11025 | | 4 | WASHER, LOCK 1/4" |
| 22 | | R54047 | | 4 | PAD Bracket Shim; Left-Hand and Right-Hand |
| 23 | | F44883 | | 2 | CLIP, ELECTRICAL |
| 24 | | 291129A1 | | 1 | STEM Hold Open Rod; Left-Hand |
| 25 | | 280336A1 | | 1 | STEM Hold Open Rod; Right-Hand |
| 26 | | 895-11008 | | 4 | WASHER 9 x 17 x 1,6 mm Washer |



MidWestTech | New Holland LV80 Tractor Loader Parts Catalog | Publication 86634756-02 Order the manual at mid-west-tech.com >