SERVICE MANUAL

LV80
Tractor Loader



86641827

MidWestTech | New Holland LV80 Tractor Loader Service Manual | Publication 86641827

Order the manual at mid-west-tech.com >

SECTION 2
439 DIESEL ENGINE

TABLE OF CONTENTS

GENERAL INFORMATION

Proprietary Notice V
Company Policy V
Parts and Accessories V
Model Codes V
Owner Assistance VI
Spare Parts VI
To The Owner VII
Improvements VII
Precautionary Statements VIII
Personal Safety VIII
Machine Safety VIII
Safety Rules IX
California Proposition 65 X

CHAPTER 1

ENGINE AND RADIATOR REMOVAL AND INSTALLATION

Table of Contents 1-1
Special Tools 1-3
Specifications 1-3
Radiator Removal 1-3
Engine Removal 1-6
Installing the Front Engine Support 1-22

CHAPTER 2

STALL TESTS

Table of Contents 2-1
Specifications 2-3
General Information 2-3
Preparing the Machine for the Stall Test 2-3
Procedure to Heat Torque Converter and Hydraulic Oil 2-4
Stall Test Procedure 2-4
Check Sheet - NA Engine 2-5
Check Sheet - Turbo Engine 2-6

CHAPTER 3

SPECIFICATIONS

Table of Contents 3-1
Run-in Instructions 3-3
Identification Marks 3-5
Engine Specification Details 3-6
Special Torques 3-13

CHAPTER 4

AFTERCOOLER

Table of Contents 4-1
Specifications 4-3
Special Torque 4-3
Special Tools 4-3
Removing the Aftercooler 4-4
Inspecting the Aftercooler 4-8
Installing the Aftercooler 4-9

MidWestTech | New Holland LV80 Tractor Loader Service Manual | Publication 86641827 Order the manual at mid-west-tech.com >

CHAPTER 5

CYLINDER HEAD AND VALVE TRAIN

Table of Contents 5-1
Specifications 5-3
Identification Marks 5-4
Special Torques 5-5
Special Tools 5-6
Cylinder Head Removal 5-7
Cylinder Head Disassembly 5-15
Checking and Resurfacing the Cylinder Head 5-16
Valve Guide Replacement 5-18
Inspection of the Valves and Valve Seats 5-21
Valve Seat Installation 5-25
Refacing Intake and Exhaust Valves and Valve Seats 5-26
Diagnosis of Different Dye Patterns 5-28
Cylinder Head Assembly 5-38
Rocker Arm Disassembly 5-40
Rocker Arm Assembly 5-41
Locating Top Center 5-49
Adjusting the Rocker Arm to Valve Clearance 5-50

CHAPTER 6

CYLINDER BLOCK

Table of Contents 6-1
Specifications 6-3
Special Torques 6-6
Special Tools 6-7
Front Oil Seal Replacement 6-9
Rear Oil Seal Replacement 6-13
Front Oil Seal and Wear Sleeve Installation 6-16
Rear Oil Seal and Wear Sleeve Installation 6-21
Cylinder Wall Inspection 6-29
Reconditioning the Engine Cylinder Block 6-33
Piston and Connecting Rod Disassembly and Installation 6-37
Piston and Connecting Rod Assembly and Installation 6-43
Crankshaft 6-47
Crankshaft and Main Bearings 6-52
Crankshaft Gear Removal 6-59
Crankshaft Inspection 6-59
Crankshaft Reconditioning 6-61
Crankshaft Installation 6-62
Camshaft 6-77
Flywheel Housing Bore Alignment Check 6-89
Flywheel Housing Face Alignment Check 6-91
Flywheel 6-93
Tachometer Drive, If Equipped 6-94
Expansion Plug Removal and Installation 6-95
Crankcase Pressure Check (Blow By) 6-104

MidWestTech | New Holland LV80 Tractor Loader Service Manual | Publication 86641827 Order the manual at mid-west-tech.com >

CHAPTER 7
LUBRICATION SYSTEM
Table of Contents 7-1
Specifications 7-3
Special Torques 7-4
Lube Flow Chart 7-4
Oil Pump 7-5
Oil Pressure Relief Valve Service 7-11
Oil Filter Housing and Oil Cooler 7-13
Oil Pan and Oil Inlet Tube 7-15

CHAPTER 8
BALANCER
Table of Contents 8-1
Specifications 8-3
Special Torques 8-3
Three Gear Balancer 8-4

CHAPTER 9
COOLING SYSTEM
Table of Contents 9-1
Specifications 9-3
Safety Rules 9-3
How to Clean the Cooling System 9-3
Water Pump 9-4
Thermostat 9-6
Coolant Inlet Manifold 9-10
Fan Pulley Bracket 9-12
Belt Tensioner 9-15
Thermostat Service 9-18

CHAPTER 10
TURBOCHARGER
Table of Contents 10-1
Specifications 10-3
Special Torques 10-3
Special Tools 10-3
Troubleshooting Guide for the Turbocharger 10-4
Servicing the Turbocharger 10-5

CHAPTER 11
HX25W AND HX30W TURBOCHARGER
Table of Contents 11-1
Specifications 11-3
Special Torques 11-3
Troubleshooting Guide for the Turbocharger 11-4
Turbocharger Service 11-5
Cleaning and Inspection 11-12
Turbocharger Wastegate Calibration 11-26

NOTE: New Holland reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

MidWestTech | New Holland LV80 Tractor Loader Service Manual | Publication 86641827 Order the manual at mid-west-tech.com >