OPERATOR'S MANUAL

Articulated Dump Trucks AD250 (3.5 Version)



NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland AD250 (3.5 Version) Articulated Dump Truck Operator's Manua... Order the manual at mid-west-tech.com >

CONTENTS

	Page
CONDITIONS OF USE	1
INTRODUCTION	3
Copyright	3
CONFORMITY MARKING	4
INFORMATION ON THIS HANDBOOK	5
Definitions	5
Contents	5
Symbols	5
Purpose of this handbook	6
To whom this handbook is addressed	6
Safekeeping of this handbook	6
Updates to this handbook	6
Units of measure	6
SCHEDULED USE	7
VEHICLE OPERATORS	7
WASTE DISPOSAL	8
SCRAPPING THE VEHICLE	8
WARRANTY AND LIABILITY OF THE MANUFACTURER	9
Warranty conditions	9
Liability	9
SERVICE	9
Warranty coupons	9
Service	9
Spare parts	9
SAFETY INSTRUCTIONS	1
INTRODUCTION	3
SAFETY INFORMATION AND SYMBOLS	3
GENERAL INSTRUCTIONS	4
PREVENTING FIRES	5
INSTRUCTIONS FOR USE	7
CAB	7
STARTING AND STOPPING	8
DRIVING THE VEHICLE	9
WORKING THE VEHICLE	9
TOWING THE VEHICLE	11
REPLACING A WHEEL	11

	Page
MAINTENANCE INSTRUCTIONS	12
Introduction	12
Preventing injuries	13
Preventing intoxication and contamination	15
Preventing burns and electrocution	16
INSTRUCTIONS FOR USE	1
SAFETY WARNINGS FOR CORRECT VEHICLE USE	3
CAB	5
Accessing the cab	5
Door	5
Driver's seat	6
Emergency seat	6
Seat belts	7
MAIN CONTROLS	8
Control and utility arrangement	8
Instrument panel and warning lights	10
Detail A: warning lights panel	10
Adjusting the steering wheel position	11
Rearview mirrors	11
Side windows	11
Position light and headlight control	12
Headlight control	12
Direction indicator and horn control	12
Windscreen wiper/washer control	12
Driven rearview mirror control	13
Heated rearview mirror control	13
Side window wiper control	13
Side window washer control	13
Engine ignition switch	14
Camera power control	14
Hazard light control	14
Steering	14
Accelerator	15
Service brake	15
Parking brake	15
AUTO MODE	15
Automatic transmission	16
Longitudinal differential lock control	17

MidWestTech | New Holland AD250 (3.5 Version) Articulated Dump Truck Operator's Manua... Order the manual at mid-west-tech.com >

	Page
Body hoist control	17
Climate control system controls	18
STARTING AND STOPPING THE ENGINE	**20**
Refueling	20
Checks before starting the engine	20
Starting the engine at normal temperature	21
Jump starting	22
Warming the engine	23
Stopping the engine	23
STARTING THE VEHICLE	**24**
STOPPING AND PARKING THE VEHICLE	**25**
Stopping	25
Standing	25
Parking	25
DRIVING THE VEHICLE	**26**
Precautions during the initial period of use	26
Normal running	26
Using the automatic transmission	27
Using the differential lock/front traction engagement	31
WORKING THE VEHICLE	**32**
Hauling and empty return	32
Dumping	32
TOWING THE VEHICLE	**34**
REPLACING A COMPLETE WHEEL	**36**
GROUND HOIST CONTROL	**38**
MAINTENANCE INSTRUCTIONS	**1**
SAFETY WARNINGS FOR VEHICLE MAINTENANCE	**3**
INTRODUCTION	**5**
PRELIMINARY OPERATIONS	**6**
Raised body safety lock	6
Opening the battery disconnect switch	6
Opening the front mudguards	7
Opening the hood manually	7
Shutting the hood manually	7
Opening the hood electrically	7
Shutting the hood electrically	7

	Page
SCHEDULED MAINTENANCE PROGRAM	**8**
Checking, adjusting and cleaning operations	8
Lubrication and replacement operations	9
LUBRICATION AND SCHEDULED REPLACEMENT CHART	**10**
Lubrication and scheduled replacement chart key	11
OPERATIONS TO BE CARRIED OUT EVERY DAY	**12**
Checking engine oil level	12
Checking engine coolant level	12
Bleeding fuel filter condensate	12
Checking accessory belt integrity	13
Checking hydraulic fluid level	13
Checking windscreen washer fluid level	13
ENGINE	**14**
Change engine oil	14
Replace engine oil filters	15
Cleaning engine breather	15
Accessory drive belt	16
Adjusting tappet clearance	17
FUEL FEED SYSTEM	**18**
Replace fuel filter	18
Bleeding fuel feed circuit air	19
Fuel tank	19
AIR INTAKE SYSTEM	**20**
Checking turbo compressor lubrication	20
Cleaning/replacing the main filtering element	20
Replacing secondary filtering element	21
COOLING SYSTEM	**22**
Checking antifreeze concentration	23
Clean radiator surface	23
Change engine coolant	24
Checking coolant–transmission oil heat exchanger tightness	24
AUTOMATIC TRANSMISSION	**25**
Checking oil level	25
Changing oil	26
Replacing oil filter	26

MidWestTech | New Holland AD250 (3.5 Version) Articulated Dump Truck Operator's Manua... Order the manual at mid-west-tech.com >

	Page
FRONT AXLE/REAR TANDEM AXLES	**27**
Checking axle oil/transfer case oil level	27
Changing axle/transfer case oil	28
HYDRAULIC SYSTEM	**30**
Change hydraulic oil	30
Replacing pressurised oil filter (pump outlet)	30
Replacing inner hydraulic oil filter (intake)	31
Changing hydraulic brake oil filter	31
Checking fitting and pipe tightness	31
Bleeding the hydraulic system	32
GREASING	**33**
SUSPENSION	**34**
Front suspension element inflating device	34
Equipment connection diagram	34
Changing the suspension oil element	34
Checking suspension element pressure	35
Inflating the suspension elements	35
BRAKING SYSTEM	**36**
Checking brake pad wear	36
TIRES AND WHEELS	**36**
Checking wheels and tires	36
Inflating tires	36
AIR CONDITIONING SYSTEM	**37**
Cleaning condenser	37
Cleaning/replacing passenger air cleaner	37
Checking system charge	37
BODYWORK	**38**
Replacing front windscreen wiper blade	38
Replacing side windscreen wiper blade	38
Windscreen washer fluid reservoir	38
Cleaning	39
ELECTRICAL SYSTEM	**40**
Precautions	40
Battery maintenance (not sealed)	41
Recharging with external devices	42
Fuse and relay box	42

	Page
LIGHTING SYSTEM	**43**
Replacing the headlight bulbs	43
Directing the headlights	43
Replacing front direction indicator/front position light bulbs	44
Replacing the side direction indicator bulbs	44
Replacing the rear light bulbs	44
Replacing the rear light bulbs	44
Replacing the supplementary headlight bulb	45
Replacing ceiling light bulb	45
STORING THE VEHICLE	**46**
Cleaning	46
Checks and repairs	46
Maintenance	46
Storage	47
Return to service	47
TECHNICAL DATA	**1**
VEHICLE COMPOSITION	**3**
DIMENSIONS [MM (FT)]	**4**
WEIGHTS	**5**
HORIZONTAL CENTER OF GRAVITY	**5**
PERFORMANCE	**6**
PERFORMANCE ALIGNMENT CHART	**7**
VEHICLE IDENTIFICATION DATA	**8**
Chassis number	8
POSITION OF IDENTIFICATION DATA ON MAIN GROUPS	**9**
Cab	9
Chassis	9
Engine	9
Gear shift	9
Drive axles	10
Hoist cylinder	10
Front suspension cylinder	10
MAIN GROUP CHARACTERISTICS	**11**
Engine	11
Automatic transmission	12
Front drive axle	12

MidWestTech | New Holland AD250 (3.5 Version) Articulated Dump Truck Operator's Manua... Order the manual at mid-west-tech.com >