580 Super K Loader Backhoe

Parts Catalog

8-6952

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 580 Super K Loader Backhoe Parts Catalog | Publication 8-6952 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner 2-9
Air Cleaner Mounting 2-5,2-7
Air Conditioner
  Blower 9-151
  Compressor 4-11
  Compressor Mounting 4-15
  Condenser 9-159
  Controls 9-141
  Evaporator Core 9-157
  Filter - air 9-149
  Receiver-Drier 9-159
Alarm - backup 4-49,4-49B,4-51
Alarm - warning 4-53
Alternator - electrical 4-7,4-9
Alternator Mounting 4-13
Antirollback - loader 9-9
Armrests - seat 9-125
Attachment Kit - hand
  held tools 8-59B,8-59D
Axle
  Front - four wheel drive
    Assembly ..... 6-43 - 6-61
    Ball Joints 6-47
    Control Lever 6-37,6-37B
    Differential 6-55,6-57
    Differential Carrier 6-43
    Drive Shaft 6-41
    Mounting 6-39
    Planetary 6-51,6-53
    Ring and Pinion 6-59,6-61
    Shafts 6-49
    Steering Cylinder 6-47
    Swivel Housing 6-45
  Front - two wheel drive 5-17
  Rear 6-79

B

Backhoe
  Boom 9-39,9-41
  Boom Latch 9-43
  Boom Lock 8-57,8-59
  Bucket Links - attachments 9-47D
  Buckets ..... 9-53 - 9-69
  Controls (See Controls)
  Control Tower 9-21
  Coupler - bucket 9-45,9-49
  Dipper 9-45
  Dipper Kit 9-47B
  Extendable Dipper 9-49,9-51
  Frost Point 9-47
  Hydraulics (See Hydraulic Systems)
  Mounting Parts 9-37

B

Backhoe-Cont.
  Stabilizers 9-35
  Swing Tower 9-37
  Valves (See Valves)
Backup Alarm 4-49,4-49B,4-51
Battery ..... 4-19 - 4-23
Beacon - rotating 4-57
Bearings - front wheel 5-19
Belts - fan, alternator, and
  compressor 2-3,2-3B,4-13,4-15
Belts - seat 9-109,9-111
Block - cylinder ..... 2-41 - 2-47
Blower - air conditioner 9-151
Boom Latch 9-43
Boom Lock 8-57,8-59
Boots
  Accelerator Pedal 3-9
  Backhoe Levers 9-21
  Differential Lock 6-33
  Dual Lever - loader 9-7
  Dual Lever - 4WD and
    parking brake 6-37,7-13
  Foot Swing Levers 9-21,9-25,9-27
  Hand Swing Levers 9-21,9-29,9-31
  Lamp Socket, instrument
    cluster 4-33
  Parking Brake Cable 7-13
  Shuttle Control Rod 6-29
  Single Lever - loader 9-3
  Single Lever - 2WD parking
    brake 7-13
  Suspension Seat 9-115
  Transaxle Control Lever 6-35
Box - battery and tool 4-19,4-21
Box - loader valve 9-95
Brake - differential, transaxle 7-3
Brake - parking 7-13
Brake - parking, transaxle 7-5
Brake - PTO 6-89,6-91
Brake Master Cylinder
  Assembly 7-11
  Hydraulic Circuit 7-9
  Mounting 7-7
Brake Pedals 7-7
Buckets - backhoe
  Bellhole and
    Graveyard 9-69
  Teeth ..... 9-53 - 9-69
  Trenching ..... 9-53 - 9-67
Buckets - loader
  Clam 9-19
  Long Lip 9-17

MidWestTech | Case 580 Super K Loader Backhoe Parts Catalog | Publication 8-6952 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

B

Buckets - loader-Cont.
- Short Lip 9-17
- Teeth 9-17,9-19

C

Cab
- Air Conditioner ..... 9-157 - 9-161
- Air Filter 9-149
- Blower 9-151
- Consoles - control 9-131
- Covers - interior 9-129
- Doors and Windows/ Glass ..... 9-127,9-133 - 9-139
- Electrical and Lighting ..... 4-37, ... 4-37B,4-41,4-41B,4-45,9-141,9-147
- Frame and Roof Cap 9-129
- Headliner, Louvers, and Dome Lamps 9-147
- Heater 9-153,9-155
- Mounting Parts 9-127
- Panel - cab control 9-141
- Windshield Wipers 9-143,9-145

Cables - battery ..... 4-19 - 4-23
Camshaft - engine 2-39
Canopy - ROPS 9-163
Chassis - tractor 9-85
Cluster - instrument 4-33
Clutch - power shuttle 6-19,6-21
Clutch - PTO 6-89,6-91
Clutch Cutout 4-27
Cold Start System 2-13,4-23
Column - steering 5-9
Compartment - operator manual 4-29
Compressor - air conditioner 4-11
Compressor Mounting 4-15
Concrete Breaker Fork 9-71
Controls
- Antirollback - loader 9-9
- Backhoe
  - Foot Swing ..... 9-23 - 9-27
  - Hand Swing 9-29,9-31
- Boom Latch 9-43
- Brake 7-7,7-13
- Clutch Cutout 4-27
- Engine Speed - throttle 3-7,3-9
- Extendable Dipper 9-27,9-31
- Front Drive Axle - 4WD 6-37,6-37B
- Hitch - three-point 9-73
- Loader
  - Bucket 9-5
  - Clam 9-7
  - Lift 9-3
- PTO 6-33

C

Controls-Cont.
- Return-to-Dig - loader 9-11
- Shuttle 6-29
- Steering 5-3
- Swing Sequence Valve - backhoe 9-33
- Transaxle Shift 6-35,6-81

Control Tower - backhoe 9-21
Converter - torque ..... 6-13 - 6-17
Cooler - hydraulic oil 6-5,8-13,8-15
Cooling Systems
- Engine 2-3,2-3B
- Engine Oil 2-31
- Hydraulic Oil 8-13,8-15
- Transaxle Shuttle 6-5,6-7

Core - evaporator, air conditioner 9-157
Counterweights 9-81,9-83
Coupler - backhoe bucket 9-45,9-49
Couplings - hydraulic line disconnect 8-3
Couplings - hydraulic pump to engine 8-3
Covers
- Anti-Vandalism
  - Instrument Panel - front 4-29
  - Instrument Panel - side 4-31,9-131
- Backhoe Control Tower 9-21
- Battery and Tool Box 4-19,4-21
- Cylinder Head 2-35
- Front Gear 2-23
- Fuse Box 9-131
- Instrument Panel 4-29,4-31
- Pump Guard - front 9-87
- Rear Closure Panel 9-105,9-107
- Steering Column 4-29,5-3
- Upright 9-93

Crankshaft 2-49
Cylinder - brake master 7-11
Cylinder Block ..... 2-41 - 2-47
Cylinder Head 2-37
Cylinders - hydraulic
- Boom - backhoe ..... 8-129 - 8-131D
- Bucket - backhoe ..... 8-137 - 8-139D
- Bucket - loader 8-119,8-119B
- Clam - loader 8-121
- Dipper - backhoe ..... 8-133 - 8-135D
- Dipper Extension - backhoe 8-141
- Lift - hitch, three-point 8-143
- Lift - loader ..... 8-117 - 8-117D
- Pitch - hitch, three-point 8-147
- Stabilizer - backhoe 8-123,8-123B
- Steering - 2WD 5-15
- Steering - 4WD 6-47
- Swing - backhoe ..... 8-125 - 8-127B

MidWestTech | Case 580 Super K Loader Backhoe Parts Catalog | Publication 8-6952 Order the manual at mid-west-tech.com >