LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX432R Balers

Parts Catalog

87058235 - 2/05

CASE IH

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.0016	01	MAIN SECTIONS
0.0017	01	SECTION LIST 1 - POWER TAKE-OFF
0.0019	01	SECTION LIST 3 - MAIN GEARBOX
0.0021	01	SECTION LIST 5 - AXLE
0.0022	01	SECTION LIST 6 - ELECTRICAL SYSTEM
0.0023	01	SECTION LIST 7 - HYDRAULIC SYSTEMS
0.0024	01	SECTION LIST 8 - SHEET METAL/DECALS
0.0025	01	SECTION LIST 9 - LUBRICATION
0.0027	01	SECTION LIST 11 - WHEELS
0.0028	01	SECTION LIST 12 - MAIN FRAME
0.0029	01	SECTION LIST 13 - FEEDER
0.0030	01	SECTION LIST 14 - BALE CHAMBER
0.0031	01	SECTION LIST 15 - KNOTTER/WRAPPER
0.0032	01	SECTION LIST 16 - BALE EJECTOR
0.0034	01	SECTION LIST 18 - ACCESSORIES
0.0037	01	VERSION LIST
0.0038	01	IDENTIFICATION PLATE
0.0039	01	MAINTENANCE PARTS
0.0039A	01	MAINTENANCE PARTS
0.0039B	01	MAINTENANCE PARTS
0.0041	01	CODE TABLE
01.00	01	SECTION LIST 1 - POWER TAKE-OFF
01.02	01	POWER TAKE-OFF, FRONT
01.03	01	POWER TAKE-OFF, REAR
01.03A	01	POWER TAKE-OFF, REAR
01.04	01	POWER TAKE-OFF, REAR
01.04A	01	POWER TAKE-OFF, REAR
01.05	01	POWER TAKE-OFF, REAR
01.05A	01	POWER TAKE-OFF, REAR
01.06	01	POWER TAKE-OFF, REAR
01.06A	01	POWER TAKE-OFF, REAR
01.07	01	POWER TAKE-OFF, REAR
01.07A	01	POWER TAKE-OFF, REAR
01.08	01	POWER TAKE-OFF, REAR
01.08A	01	POWER TAKE-OFF, REAR
01.10	01	FLYWHEEL, SLIP CLUTCH
01.11	01	FLYWHEEL
01.12	01	FLYWHEEL BRAKE
03.00	01	SECTION LIST 3 - MAIN GEARBOX
03.01	01	MAIN GEARBOX
03.02	01	MAIN GEARBOX
03.03	01	MAIN GEARBOX
03.04	01	MAIN GEARBOX
03.05	01	MAIN GEARBOX
03.06	01	MAIN GEARBOX
03.07	01	MAIN GEARBOX
03.08	01	MAIN GEARBOX
03.09	01	MAIN GEARBOX
03.10	01	MAIN GEARBOX
03.11	01	PLUNGER, LOAD MEASUREMENT
05.00	01	SECTION LIST 5 - AXLE

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05.01	01	SINGLE AXLE WITHOUT BRAKES
05.02	01	SINGLE AXLE WITHOUT BRAKES
05.03	01	SINGLE AXLE WITH BRAKES
05.04	01	SINGLE AXLE WITH BRAKES
05.05	01	SINGLE AXLE WITH BRAKES
05.06	01	TANDEM AXLE - SUSPENSION AND TUBE
05.07	01	TANDEM AXLE WITHOUT BRAKES
05.08	01	TANDEM AXLE WITH BRAKES
05.09	01	TANDEM AUTO-STEER AXLE WTHOUT BRAKES
05.10	01	TANDEM AUTO-STEER AXLE WITHOUT BRAKES, WHEEL BEARING
05.11	01	TANDEM AUTO-STEER AXLE WITH BRAKES, FRONT AXLE
05.12	01	TANDEM AUTO-STEER AXLE WITH BRAKES, REAR AXLE
05.13	01	TANDEM AUTO-STEER AXLE, BRAKES
05.14	01	AXLE, FIXING PARTS
05.15	01	PNEUMATIC BRAKES, BRAKE VALVE
05.16	01	PNEUMATIC BRAKES, AIR RESERVOIR
05.17	01	PNEUMATIC BRAKES, SINGLE AXLE
05.18	01	PNEUMATIC BRAKES - TANDEM AXLE
05.19	01	PARKING BRAKES - SINGLE AXLE
05.20	01	PARKING BRAKES - TANDEM AXLE
06.00	01	SECTION LIST 6 - ELECTRICAL SYSTEM
06.01	01	ELECTRIC WIRING
06.01A	01	CONTROL BOX
06.02	01	ROAD LIGHTS
06.03	01	REVOLVING FLASH LIGHT
06.04	01	SIDE LIGHTS, DENMARK
06.05	01	WORK LIGHTS
06.05A	01	ADDITIONAL WORK LIGHTS - FOR NA ONLY
06.06	01	MONITOR
06.07	01	CONNECTORS
06.51	01	CONNECTORS, POWER & CAN CABLE ON TRACTOR
06.52	01	CONNECTORS, X3 WIRING LOOM
06.53	01	CONNECTORS, X3 WIRING LOOM
06.54	01	CONNECTORS, X4 WIRING LOOM
06.56	01	CONNECTORS, 2 PIN
06.57	01	CONNECTORS, 3 PIN: X116
06.58	01	CONNECTORS, 4 PIN: X130
06.59	01	CONNECTORS, 6 PIN: X200
06.60	01	CONNECTORS: X1
06.61	01	CONNECTORS: X2
06.62	01	CONNECTORS: X201
06.63	01	CONNECTORS: X3 - X4
06.64	01	CONNECTORS, TRACTOR BATTERY HOOK-UP
06.65	01	CONNECTORS: E2
06.66	01	CONNECTORS: E3
06.67	01	CONNECTORS: Y2 - Y3
06.68	01	CONNECTORS: X127 - X128 - X129
06.69	01	CONNECTORS: X203 - X204 - X205
06.70	01	CONNECTORS: X101
06.71	01	CONNECTORS: X206
07.00	01	SECTION LIST 7 - HYDRAULIC SYSTEMS

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07.01	01	HYDRAULIC BRAKES, SINGLE AXLE, NOT FOR NA
07.02	01	HYDRAULIC BRAKES, TANDEM AXLE, NOT FOR NA
07.03	01	EMERGENCY BRAKE SYSTEM, FRANCE
07.04	01	PICK-UP LIFTING SYSTEM
07.05	01	PICK-UP LIFTING SYSTEM
07.06	01	HYDRAULICS KNIVES CROPCUTTER
07.07	01	HYDRAULICS KNIVES CROPCUTTER
07.08	01	DENSITY PRESSER SYSTEM, FRONT
07.09	01	DENSITY PRESSER SYSTEM, REAR, WITH BALE EJECT SYSTEM
07.09A	01	DENSITY PRESSER SYSTEM, REAR, SPECIFIC WITHOUT BALE EJECT SYSTEM
07.09B	01	DENSITY CYLINDER
07.10	01	BALE EJECT CONTROLE AND BALE CHUTE
07.11	01	BALE EJECTOR
07.12	01	TANDEM AUTO-STEER AXLE
07.13	01	TUBE CLAMPS AND HYDRAULIC TUBES
08.000	01	SECTION LIST 8 - SHEET METAL/DECALS
08.001	01	PROTECTIONS FLYWHEEL
08.002	01	PICK-UP PROTECTION
08.003	01	PICK-UP PROTECTION
08.004	01	KNOTTER SHIELDS
08.005	01	PROTECTIONS, LH
08.006	01	PROTECTIONS, RH
08.007	01	TWINE BOX, RH
08.007A	01	TWINE BOX, RH
08.008	01	TWINE BOX, LH
08.008A	01	TWINE BOX, LH
08.009	01	LOWER SHIELDS, SINGLE AXLE, LH
08.010	01	LOWER SHIELDS, SINGLE AXLE, RH
08.011	01	LOWER SHIELDS, TANDEM AXLE, LH
08.012	01	LOWER SHIELDS, TANDEM AXLE, RH
08.013	01	LADDER AND HAND-RAIL FOR MAINTENANCE
08.013A	01	LADDER AND HAND-RAIL FOR MAINTENANCE
08.014	01	STORAGEBOXES
08.015	01	EASY SHIELDING UNLOCK - FOR NA ONLY
08.101	01	DECALS
08.102	01	DECALS
08.103	01	DECALS, NA
09.00	01	SECTION LIST 9 - LUBRICATION
09.01	01	GREASING
09.02	01	AUTOMATIC OILING
09.03	01	KIT, LUBRICATION
11.00	01	SECTION LIST 11 - WHEELS
11.01	01	WHEELS
12.00	01	SECTION LIST 12 - MAIN FRAME
12.01	01	MAIN FRAME
12.02	01	JACK AND HITCH
12.03	01	JACK AND HITCH
12.04	01	JACK
13.00	01	SECTION LIST 13 - FEEDER
13.01	01	PICK-UP, MAIN TRANSMISSION, RH
13.01A	01	PICK-UP, MAIN TRANSMISSION , RH - CLUTCH

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >

FEED CHAMBER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1	1	84818755		1	FRAME
1	2	84818759		1	FRAME
2	3	84607485		AR	PLATE
3	3	84607490		AR	PLATE
4		84607487		2	PLATE
5		84607491		2	PLATE
6		84042608		1	PLATE, COVER RH
7		84042607		1	PLATE, COVER LH
8		86508583		4	SCREW M16x35
9		80338949		AR	SCREW Short Neck, CL 8.8, M10 x 1.5 x 25
10		80140045		AR	WASHER, LOCK Belleville, M10
11		80100016		AR	NUT M10
12		80385922		4	SCREW M16x45
13		86000441		4	NUT M16
14		80333115		2	BOLT
15		84042709		1	PLATE, COVER
16		84042710		1	PLATE, COVER
17		89706704		1	SCREW M10x35
18		80140048		12	WASHER, LOCK 16MM
19		80100020		16	NUT M16
20		89839186		1	HANDLE
21	2	84042720		1	SHAFT
21	1	84074005		1	SHAFT
22		84043925		1	ROD
23		80376291		3	RING
24		80854963		1	SPACER
25		80140042		1	WASHER 10MM
26		80100037		1	NUT M10
27		84042706		1	PLATE, COVER
28		80120046		2	BOLT M16x60
29		80412185		2	BOLT M16x50
30		80333969		2	SPRING

(1) FOR LBX332R ONLY
(2) FOR LBX422R, LBX432R ONLY
(3) QTY = 3 FOR LBX332, QTY = 5 FOR LBX422 AND LBX432

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >

PLUNGER, RODS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1	1	84074870		2	HOUSING, BEARING
1	2	84074868		2	HOUSING, BEARING
2	1	80370026		4	CIRCLIP
2	2	80412270		4	RING, SNAP
3	1	84000584		4	WASHER, THRUST
3	2	89838119		4	WASHER, THRUST
4	1	84004409		4	GASKET
4	2	89838315		4	GASKET
5		84045245		2	RING
6	1	84004413		4	SCREW M14x70
6	2	89838120		4	SCREW M16x70
7		80120079		4	BOLT M12x40
8	1	84000586		1	CROSSRAIL
8	2	89838114		1	ANGLE BAR
9	1	84045246		2	SHAFT
9	2	84045247		2	SHAFT
10	1	89516384		2	BEARING ASSY
10	2	89838113		2	BEARING ASSY
11	1	84000588		2	LINK CONROD
11	2	89838110		2	LINK CONROD
12	1	84000581		AR	PLATE, ADJUSTING
12	2	89838109		AR	PLATE, ADJUSTING
13	1	100019		4	NUT M14
13	2	9505933		4	NUT M16
14	1	84011662		8	WASHER 14MM
14	2	80394631		8	WASHER 17MM
15	1	440419		4	SCREW M14x55
15	2	80412398		4	SCREW M16x50
16		84045248		2	PLATE, LOCKING

(1) FOR LBX332S, LBX332P, LBX332R ONLY
(2) FOR LBX422S, LBX422R, LBX432S, LBX432R ONLY

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >

KNOTTER FANS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		84429995		AR	FAN (25, 26)
2		80140182		4	WASHER
3	1	84400011		1	SUPPORT
3	2	84400009		1	SUPPORT
3	3	84429805		1	SUPPORT
4		80362786		AR	TAB, LOCKING
5		80445394		5	RIVET
6		80362785		4	WASHER
7		84058832		1	CLIP
8		89839372		AR	CLAMP
9		89824326		AR	WASHER 5MM
10		80323597		AR	STRAP
11	1, 2	84053243		1	PLATE RH
11	3	84400168		1	PLATE
12	1, 2	84078904		1	PLATE LH
12	3	84400166		1	PLATE
13		80043127		AR	SCREW M8x25
14	1	84072857		1	HARNESS, WIRE
14	2, 3	84072855		1	HARNESS, WIRE
15		80120100		2	SCREW M6x20
16	1	84053328		1	PLATE
16	2, 3	84053242		1	PLATE
17		84400036		2	BRACKET
18		86512439		AR	SCREW
19		80322358		AR	WASHER, LOCK 8MM
20		89706690		AR	NUT M8
21		80322357		16	WASHER, LOCK 6MM
22		89706755		14	NUT M6
23		80401266		AR	STRIP-GASKET L=0.910M
24	2, 3	80401278		AR	SEAL L=2.550M
24	4	80401278		AR	SEAL L=2.166M

(1) FOR LBX332S, LBX332P, LBX332R ONLY, 2 HOLES
(2) FOR LBX432S, LBX432R ONLY, 3 HOLES
(3) FOR LBX422S, LBX422R ONLY, 3 HOLES
(4) FOR LBX332S, LBX332P, LBX332R ONLY, 2 HOLES

LBX332P LBX332R
LBX332S LBX422R
LBX422S LBX432R

MidWestTech | Case LBX332S, LBX332P, LBX332R, LBX422S, LBX422R, LBX432S, LBX4... Order the manual at mid-west-tech.com >