1818
Uni-Loader

Parts Catalog

8-7274

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner
- Engine 2-5
- Remote - gasoline models 2-57

Alarm - backup 4-31

Alternator - diesel models
- Assembly 4-5
- Mounting 4-3

Auxiliary Hydraulic Circuit 8-23

Axles 6-17,6-19

B

Backup Alarm 4-31

Battery and Cables
- Diesel Models 4-23
- Gasoline Models 4-25

Battery Box 9-3

Bearings - main, diesel engine 2-21

Belt
- Fan - Diesel Models 2-33
- Pump Drive 6-21,6-23
- Seat 9-17

Block - cylinder
- Diesel Models 2-13
- Gasoline Models 2-39,2-41

Block Heater - diesel models 2-13

Blower Housing - gasoline engine 2-61

Brake - parking latch 7-3,7-5

Bucket and Teeth 9-7

C

Cables
- Battery
  - Diesel Models 4-23
  - Gasoline Models 4-25
- Choke - gasoline models 3-5
- Fuel Shutoff - diesel models 3-5
- Throttle 3-5

Camshaft - engine
- Diesel Models 2-27
- Gasoline Models 2-45

Canopy - ROPS 9-19

Carburetor - gasoline models 3-25

Chains - drive, axles 6-17,6-19

Chassis and Covers 9-3

Choke Control - gasoline models 3-27

Cold Start Aid 4-33

Connecting Rods - engine
- Diesel Models 2-25
- Gasoline Models 2-47

Controls
- Auxiliary Hydraulic 8-23
- Brake - parking latch 7-3,7-5

C

Controls-Cont.
- Engine
  - Choke - gasoline models 3-5,3-27
  - Drive Belt Tension 6-25
  - Fuel Shutoff - diesel models 3-5
  - Governor - diesel models 3-13
  - Governor - gasoline models 3-29
  - Speed - diesel models 3-11
  - Stop Lever - diesel models 3-9
  - Throttle Cables 3-5
- Forward and Reverse 6-29,6-31
- Loader Lift and Tilt 6-7

Cooler - oil, hydraulic 8-7

Counterweight 9-13

Covers - chassis 9-3

Crankcase - cylinder block
- Diesel Models 2-13
- Gasoline Models 2-39,2-41

Crankshaft
- Diesel Models 2-25
- Gasoline Models 2-43

Cylinder Block
- Diesel Models 2-13
- Gasoline Models 2-39,2-41

Cylinder Head - Diesel Models 2-17

Cylinders
- Bucket Tilt 8-29,8-31
- ROPS Release 9-19
- Loader Lift 8-25,8-27

D

Decals 9-21

Dipstick
- Hydraulic Reservoir 9-3
- Oil - engine
  - Diesel Models 2-15
  - Gasoline Models 2-49

Direction Controls and Linkage 6-29,6-31

Door - rear
- Diesel Models 9-11
- Gasoline Models 9-13

Drive Chains 6-17,6-19

Drive Motor - hydrostatic 6-13

E

Electrical System
- Tractor ..... 4-15 - 4-33

Engine Components - diesel models
- Bearings - main 2-21
- Belt - fan 2-33
- Block Heater 2-13
- Camshaft 2-27

MidWestTech | Case 1818 Uni Loader Parts Catalog | Publication 8-7242 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

E

Engine Components - diesel models-Cont.
- Connecting Rod 2-25
- Crankshaft 2-25
- Cylinder Block 2-13
- Cylinder Head 2-17
- Cylinder Head Cover 2-23
- Dipstick 2-15
- Engine Speed Control 3-11
- Engine Stop Lever 3-9
- Fan 2-33
- Flywheel 2-37
- Front Gear Cover 2-19
- Fuel Filter 3-21
- Fuel Injection System 3-7
- Glow Plug 3-7
- Governor Control 3-13
- Idler Gear 2-27
- Injection Pump - Fuel 3-19
- Injection Pump Drive 3-15
- Manifold - intake and exhaust 2-35
- Nozzle Assembly 3-17
- Oil Pan 2-15
- Pan - oil 2-15
- Pistons 2-25
- Pump - oil 2-13
- Relief Valve - front gear cover 2-19
- Rocker Arm 2-29
- Starter Assembly 4-7
- Thermostat, Housing, and Tubes 2-31
- Valve - relief, front gear cover 2-19
- Valve Mechanism 2-29
- Water Pump 2-33

Engine Components - gasoline models
- Air Cleaner - remote 2-57
- Air Intake System 2-55
- Blower Housing 2-61
- Camshaft 2-45
- Carburetor 3-25
- Choke Control 3-27
- Connecting Rod 2-47
- Crankshaft 2-43
- Cylinder Block 2-39,2-41
- Dipstick 2-49
- Exhaust System 2-57
- Filter - oil 2-63
- Filter - oil, remote 2-53
- Front Gear Cover 2-51
- Flywheel 2-43
- Fuel Pump 3-23
- Governor Linkage 3-29
- Manifolds - exhaust 2-59
- Oil Filter 2-63

E

Engine Components - gasoline models-Cont.
- Oil Filter - remote 2-53
- Oil Pan 2-49
- Oil Pump 2-49
- Pan - oil 2-49
- Piston 2-47
- Pump - oil 2-49
- Remote Oil Filter 2-53

Engine Mounting 2-9

Equipment Pump - hydraulic
- Diesel Models 8-3
- Gasoline Models 8-5

Exhaust System 2-7,2-59

Eye - lift, tractor 9-19

F

Fan - Diesel Models 2-33

Filter
- Air Cleaner 2-5
- Fuel - Diesel Models 3-21
- Hydraulic Oil 8-11,8-11B
- Oil - engine, gasoline models 2-53,2-63

Floor Plate 9-3

Flywheel
- Diesel Models 2-37
- Gasoline Models 2-43

Fork - pallet 9-9

Forward Controls 6-29,6-31

Frame
- Loader Lift 9-5
- Main 9-3
- Operators Compartment - fenders 9-19
- ROPS 9-19

Fuel
- Cap - tank 9-3
- Filter - Diesel Models 3-21
- Injection Nozzle - diesel models 3-17
- Injection Pump - diesel models 3-19
- Injection Pump Drive - diesel models 3-15
- Injection System - diesel models 3-7
- Lines to Engine 3-3
- Pump - Gasoline Models 3-23
- Sender
  - Diesel Models 4-19
  - Gasoline Models 4-21

G

Gauges - instruments 4-15,4-17

Glow Plug - diesel models 3-7

Governor - engine
- Diesel Models 3-13
- Gasoline Models 3-29

MidWestTech | Case 1818 Uni Loader Parts Catalog | Publication 8-7242 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

G

Guard - ROPS 9-19

H

Harness - wiring
Backup Alarm 4-31
Front
Diesel Models 4-15
Gasoline Models 4-17
Horn 4-29
Lamp 4-27
Rear
Diesel Models 4-19
Gasoline Models 4-21
Heater - cylinder block, diesel engine 2-13
Horn 4-29
Hoses - see Hydraulic Circuits or Fuel Lines
Hydraulic Circuits
Auxiliary Equipment 8-23
Hydrostatic Drive
Supply and Return Lines
Diesel Models 8-7
Gasoline Models 8-9,8-9B,8-9D
Variable Displacement Pumps to Oil Filter 8-11,8-11B
Variable Displacement Pumps to Hydrostatic Motors 6-15
Loader Bucket Tilt 8-5
Loader Lift 8-3

I

Ignition Switch
Diesel Models 4-15
Gasoline Models 4-17
Ignition System - gasoline models 4-9
Index - numerical 10-2
Injection Pump - fuel, diesel models 3-19
Injection Pump Drive - diesel models 3-15
Injection System - fuel, diesel models 3-7
Instrument - electrical
Diesel Models 4-15
Gasoline Models 4-17

L

Lamps and Wiring 4-27
Latch - parking 7-3,7-5
Levers - see Controls
Lift Eyes - tractor 9-19
Loader Bucket 9-7
Loader Control Valve 8-13
Loader Controls 8-33
Loader Hydraulics
Lift 8-19

L

Loader Hydraulics-Cont.
Tilt 8-21
Loader Lift Frame 9-5

M

Manifold - intake and exhaust
Diesel Engine 2-35
Gasoline Engine 2-59
Motor
Hydrostatic Drive 6-13
Starter Assembly
Diesel 4-7
Gasoline 4-11
Mounting
Air Cleaner 2-5
Alternator - diesel models 4-3
Auxiliary Control Valve 8-23
Engine 2-9
Equipment Pump - hydraulic 6-3
Loader Control Valve 8-13
Motor - hydrostatic drive 6-13
Muffler 2-7
Radiator 2-3
Seat 9-17
Starter
Diesel Models 2-37
Gasoline Models 4-11
Valve
Auxiliary Hydraulic 8-15
Loader Control 8-19
Variable Displacement Pump 6-3
Muffler 2-7

N

Nozzle Assembly - fuel injection, diesel models 3-17
Numerical Index 10-2

O

Oil Cooler - hydraulic 8-7
Oil Filter - engine
Diesel Models 2-15
Gasoline Models 2-63
Oil Filter - hydraulic 8-11,8-11B
Oil Pan
Diesel Models 2-15
Gasoline Models 2-49
Oil Pump - engine
Diesel Models 2-13
Gasoline Models 2-49
Operator Restraint 7-3

MidWestTech | Case 1818 Uni Loader Parts Catalog | Publication 8-7242 Order the manual at mid-west-tech.com >