NEW HOLLAND

TRACTOR LOADER

U80

PARTS CATALOG

87359018 NA

Issued 02-2006

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland U80 Tractor Loader Parts Catalog | Publication 87359018

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	RADIATOR - MOUNTING (MODELS WITHOUT AIR CONDITIONING)
02 -01A	RADIATOR - MOUNTING (MODELS WITH AIR CONDITIONING)
02 -02	RADIATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
02 -02A	RADIATOR ASSY (MODELS WITH AIR CONDITIONING)
02 -03	AIR CLEANER - AIR INTAKE PARTS
02 -04	MUFFLER - EXHAUST SYSTEM (WITH TURBOCHARGER)
02 -05	MUFFLER - EXHAUST SYSTEM (WITHOUT TURBOCHARGER)
02 -06	COLD START SYSTEM
02 -07	ENGINE - MOUNTING
02 -08	WATER PUMP SYSTEM
02 -09	FRONT GEAR COVER
02 -10	MANIFOLDS
02 -11	TURBOCHARGER SYSTEM
02 -12	TURBOCHARGER ASSY
02 -13	OIL FILTER AND COOLER
02 -14	OIL PUMP AND OIL PAN
02 -15	CYLINDER HEAD COVERS
02 -16	CYLINDER HEAD AND VALVE MECHANISM - 4-390
02 -17	CYLINDER HEAD AND VALVE MECHANISM - 4T-390
02 -18	CAMSHAFT
02 -19	CYLINDER BLOCK (WITH TURBOCHARGER)
02 -19A	CYLINDER BLOCK (WITHOUT TURBOCHARGER)
02 -20	CRANKSHAFT
02 -21	FLYWHEEL AND HOUSING
02 -22	PISTONS AND CONNECTING RODS (WITH TURBOCHARGER)
02 -22A	PISTONS AND CONNECTING RODS (WITHOUT TURBOCHARGER)
02 -23	GASKET KIT, VALVE GRIND
02 -24	GASKET KIT, CYLINDER BLOCK
02 -25	GASKET KIT, BASIC SERVICE ENGINE
03 -01	FUEL LINES, RESERVOIR - FILTER, IN-LINE FUEL
03 -02	CONTROLS - THROTTLE, HAND
03 -03	CONTROLS - THROTTLE, FOOT
03 -04	FUEL INJECTION SYSTEM
03 -05	FUEL FILTER
03 -06	FUEL INJECTION PUMP AND DRIVE
03 -07	FUEL INJECTION NOZZLE
04 -01	STARTER
04 -02	ALTERNATOR
04 -03	STARTER MOUNTING - ALTERNATOR MOUNTING
04 -04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04 -05	BATTERY - CABLES AND CUTOFF SWITCH
04 -06	BATTERY, DUAL - COLD START
04 -07	HARNESS, FRONT CONSOLE - SWITCHES
04 -08	HARNESS, SIDE CONSOLE - MOUNTING AND CONNECTIONS
04 -09	HARNESS, SIDE CONSOLE - SWITCHES
04 -10	INSTRUMENT PANEL, FRONT - COVERS
04 -11	INSTRUMENT PANEL, SIDE - SWITCHES AND COVERS
04 -12	INSTRUMENT CLUSTER
04 -13	ELECTRICAL - LAMPS, ROPS CANOPY
04 -13A	ELECTRICAL - LAMPS, ROPS CAB
04 -13B	LAMP ASSY - CAB MODELS
04 -14	HORN - ALARM, BACKUP

MidWestTech | New Holland U80 Tractor Loader Parts Catalog | Publication 87359018 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -15	BEACON, ROTATING
05 -01	STEERING WHEEL - COLUMN
05 -02	HYDRAULICS - STEERING (MODELS WITHOUT HUSCO LOADER VALVE)
05 -02A	HYDRAULICS - STEERING (MODELS WITH HUSCO LOADER VALVE)
05 -03	STEERING COLUMN
05 -04	CYLINDER ASSY - STEERING
05 -05	AXLE, FRONT - SPINDLES
05 -06	HUB AND BEARINGS, FRONT WHEEL
05 -07	AXLE - MOUNTING
05 -08	AXLE, FRONT - HOUSING
05 -09	AXLE, FRONT - HOUSING, SWIVEL
05 -10	AXLE, FRONT - CYLINDER, STEERING
05 -11	AXLE, FRONT - HUB AND BEARINGS
05 -12	WHEELS, FRONT - TIRES
06 -01	AXLE, FRONT DRIVE - MOUNTING
06 -02	AXLE, FRONT DRIVE - HOUSING
06 -03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06 -04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06 -05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06 -06	AXLE, FRONT DRIVE - PLANETARY
06 -07	AXLE, FRONT DRIVE - DIFFERENTIAL
06 -08	AXLE, FRONT DRIVE - RING AND PINION
06 -09	DRIVE SHAFT, FRONT AXLE
06 -10	COOLING SYSTEM - TRANSMISSION (MODELS WITHOUT AIR CONDITIONING)
06 -10A	COOLING SYSTEM - TRANSMISSION (MODELS WITH AIR CONDITIONING)
06 -11	TRANSMISSION - MOUNTING
06 -12	TRANSMISSION ASSY - FILTER, OIL
06 -13	TRANSMISSION ASSY (2WD) - HOUSING
06 -14	TRANSMISSION ASSY (4WD) - HOUSING
06 -15	TRANSMISSION ASSY - PUMP, OIL
06 -16	TRANSMISSION ASSY - SHIFTER MECHANISM
06 -17	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06 -18	TRANSMISSION ASSY - SHAFT, INPUT
06 -19	TRANSMISSION ASSY - SHAFT, SECONDARY
06 -20	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06 -21	TRANSMISSION ASSY (329081A3 OR 329082A3) - VALVE, CONTROL
06 -21A	TRANSMISSION ASSY (87456845 OR 87456846) - VALVE, CONTROL
06 -22	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID
06 -23	WHEELS, REAR - TIRES
06 -24	AXLE, REAR DRIVE - MOUNTING
06 -25	AXLE, REAR - DIFFERENTIAL LOCK
06 -26	AXLE, REAR DRIVE - HOUSING
06 -27	AXLE, REAR DRIVE - DIFFERENTIAL (86981746 AXLE/ 2 SPIDER DIFFERENTIAL)
06 -27A	AXLE, REAR DRIVE - DIFFERENTIAL (87447233 AXLE/ 4 SPIDER DIFFERENTIAL)
06 -28	AXLE, REAR DRIVE - RING AND PINION
06 -29	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06 -30	AXLE, REAR DRIVE - PLANETARY
06 -31	DRIVE SHAFT, REAR AXLE
07 -01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07 -02	AXLE, REAR DRIVE - BRAKE, PARKING
07 -03	BRAKE - PEDALS
07 -04	HYDRAULICS - BRAKE MASTER CYLINDER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07 -05	CYLINDER ASSY - BRAKE MASTER
07 -06	CONTROLS - BRAKE, PARKING
08 -01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE (MODELS WITHOUT HUSCO LOADER VALVE)
08 -01A	HYDRAULICS - PUMP, FILTER AND LOADER VALVE (WITH HUSCO LOADER VALVE W/SEPARATE PRIORITY VALVE)
08 -01B	HYDRAULICS - PUMP, FILTER AND LOADER VALVE (WITH HUSCO LOADER VALVE W/BUILT-IN PRIORITY VALVE)
08 -02	HYDRAULICS - COOLER, RETURN LINES AND FILTER
08 -03	HYDRAULICS - CYLINDER, LOADER LIFT
08 -04	HYDRAULICS - CYLINDER, LOADER BUCKET
08 -05	HYDRAULICS - CYLINDER, LOADER CLAM
08 -06	HYDRAULICS - CYLINDER, LOADER CLAM
08 -07	HYDRAULICS - GLIDE RIDE CONTROL
08 -07A	HYDRAULICS - RIDE CONTROL (87433240 SOLENOID VALVE)(MODELS WITH HUSCO LOADER VALVE)
08 -08	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08 -08A	HYDRAULICS - COUPLER, LOADER TOOL QUICK (MODELS WITH HUSCO LOADER VALVE)
08 -09	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08 -09A	VALVE, COUPLER (87435909) - LOADER TOOL
08 -10	HYDRAULICS - HITCH, THREE POINT
08 -11	HYDRAULICS - HITCH LOCK VALVE, THREE POINT
08 -12	HYDRAULICS - VALVE, LASER CONTROL
08 -13	PUMP, EQUIPMENT HYDRAULIC
08 -14	VALVE ASSY - LOADER CONTROL, TWO SPOOL
08 -15	VALVE ASSY - LOADER CONTROL, THREE SPOOL
08 -16	VALVE SECTION - INLET
08 -17	VALVE SECTION - LOADER BUCKET
08 -18	VALVE SECTION - LOADER LIFT
08 -19	VALVE SECTION - OUTLET
08 -20	VALVE SECTION - LOADER CLAM
08 -21	VALVE ASSY - RELIEF, CIRCUIT
08 -21A	VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - USED WITH SEPARATE PRIORITY VALVE)
08 -21B	VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - USED WITH SEPARATE PRIORITY VALVE)
08 -21C	VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE)
08 -21D	VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE)
08 -22	VALVE ASSY - HITCH, THREE POINT
08 -23	VALVE ASSY - HITCH, THREE POINT
08 -24	VALVE SECTION - HITCH INLET
08 -25	VALVE SECTION - HITCH LIFT
08 -26	VALVE SECTION - HITCH LIFT
08 -27	VALVE SECTION - HITCH PITCH, TILT AND IMPLEMENT
08 -28	VALVE, FLOW CONTROL - HITCH, THREE POINT
08 -29	VALVE, LOCK - HITCH, THREE POINT
08 -30	ACCUMULATOR ASSY - RIDE CONTROL
08 -31	FILTER ASSY, OIL
08 -32	CYLINDER ASSY - LOADER LIFT

Order the manual at mid-west-tech.com >

CYLINDER ASSY - LOADER LIFT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1	1	87384876		2	CYLINDER, LIFT Loader Lift, 82.6 ID x 766 mm strk, Gray; Incl. Ref 2- 20
2		384241A1		1	SLEEVE, HYD' CYL' Tube Without Bushings; Unpainted
		NSS		1	NOT SERVICED SEPARATELY Gland, Cylinder, Incl. Ref 4 - 10
4		1980321C3		1	GLAND
5		D95143		1	SEAL
6		G102425		1	BUSHING, LARGE
		1542875C1		1	SET OF PARTS Incl. Ref 7, 8, Not Serviced Separately, Order 86982375 Seal Kit
7		1542999C1		1	SEAL Rod Seal, Not Serviced Separately, Order 86982375 Seal Kit
8		1542998C1		1	SEAL Buffer Seal, Not Serviced Separately, Order 86982375 Seal Kit
9		86509814		1	O-RING 2-7/8 ID x 1/8 in
10		G32122		1	RING
11		86642312		1	SCREW No. 8 x 3/8
12		133083A1		1	ROD, PISTON 44 mm (1-3/4 in) dia Rod; Unpainted
13		135161A1		1	PISTON
14		G102287		1	SEAL
15		S109444		1	RING
16		S109445		1	RING
17		25974R1		1	BOLT 1 NF x 2-1/2; 8; No Longer Used, Order 86982437 Bolt With Washer
18		G32303		1	WASHER No Longer Used, Order 86982437 Bolt With Washer
19		80710		2	NIPPLE, LUBE 1/8 PT x 21/32
20		86982437		1	BOLT, SPECIAL With Washer, 1 x 2-1/2
		86982375		1	KIT, SEALS Seal, Incl. Ref 5 - 10, 14 - 16

(1) The cylinder assembly part number is stamped on some cylinder glands or tubes.

MidWestTech | New Holland U80 Tractor Loader Parts Catalog | Publication 87359018 Order the manual at mid-west-tech.com >

FRAME - LOADER LIFT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					LIFT CYLINDER, SUPPORT STRUT, RETURN-TO-DIG AND ANTIROLLBACK
1		86981847		1	ARM Incl. Ref 2 - 4
2		D127542		4	BUSHING
3		100696A1		4	BUSHING, LARGE Bucket Cylinder Link Pivot, No Longer Included With Frame, Purchase Separately
4		109268A1		4	BUSHING
5		111522A1		1	PIN
6		387019A1		2	PIN
7		86625259		6	WASHER 2-1/16 x 3 x 3/32
7B		181842A1		X	WASHER
8		86625154		6	RING, SNAP No. 50
9		87384876		2	CYLINDER, LIFT Loader Lift Cylinder, 82.6 ID x 766 mm strk, Gray, See Figure 08-32
10		80719		2	NIPPLE, LUBE 90 deg, 1/8 PT x 27/32
11		128818A1		1	SUPPORT Return-To-Dig
12		142524A1		1	PROTECTOR
13		86508568		2	SCREW M6 x 16
14		86642316		1	CLAMP 7,9 mm
15		86625073		2	CLIP M6
16		D137363		1	SWITCH Return-To-Dig
17		280859		2	NUT No. 6
18		281045		2	SCREW
19		128312A1		2	BOLT M10 x 15
20		86624176		6	WASHER 11 x 21 x 2 mm
23		104824A1		1	PIN, LARGE
24		118900A1		1	PIN, LARGE
25		113629A1		1	PIN, LARGE
26		86625153		4	RING, SNAP
27		86981784		1	ROD Antirollback
28		192815A1		1	PIN
30		118901A1		2	PIN, LARGE
31		86625153		4	RING, SNAP
32		80710		2	NIPPLE, LUBE 1/8 PT x 21/32
33		86625114		1	PIN, LARGE 3/8 x 7/8
34		280250		1	PIN, SPLIT (COTTER) 3/32" x 3/4"
35		87364		1	WASHER 17/32 x 1-1/16 x 3/32

MidWestTech | New Holland U80 Tractor Loader Parts Catalog | Publication 87359018 Order the manual at mid-west-tech.com >

CHASSIS - MOUNTS, POD

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					CHASSIS
1		86981741		1	FRAMEWORK Incl. Ref 2, Used In Production, For Service Order 86982381, Chassis Kit, Which Includes Chassis and Decals; Models Without Husco Loader Valve
1		87326905		1	CHASSIS Replaces 87448253, 87307003; Incl. Ref 2; Models With Husco Loader Valve; Not Illustrated
2		180427A1		2	BUSHING
3		80719		2	NIPPLE, LUBE 90 deg, 1/8 PT x 27/32
					OPERATOR COMPARTMENT POD MOUNTS
4		86625071		4	NUT M10
5		86541970		1	BOLT M16 x 100; 10.9
6		86625247		1	WASHER 21/32 x 2 x 1/4
7		D138565		2	SHOCK ABSORBER
8		186977A1		1	WASHER 21/32 x 2-3/4 x 11/64
9		392530		1	NUT M16; 10
10		141249A1		2	SUPPORT
11		43260		4	BOLT M12 x 30; 10.9
12		86625255		4	WASHER 13,5 x 24 x 3 mm
13		86624983		2	BOLT M16 x 110; 10.9
14		86625247		2	WASHER 21/32 x 2 x 1/4
15		186977A1		4	WASHER 21/32 x 2-3/4 x 11/64
16		D138565		4	SHOCK ABSORBER Front
17		392530		2	NUT M16; 10
18		180578A1		2	SCREW M16 x 120
19		A141451		2	SHOCK ABSORBER Rubber, Rear
20		186977A1		2	WASHER 21/32 x 2-3/4 x 11/64
21		392530		2	NUT M16; 10
22		86625266		2	WASHER 17,5 x 30 x 4 mm

MidWestTech | New Holland U80 Tractor Loader Parts Catalog | Publication 87359018 Order the manual at mid-west-tech.com >