NEW HOLLAND

LOADER BACKHOE

B95TC

PARTS CATALOG

87360667 NA

Issued 02-2006

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland B95TC Loader Backhoe Parts Catalog | Publication 87360667

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

636A	04	ACCESSORY ENGINE- ALTERNATOR
636A	05	ACCESSORY ENGINE - BRACKET MUFFLER
636A	06	ACCESSORY ENGINE - STARTER
SEC. 02	00	FUEL TANK - MUFFLER - RADIATOR - AIR CLEANER - CHASSIS
1.14.0	01	FUEL TANK & RELATED PARTS
1.15.0	01	MUFFLER & EXTENSIONS
1.15.0	02	MUFFLER & EXTENSIONS
1.17.2	01	EXPANSION TANK
1.19.1	01	AIR CLEANER & HOSES
1.21.5/ 5	01	FRAME (CENTER PIVOT)
175	01	AIR INTAKE CAP & PRE-CLEANER
176	01	AIR INTAKE CAP & PRE-CLEANER
203	01	FRONT WEIGHTS
215	01	FRONT WEIGHTS
636	01	RADIATOR
636	02	RADIATOR
636/ 1	01	RADIATOR
636/ 2	02	RADIATOR
637/ 1	01	RADIATOR
637/ 2	01	RADIATOR
637/ 3	01	RADIATOR
SEC. 03	00	TRANSMISSION 1/2
SEC. 03	01	TRANSMISSION 2/2
1.28.0/ A	01	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	02	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	03	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	04	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	05	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	06	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	07	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ B	01	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	02	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	03	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	04	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	05	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	06	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	07	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	08	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.6	01	GEAR FILTER PIPES (POWER-SHUTTLE)
1.29.1	01	TRANSMISSION ESTERNALSHIFTING CONTROLS (POWER-SHUTTLE)
1.38.1	01	FRONT & REAR DRIVESHAFT (POWER-SHUTTLE)
1.39.8	01	TRANSMISSION OIL COOLING PIPES (POWER-SHUTTLE)
SEC. 04	00	FRONT AXLE
1.40.0	01	FRONT AXLE (2WD)
1.40.0	02	FRONT AXLE (2WD)
402	01	4WD FRONT AXLE, HOUSING, BUSHINGS & SUPPORTS
402	02	4WD FRONT AXLE, SWIVEL HOUSING & STEERING CYLINDER
402	03	4WD FRONT AXLE, HUBS
402	04	4WD FRONT AXLE, RING GEAR & PINION ASSEMBLY
402	05	4WD FRONT AXLE, DIFFERENTIAL
402	06	4WD FRONT AXLE, DRIVE SHAFT
415	01	FRONT AXLE - (4WD) W/GEAR,BEVEL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

415	02	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	03	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	04	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	05	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	06	FRONT AXLE - (4WD) W/GEAR,BEVEL
SEC. 05	00	REAR AXLE
1.44.0E	01	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
1.44.0E	02	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
1.44.0E	03	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
1.44.0E	04	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
SEC. 06	00	ELECTRICAL
1.75.2/ 3	01	CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	03	ENGINE HARNESS (POWER SHUTTLE)
131	01	SINGLE BATTERY
321	01	DOUBLE BATTERY
995	01	COLD START
995	02	COLD START
SEC. 07	00	SLIDES VALVES
1.82.0	01	HYDRAULIC OIL RESERVOIR
1.82.3	01	HYDRAULIC PUMP (35+35-154L/MM)
1.82.3/ 1	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.3/ 2	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.6	01A	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	01B	FRONT HYDRAULIC PUMP INTAKE & OUTLET HOSES (CENTER PIVOT)
1.82.6	02A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	02B	REAR HYDRAULIC PUMP STABILIZER, LOADER & BACKHOE VALVE HOSES (CENTER PIVOT)
1.82.6	03A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	03B	QUICK RELEASE COUPLERS & HOSES (CENTER PIVOT)
1.82.6	04A	RETURN MANIFOLD HOSES (CENTER PIVOT)
1.82.6	04B	RETURN MANIFOLD HOSES (CENTER PIVOT)
1.82.6	05F	OIL COOLER & FILTER HOSES (CENTER PIVOT)
1.82.6	05G	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	06A	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	06B	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	07	HYDRAULIC SYSTEM PIPING
1.82.6	08A	LOADER LIFT CYLINDER HOSES (CENTER PIVOT)
1.82.6	08C	LOADER LIFT CYLINDER HOSES (CENTER PIVOT)
1.82.6	09A	LOADER BUCKET CYLINDER HOSES (CENTER PIVOT)
1.82.6	09B	LOADER BUCKET CYLINDER HOSES (CENTER PIVOT)
1.82.6	10A	HYDRAULIC SYSTEM PIPING NA (CENTER PIVOT)
1.82.6	11A	BACKHOE CONTROL VALVE HOSES (CENTER PIVOT)
1.82.6	11B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	12B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	13A	ROTATION PLATE HOSE CLAMPS (CENTER PIVOT)
1.82.6	16	BACKHOE CONTROL VALVE(CENTER PIVOT)
1.82.6	17	DIPPER VALVE SECTION (CENTER PIVOT)
1.82.6	18	BUCKET, SWING, & BOOM VALVE SECTION (CENTER PIVOT)
302	01	TWO-SECTION CONTROL VALVE FOR LOADER
302	02	TWO-SECTION CONTROL VALVE FOR LOADER
302	03	TWO-SECTION CONTROL VALVE FOR LOADER

MidWestTech | New Holland B95TC Loader Backhoe Parts Catalog | Publication 87360667 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

339	03	LOADER CONTROL VALVE, THREE SECTION, RELIEF & CHECK VALVES (CENTER PIVOT)
344	01	STABILIZER CONTROL VALVE, TWO SECTION (CENTER PIVOT)
344	02	STABILIZER CONTROL VALVE, LH & RH SECTION (CENTER PIVOT)
356	01	STABILIZER CONTROL VALVE, TREE SECTION (CENTER PIVOT)
356	02	STABILIZER CONTROL VALVE, THIRD SECTION (CENTER PIVOT)
391	01	LOCK VALVE FOR BUCKET 4X1 / 6X1
391/ 1	01	LOCK VALVE ON LOADER TILTING CYLINDERS
391/ 1	02	LOCK VALVE ON LOADER LIFT CYLINDERS
391/ 1	03	LOCK VALVE ON LOADER LIFT CYLINDERS
392	01	LOCKING VALVE ON BACKHOE LIFT AND DIPP. CYLINDER
392	02	BACKHOE LIFT & DIPPERSTICK CYLINDER LOCK VALVE
437/ 1	01	GLIDE RIDE VALVE,HYDRAULIC SYSTEM FOR MACHINE FRAME LEVELLING & ON/OFF SWITCH
698	01	GLIDE RIDE VALVE,HYDRAULIC SYSTEM FOR MACHINE FRAME LEVELLING & ON/OFF SWITCH
708	01	THREE-SECTION CONTROL VALVE FOR LOADER
708/ 1	01	KIT OF CONVERSION FROM 2 TO 3 SPOOLS
721	01	TELESCOPIC CONTROL VALVE, 3 SECTIONS(CENTER PIVOT)
721	02	HED TELESCOPIC CONTORL VALVE, SECTION HOSES(CENTER PIVOT)
721	03	HED CYLINDER PISTON END HYDRAULIC LINES(CENTER PIVOT)
721	04	HED CYLINDER ROD END HYDRAULIC LINES(CENTER PIVOT)
721	05	HED FOOT PEDAL, CABLE & DECALS(CENTER PIVOT)
SEC. 08	00	BODY & HOOD
1.87.2	01	CAB SCREEN
1.87.8	01	CAB FASTENERS
SEC. 09	00	LOADER 1/1
SEC. 09	01	BACKHOE 1/2
SEC. 09	02	BACKHOE 2/2
1.11.0	01	ARMS AND JOINTS
1.11.1	01	LOADER CYLINDER
1.11.2/ 01	01	LOADER BUCKET CONTROL CYLINDER
1.88.01	01	TRANSPORT LOCK" REAR LOCKING" (CENTER PIVOT)
1.88.01	02	TRANSPORT LOCK" REAR LOCKING" (CENTER PIVOT)
1.88.01/ 2	01	"TRANSPORT LOCK" ON/OFF SWITCH, VALVE & HOSES
1.88.01/ 2	02	TRANSPORT LOCK HOOK, CYLINDER & HOSE (SIDE SHIFT,CENTER PIVOT)
1.88.08	01	SWING POST ASSEMBLY, BUSHINGS & PINS
1.88.08	02	SWING POST PINS & TRANSPORT LOCK HOOK
1.88.09	01	DISTRIBUTOR VALVE SUPPORT (CENTER PIVOT)
1.88.11	01	ARMS AND JOINTS
1.88.11/ 1B	01	LIFT CYLINDER
1.88.11/ 2	02	LOADER BUCKET CONTROL CYLINDER
1.88.11/ 2A	01	LOADER BUCKET CONTROL CYLINDER
1.88.11/ 3	01	LIFT CYLINDER AND BUCKET PIPES
1.88.11/ 5	01	SELF-LEVELING LINKAGE, LOADER CONTROLS (CENTER PIVOT)
1.88.11/ 5	02	SELF-LEVELING LINKAGE, LOADER ARM (CENTER PIVOT)
1.88.11/ 6	02	STABILIZER CYLINDERS (CENTER PIVOT)
1.88.11/ 7	01	PIPES FOR STABILIZER CYLINDERS (CENTER PIVOT)
1.88.11/ 8	01	RETURN TO DIG SENSOR
1.88.11/ 9A	01	CYLINDERS AND ROTATION PLATE
1.88.11/ 9C	01	SWING CYLINDERS BACKHOE
1.88.12/ 3	01	FRONT CONTROL VALVE SUPPORT AND TRANSMISSIONS (CENTER PIVOT)

Order the manual at mid-west-tech.com >

RADIATOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		16043021		8	SCREW M8x12
2		47048962		10	WASHER
3		87306886		4	WASHER
4		87306887		4	SCREW M10x16
5		47049581		1	GASKET
6		47050674		1	VALVE, ENG EXHAUST, STD
7		47050733		1	COLLAR
8		47050734		1	COLLAR
9		85828168		4	BRACKET LH
10		87419240		1	CONNECTOR, HYD.
11		85825170		3	BUTTON
12		86983070		1	SEAL, RUBBER
13		87026277		2	SCREW
14		87302922		1	BRACKET RH
15		85825169		1	SPACER
16		87407272		1	HOSE, LARGE
17	1	87410096		1	RADIATOR
18	2	87410099		1	PLATE
19		87410916		1	CONVEYOR
20		87413237		1	HOSE, LARGE
21		87416637		1	GASKET
22		(87302920)		1	

(1) Water
(2) Oil Cooler

Without Air Conditioner

Order the manual at mid-west-tech.com >

4WD FRONT AXLE, DRIVE SHAFT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1	1	85805993		2	JOINT, UNIVERSAL ASSY
1	2	85827741		2	JOINT, UNIVERSAL
2		85805999		2	PLATE, ANTI-WRAP
3	1	85827069		2	YOKE (DIFF.)
3	3	87306929		1	FORK, SHIFTER
4		85827070		2	BODY
5	1	85807283		2	SPIDER WATER PROOF
5	3	85805996		2	SPIDER
6	1	85807284		1	KIT WATER PROOF
6	3	9968060		4	RING, LOCKING
7	1	85805997		2	YOKE (WHEEL)
7	3	87306930		2	FORK, SHIFTER
8	1	85806000		2	CIRCLIP
8	3	87306933		2	RING
9		85817697		2	WASHER

(1) Serial Number Axle 85824329 Until 031054301, Axle 85824331 Until 031054263

(2) Power Shuttle 12.8 And 13.714, Serial Number Axle 85827725 031054302 And After, Axle 85824326 031054264 And After

(3) Serial Number Axle 85827725 031054302 And After, Axle 85824326 031054264 And After

MidWestTech | New Holland B95TC Loader Backhoe Parts Catalog | Publication 87360667 Order the manual at mid-west-tech.com >

SWING POST PINS & TRANSPORT LOCK HOOK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		85801026		1	SPINDLE
2		D7NNC622C		2	SPACER M45X66X3
3		N800271S36M		2	RING
4		87901S8		AR	NIPPLE, LUBE 1/8"-27
5		85801079		1	PIN
6		85803198		1	RING, SNAP
7		15201934		2	SCREW M14x170
8		10717421		2	NUT M14
9		85803246		1	PIN
10		85802872		2	PIN
11		85802396		2	WASHER
12		85802397		2	SCREW M16X40
13		85801191		2	SPACER
14	1	85803637		1	HOOK
14	2	85819493		1	HOOK
15		8274447		1	SHIM
16	1	85819613		1	PIN
16	2	85819702		1	PIN
17	3	85816776		1	KIT

(1) Only for LB110.B - LB115.B - B115
(2) Only for LB90.B - LB95.B - LB110.B - B95 - B95LR - B95TC - B110 - B115
(3) Kit composed of N.4 LH retaining plate and N.4 RH retaining plate

Order the manual at mid-west-tech.com >