NEW HOLLAND

WHEEL LOADER

W110

PARTS CATALOG

87360668 NA

Issued 02-2006

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland W110 Wheel Loader Parts Catalog | Publication 87360668

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	MOUNTING, ENGINE
02 -02	RADIATOR - MOUNTING
02 -03	FAN - FAN BELT
02 -04	COOLANT RECOVERY SYSTEM
02 -05	COOLING SYSTEM - MOTOR, DRIVE (STANDARD FAN DRIVE)
02 -06	COOLING SYSTEM - MOTOR, DRIVE (REVERSIBLE FAN DRIVE)
02 -07	VALVE ASSY - COOLING SYSTEM
02 -08	MOTOR, DRIVE (REVERSIBLE FAN DRIVE)
02 -09	AIR CLEANER - AIR INTAKE PARTS
02 -10	AIR CLEANER ASSY
02 -11	MUFFLER - EXHAUST SYSTEM - STANDARD/ASPIRATOR SPARK ARRESTER
02 -12	MUFFLER - SPARK ARRESTER/ASPIRATOR
02 -13	ENGINE
02 -14	ENGINE, OIL
02 -15	OIL PUMP - ENGINE
02 -16	OIL FILTERS - ENGINE
02 -17	OIL FILTER AND COOLER
02 -18	OIL PUMP, PAN
02 -19	OIL PUMP, PAN - DRAIN LINE
02 -20	BREATHER - ENGINE
02 -21	BREATHER - ENGINE - STANDARD
02 -22	TURBOCHARGER SYSTEM
02 -23	TURBOCHARGER
02 -24	WATER PUMP
02 -25	WATER PUMP - CONTROL
02 -26	CYLINDER BLOCK
02 -27	CYLINDER BLOCK - PLUG ASSY
02 -28	CYLINDER BLOCK
02 -29	FLYWHEEL HOUSING
02 -30	GEAR COVER - REAR HOUSING
02 -31	FRONT GEAR COVER
02 -32	FRONT GEAR COVER - PLATE
02 -33	CYLINDER HEAD - COVERS
02 -34	CYLINDER HEAD - VALVE MECHANISM
02 -35	CYLINDER HEAD
02 -36	MANIFOLD - INTAKE
02 -37	MANIFOLD - EXHAUST
02 -38	CAMSHAFT
02 -39	CRANKSHAFT
02 -40	CRANKSHAFT - PULLEY
02 -41	FLYWHEEL - ENGINE
02 -42	CONNECTING ROD
02 -43	PISTONS - CONNECTING ROD
02 -44	COOLING SYSTEM - ENGINE
02 -45	THERMOSTAT - ENGINE COOLING SYSTEM
02 -46	ENGINE - LIFT HOOK
02 -47	ENGINE - BLOCK HEATER
02 -48	ENGINE - COLD START SYSTEM
03 -01	CONTROLS - THROTTLE, FOOT
03 -02	PEDAL ASSY - THROTTLE, FOOT
03 -03	FUEL LINES - FILTER, IN-LINE FUEL
03 -04	FUEL TANK FILLER - SENDER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03 -05	FUEL PUMP
03 -06	FUEL INJECTION PUMP
03 -07	FUEL INJECTION SYSTEM - PUMP MOUNTING
03 -08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03 -09	FUEL INJECTION SYSTEM - DRAIN LINE
03 -10	FUEL INJECTION SYSTEM
03 -11	FUEL INJECTION SYSTEM - INJECTOR
03 -12	FUEL INJECTION SYSTEM - TURBOCHARGER, PIPES AND CONNECTIONS
03 -13	FUEL FILTER
04 -01	STARTER
04 -02	ALTERNATOR
04 -03	BATTERY - STANDARD
04 -04	BATTERY - CABLES
04 -05	CAB - ELECTRIC COMPONENTS - OPTIONAL
04 -06	CONTROLS, CAB
04 -07	PANEL, CONTROL
04 -08	PANEL, CONTROL
04 -09	INSTRUMENT CLUSTER
04 -10	CAB - WIPER, FRONT
04 -11	CAB - WIPER, REAR
04 -12	HARNESS - CAB, MAIN
04 -13	HARNESS - CAB, MAIN
04 -14	HARNESS - CAB, MAIN
04 -15	HARNESS - GRID HEATER
04 -16	HARNESS - GRID HEATER
04 -17	HARNESS - GRID HEATER
04 -18	HARNESS, FRONT - TC
04 -19	HARNESS, FRONT - Z-BAR
04 -20	HARNESS, REAR CHASSIS
04 -21	HARNESS - RTD - TC - Z-BAR
04 -22	HARNESS - TRANSMISSION
04 -23	AUXILIARY STEERING AND RIDE CONTROL RELAY
04 -24	ELECTRICAL - STEERING, AUXILIARY
04 -25	MOUNTING - LAMP, FRONT
04 -26	MOUNTING - LAMP, REAR
04 -27	LAMP ASSY - LAMP, FRONT
04 -28	LAMP ASSY - LAMPS, REAR COMBINATION
04 -29	CONVERTER, POWER OUTLET - MOUNTING
04 -30	DOUBLE-SIZE ROTATING LAMP
04 -31	RADIO
05 -01	STEERING COLUMN
05 -01A	STEERING COLUMN -
05 -02	VALVE ASSY - STEERING CONTROL
05 -03	HYDRAULICS - STEERING
05 -04	HYDRAULICS - STEERING - STANDARD
05 -05	STEERING - CYLINDER - HYDRAULICS
05 -06	HYDRAULICS - STEERING, AUXILIARY
05 -06A	HYDRAULICS - STEERING, AUXILIARY
05 -07	PRIORITY VALVE - STEERING, AUXILIARY
05 -08	PUMP - STEERING, AUXILIARY
05 -09	CYLINDER ASSY - STEERING
06 -01	HYDRAULICS - TRANSMISSION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06 -02	MOUNTING - TRANSMISSION
06 -03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06 -04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT
06 -05	TRANSMISSION ASSY - INPUT SHAFT
06 -06	TRANSMISSION ASSY - HOUSING
06 -07	TRANSMISSION ASSY - HOUSING TUBES
06 -08	TRANSMISSION - CLUTCH ASSY, FIRST
06 -09	TRANSMISSION - CLUTCH ASSY, SECOND
06 -10	TRANSMISSION - CLUTCH ASSY, THIRD
06 -11	TRANSMISSION - CLUTCH ASSY, FOURTH
06 -12	TRANSMISSION - CLUTCH ASSY, FORWARD
06 -13	TRANSMISSION - CLUTCH ASSY, REVERSE
06 -14	TRANSMISSION - SHAFT, OUTPUT
06 -15	TRANSMISSION - POWER TAKE OFF
06 -16	TRANSMISSION - VALVE PLATES
06 -17	TRANSMISSION - VALVE, CONTROL
06 -18	TRANSMISSION - VALVE, CONTROL
06 -19	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP
06 -20	TRANSMISSION - SENSOR, SPEED AND PUMP COVER
06 -21	TRANSMISSION - FILTER, OIL AND FILLER COVER
06 -22	TRANSMISSION - COVER
06 -23	AXLE, FRONT - MOUNTING
06 -23A	AXLE, FRONT - HOUSING
06 -23B	AXLE, FRONT - DIFFERENTIAL CARRIER
06 -23C	AXLE, FRONT - DIFFERENTIAL
06 -23D	AXLE, FRONT - BRAKE
06 -23E	AXLE, FRONT - HUB, PLANETARY
06 -24	AXLE, REAR - MOUNTING
06 -24A	AXLE, REAR - HOUSING
06 -24B	AXLE, REAR - DIFFERENTIAL CARRIER
06 -24C	AXLE, REAR - DIFFERENTIAL
06 -24D	AXLE, REAR - HUB, DISC BRAKES
06 -24E	AXLE, REAR - HUB, PLANETARY
06 -25	AXLE - REAR, STOP
06 -26	DRIVE SHAFT - ENGINE
06 -27	DRIVE SHAFT, FRONT - BEARING, SUPPORT AND LUBE LINE
06 -28	DRIVE SHAFT - CENTER AND REAR
06 -29	WHEELS
07 -01	BRAKE, PARKING
07 -02	HYDRAULICS - BRAKE, MAIN
07 -03	HYDRAULICS - BRAKE, MAIN
07 -04	HYDRAULICS - BRAKE, MAIN
07 -05	HYDRAULICS - BRAKE, MAIN - AXLE
07 -06	ACCUMULATOR - BRAKE
07 -07	VALVE ASSY - BRAKE
08 -01	RESERVOIR
08 -02	RESERVOIR - GAUGE, SIGHT
08 -03	HYDRAULICS - RESERVOIR TO HYDRAULIC PUMP
08 -04	HYDRAULIC OIL COOLER
08 -05	HYDRAULICS - COOLER WITHOUT BYPASS
08 -06	HYDRAULICS - BYPASS
08 -07	HYDRAULICS - FILTER, OIL

Order the manual at mid-west-tech.com >

HYDRAULICS - LOADER BUCKET - RIGHT SIDE (TC LOADER)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION LOADER BUCKET; XT LOADER
		REF			INSTRUCTION USED WITH OR WITHOUT RSM2-16 RIDE CONTROL OPTION
1		87452747		2	BLOCK Mounting
2		379374A1		2	BLOCK Mounting
3		827-10070		4	BOLT M10 x 70; 10.9
4		827-10090		4	BOLT M10 x 90; 10.9
5		627-10020		2	BOLT M10 x 20; 10.9
6		87447893		1	BRACKET XT Tilt Tubes Right Hand
7		700-104		2	CONNECTOR, HYD. 1-3/16 fc sl x 27 Or; Incl. 7A, 7B
7A		637-64236		1	O-RING 23,6 ID x 2,9; Boss Seal
7B		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
8		700-307		2	ELBOW 1-3/16 fc sl x 27 Or; Incl. 8A, 8B
8A		637-64236		1	O-RING 23,6 ID x 2,9; Boss Seal
8B		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
9		87302137		2	ELBOW ELBOW ORFS, 45deg; BHD 20mm Or 3/4 in; Incl. 9A
9A		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
10		87304893		1	HOSE ASSY. XT Tilt Base; 2175mm (85-5/8 in)
11		87304892		1	HOSE ASSY. XT Tilt Rod; 2255mm (88-3/4 in)
12		701-1249		2	NUT, LOCK
12A		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
13		832-10410		4	NUT M10
14		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
15		8500858		2	PLATE Clamp Cover
16		367658A1		2	PLATE Clamp Cover
17		701-427		2	TEE 1-3/16 fc sl; Incl. 25
17A		238-6018		3	O-RING 3/4 ID x 1/16; Face Seal
18		87447928		1	TUBE ASSY. XT Tilt Base Left
19		87447920		1	TUBE ASSY. XT Tilt Head Right
20		404363A1		1	TUBE ASSY. XT Tilt Rod
21		87447922		1	TUBE ASSY. XT Tilt Rod Right
22		87448138		1	TUBE ASSY. XT Tilt Rod Right
23		895-11010		8	WASHER 11 x 20 x 2 mm
24		895-15010		1	WASHER 11 x 24 x 2 mm
25		404353A1		1	TUBE ASSY. XT Tilt Head

MidWestTech | New Holland W110 Wheel Loader Parts Catalog | Publication 87360668 Order the manual at mid-west-tech.com >

VALVE ASSY - PISTON AXIS - TC

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION TWO AND THREE SPOOL VALVES FOR TC MODELS
15		8604575		1	KIT Incl. 15A, 15B; For REF 16, 17, 18
15A		NSS		4	NOT SERVICED SEPARATELY O-Ring; 25.07 x 2.62
15B		NSS		2	NOT SERVICED SEPARATELY Lock Nut; M8 x 1
16		8604576		2	COVER
17		87311972		1	COVER
18		8605577		1	COVER
19		(864-5060)		2	M5 X 60; 8.8
20		87311974		2	SCREW M5 x 85; 10.9
21		(864-5055)		4	M5 x 55; 8.8
22		8604578		2	VALVE, HYDRAULIC Throttle Check Valve; 2 Have Been Removed From Ref 16 Covers.
23		87311898		1	SPOOL SPOOL
23		87352565		1	SPOOL SPOOL Replaces 87311898
24		87311976		1	SPOOL SPOOL
25		8604579		1	PISTON SPOOL
26		8604580		2	SPRING Compression
27		8604581		3	SCREW Plug; M22 x 1.5
28		8604582		2	RETAINER Spring
29		8604583		4	SPRING Compression
30		87311984		2	SPRING Retanier
31		87311985		1	SPRING
32		87311986		1	RING
33		8604584		1	PISTON SPOOL
34		87311988		1	PLUG SCREW
35		8604586		1	SPRING Compression
36		87311990		2	JET
37		87311991		1	SPOOL

MidWestTech | New Holland W110 Wheel Loader Parts Catalog | Publication 87360668 Order the manual at mid-west-tech.com >

COUPLER, HYDRAULIC - TC - JRB

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{87451620}			COUPLER ASSEMBLY WITH KIT; JRB; TC; Vendor Part Number; 90A3031
		{87369595}			PKG MANUAL JRB
1		REF		1	INSTRUCTION COUPLER ASSEMBLY; JRB; TC; Vendor Part Number; D22289
		REF		1	INSTRUCTION HYDRAULIC KIT; JRB; TC; Vendor Part Number; 96A0115
2		REF		2	INSTRUCTION PLUNGER; JRB; TC; Vendor Part Number; A23264
3		REF		1	INSTRUCTION HYDRAULIC CYLINDER; JRB; TC; Vendor Part Number; B18865
4		REF		2	INSTRUCTION ROLLPIN; 3/8 X 1-3/4; JRB; TC; Vendor Part Number; 124038000175
5		REF		2	INSTRUCTION GREASE ZERK; JRB; TC; Vendor Part Number; A31294-1
6		REF		2	INSTRUCTION STR THD CONNECTOR; JRB; TC; Vendor Part Number; 46036-02
7		REF		1	INSTRUCTION HEX PLUG; JRB;TC; Vendor Part Number; 46154-05
8		REF		2	INSTRUCTION HOSE ASSEMBLY; JRB; TC; Vendor Part Number; 570046-41; Incl. 8A - 8C
8A		REF		1	INSTRUCTION FITTING; JRB; TC; Vendor Part Number; 47036-02
8B		REF			INSTRUCTION FITTING; JRB; TC; Vendor Part Number; 47020-02
8C		REF			INSTRUCTION HOSE; JRB; TC; Vendor Part Number; 56

MidWestTech | New Holland W110 Wheel Loader Parts Catalog | Publication 87360668 Order the manual at mid-west-tech.com >