NEW HOLLAND

WHEEL LOADER

W130

PARTS CATALOG

87360672 NA

Issued 02-2006

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland W130 Wheel Loader Parts Catalog | Publication 87360672

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	MOUNTING, ENGINE
02 -02	RADIATOR - MOUNTING
02 -03	FAN - FAN BELT
02 -04	COOLANT RECOVERY SYSTEM
02 -05	COOLING SYSTEM - MOTOR, DRIVE (STANDARD FAN DRIVE)
02 -06	COOLING SYSTEM - MOTOR, DRIVE (REVERSIBLE FAN DRIVE)
02 -07	VALVE ASSY - COOLING SYSTEM
02 -08	MOTOR, DRIVE (REVERSIBLE FAN DRIVE)
02 -09	AIR CLEANER - AIR INTAKE PARTS
02 -10	AIR CLEANER ASSY
02 -11	MUFFLER - EXHAUST AND INTAKE
02 -12	MUFFLER - SPARK ARRESTER/ASPIRATOR
02 -13	ENGINE
02 -14	ENGINE, OIL
02 -15	OIL PUMP - ENGINE
02 -16	OIL FILTERS - ENGINE
02 -17	OIL FILTER AND COOLER
02 -18	OIL PUMP, PAN
02 -19	OIL PUMP, PAN - DRAIN LINE
02 -20	BREATHER - ENGINE
02 -21	BREATHER - ENGINE - STANDARD
02 -22	TURBOCHARGER SYSTEM
02 -22A	TURBOCHARGER OUTLET
02 -23	TURBOCHARGER
02 -24	WATER PUMP
02 -25	WATER PUMP - CONTROL
02 -26	CYLINDER BLOCK
02 -27	CYLINDER BLOCK
02 -28	CYLINDER BLOCK
02 -29	FLYWHEEL HOUSING
02 -30	GEAR COVER - REAR HOUSING
02 -31	FRONT GEAR COVER
02 -32	GEAR COVER - PLATE
02 -33	CYLINDER HEAD - COVERS
02 -34	CYLINDER HEAD - VALVE MECHANISM
02 -35	CYLINDER HEAD
02 -36	MANIFOLD - INTAKE
02 -37	MANIFOLD - EXHAUST
02 -38	CAMSHAFT
02 -39	CRANKSHAFT
02 -40	CRANKSHAFT - PULLEY
02 -41	FLYWHEEL - ENGINE
02 -42	CONNECTING ROD
02 -43	PISTONS - CONNECTING ROD
02 -44	COOLING SYSTEM - ENGINE
02 -45	THERMOSTAT - ENGINE COOLING SYSTEM
02 -46	ENGINE - LIFT HOOK
02 -47	ENGINE - BLOCK HEATER
02 -48	ENGINE - COLD START SYSTEM
03 -01	CONTROLS - THROTTLE, FOOT
03 -02	PEDAL ASSY - THROTTLE, FOOT
03 -03	FUEL LINES - FILTER, IN-LINE FUEL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03 -04	FUEL TANK FILLER - SENDER
03 -05	FUEL PUMP
03 -06	FUEL INJECTION PUMP
03 -07	FUEL INJECTION SYSTEM - PUMP MOUNTING
03 -08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03 -09	FUEL INJECTION SYSTEM - DRAIN LINE
03 -10	FUEL INJECTION SYSTEM
03 -11	FUEL INJECTION SYSTEM - INJECTOR
03 -12	FUEL INJECTION SYSTEM - TURBOCHARGER, PIPES AND CONNECTIONS
03 -13	FUEL FILTER
04 -01	STARTER
04 -02	ALTERNATOR
04 -03	BATTERY - STANDARD
04 -04	BATTERY - CABLES
04 -05	CAB - ELECTRIC COMPONENTS - OPTIONAL
04 -06	CONTROLS, CAB
04 -07	PANEL, CONTROL
04 -08	PANEL, CONTROL
04 -09	INSTRUMENT CLUSTER
04 -10	CAB - WIPER, FRONT
04 -11	CAB - WIPER, REAR
04 -12	HARNESS - CAB, MAIN
04 -13	HARNESS - CAB
04 -14	HARNESS - CAB, MAIN
04 -15	HARNESS - GRID HEATER
04 -16	HARNESS - GRID HEATER
04 -17	HARNESS - GRID HEATER
04 -18	HARNESS, FRONT - TC
04 -19	HARNESS, FRONT - Z-BAR - XR
04 -20	HARNESS, REAR CHASSIS
04 -21	HARNESS - RTD - TC - Z-BAR - XR
04 -22	HARNESS - TRANSMISSION
04 -23	AUXILIARY STEERING AND RIDE CONTROL RELAY
04 -24	ELECTRICAL - STEERING, AUXILIARY
04 -25	MOUNTING - LAMP, FRONT
04 -26	MOUNTING - LAMP, REAR
04 -27	LAMP ASSY - LAMP, FRONT
04 -28	LAMP ASSY - LAMPS, REAR COMBINATION
04 -29	CONVERTER, POWER OUTLET - MOUNTING
04 -30	DOUBLE-SIZE ROTATING LAMP
04 -31	RADIO
05 -01	STEERING COLUMN
05 -01A	STEERING COLUMN
05 -02	VALVE ASSY - STEERING CONTROL
05 -03	HYDRAULICS - STEERING
05 -04	HYDRAULICS - STEERING - STANDARD
05 -05	HYDRAULICS - STEERING - CYLINDERS
05 -06	HYDRAULICS - STEERING, AUXILIARY
05 -06A	HYDRAULICS - STEERING, AUXILIARY
05 -07	PRIORITY VALVE - STEERING, AUXILIARY
05 -08	PUMP - STEERING, AUXILIARY
05 -09	CYLINDER ASSY - STEERING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06 -01	HYDRAULICS - TRANSMISSION
06 -02	MOUNTING - TRANSMISSION
06 -03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06 -04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT
06 -05	TRANSMISSION ASSY - INPUT SHAFT
06 -06	TRANSMISSION ASSY - HOUSING
06 -07	TRANSMISSION ASSY - HOUSING TUBES
06 -08	TRANSMISSION - CLUTCH ASSY, FIRST
06 -09	TRANSMISSION - CLUTCH ASSY, SECOND
06 -10	TRANSMISSION - CLUTCH ASSY, THIRD
06 -11	TRANSMISSION - CLUTCH ASSY, FOURTH
06 -12	TRANSMISSION - CLUTCH ASSY, FORWARD
06 -13	TRANSMISSION - CLUTCH ASSY, REVERSE
06 -14	TRANSMISSION - SHAFT, OUTPUT
06 -15	TRANSMISSION - POWER TAKE OFF
06 -16	TRANSMISSION - VALVE PLATES
06 -17	TRANSMISSION - VALVE, CONTROL
06 -18	TRANSMISSION - VALVE, CONTROL
06 -19	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP
06 -20	TRANSMISSION - SENSOR, SPEED AND PUMP COVER
06 -21	TRANSMISSION - FILTER, OIL AND FILLER COVER
06 -21A	TRANSMISSION - COVER
06 -22	AXLE, FRONT - MOUNTING
06 -22A	AXLE, FRONT - HOUSING
06 -22B	AXLE, FRONT - DIFFERENTIAL CARRIER
06 -22C	AXLE, FRONT - DIFFERENTIAL
06 -22D	AXLE, FRONT - HUB, DISC BRAKES
06 -22E	AXLE, FRONT - HUB, PLANETARY
06 -23	AXLE, REAR - MOUNTING
06 -23A	AXLE, REAR - HOUSING
06 -23B	AXLE, REAR - DIFFERENTIAL CARRIER
06 -23C	AXLE, REAR - DIFFERENTIAL
06 -23D	AXLE, REAR - HUB, DISC BRAKES
06 -23E	AXLE, REAR - HUB, PLANETARY
06 -24	AXLE, REAR - STOP
06 -25	DRIVE SHAFT - ENGINE
06 -26	DRIVE SHAFT, FRONT - BEARING, SUPPORT AND LUBE LINE
06 -27	DRIVE SHAFT - CENTER AND REAR
06 -28	WHEELS
07 -01	BRAKE, PARKING
07 -02	HYDRAULICS - BRAKE, MAIN
07 -03	HYDRAULICS - BRAKE, MAIN
07 -04	HYDRAULICS - BRAKE, MAIN
07 -05	HYDRAULICS - BRAKE, MAIN - AXLE
07 -06	ACCUMULATOR - BRAKE
07 -07	VALVE ASSY - BRAKE
08 -01	RESERVOIR
08 -02	RESERVOIR - GAUGE, SIGHT
08 -03	HYDRAULICS - RESERVOIR TO HYDRAULIC PUMP
08 -04	HYDRAULIC OIL COOLER
08 -05	HYDRAULICS - COOLER WITHOUT BYPASS
08 -06	HYDRAULICS - BYPASS

Order the manual at mid-west-tech.com >

HARNESS - GRID HEATER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION RELAY INSTALLATION WITH GRID HEATER
1		515-25143		2	14.3mm; M12 Bolt
2		895-11010		8	WASHER 11 x 20 x 2mm
3		627-10030		2	BOLT M10 x 30; 10.9
4		832-10410		2	NUT M10
5		{87404975}		1	Relay
6		440038A1		1	JUNCTION Block Fuse
7		515-23190		2	CLAMP 19.0mm; 3/8in Bolt
8		87404860		1	FUSE HOLDER
9		87307407		1	HARNESS Relay
10		8501314		1	FUSE 40 amp
11		326845A1		1	RELAY
12		{1546485C1}		1	Power
13		{87404974}		1	Power Fuse
14		253065A1		1	SPACER
15		L114612		1	COVER
16		895-25006		2	WASHER 6,6 x 18 x 1,6 mm
17		627-6020		6	BOLT M6 x 20; 10,9
18		895-11008		1	WASHER 9 x 17 x 1,6 mm
19		895-11006		8	WASHER 6,6 x 12 x 1,6 mm
20		892-11008		2	WASHER 8 mm
21		829-1408		2	NUT M8; 10
22		832-10406		4	NUT M6
23		840-1516		1	SCREW M5 x 16; 4.8
24		895-11005		1	WASHER 5,5 x 10 x 1 mm
25		832-10405		1	NUT M5
26		895-11003		4	WASHER 3,2 x 7 x .5 mm
27		824-1403		2	NUT M3
28		{840-1316}		2	M3 x 16; 4,8
29		627-10025		2	BOLT M10 x 25; 10.9
30		827-8060		2	BOLT M8 x 60; 10,9
31		82024562		2	SPACER
32		8501311		1	FUSE 150 Amp

MidWestTech | New Holland W130 Wheel Loader Parts Catalog | Publication 87360672 Order the manual at mid-west-tech.com >

HYDRAULICS - LOADER AUXILIARY (TC LOADER)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION TC LOADER
		REF			INSTRUCTION THREE SPOOL
1		87452747		2	BLOCK Tube Mounting
2		87444440		1	BRACKET Accessory Hose Mounting
3		372453A1		2	BLOCK Tube Mounting
4		700-166		2	CONNECTOR, HYD. 1-7/16 fc sl x 27 orb; Incl. 4A, 4B
4A		238-6021		1	O-RING 15/16 ID x 1/16; Face Seal
4B		637-64236		1	O-RING 23,6 ID x 2,9; Boss Seal
5		87445809		1	TUBE ASSY. Right Hand; Third Spool
6		701-366		2	ELBOW Elbow ORFS; 45deg BHD; 25mm Or 1 Inch; Incl 6A
6A		238-6021		2	O-RING 15/16 ID x 1/16; Face Seal
7		87452607		1	TUBE ASSY. Left Hand; Third Spool
8		87304933		1	HOSE ASSY. XT Accessory; Lower
9		87304930		1	HOSE ASSY. XT Accessory; Upper
10		367658A1		1	PLATE Clamp Cover
11		{827-11010}		2	M10 x 110; 10.9
12		701-914		2	PLUG 1-3/16; Incl. 12A
12A		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
13		701-908		2	NUT ORFS BHD Lock 25mm Or 1 Inch; Incl. 13A
13A		238-6021		1	O-RING 15/16 ID x 1/16; Face Seal
14		895-11010		10	WASHER 11 x 20 x 2 mm
15		832-10410		6	NUT M10
16		627-10035		2	BOLT M10 x 35; 10.9
17		8500858		2	PLATE Clamp Cover
18		827-10090		4	BOLT M10 x 90; 10.9
19		892-11010		2	WASHER, LOCK M10

MidWestTech | New Holland W130 Wheel Loader Parts Catalog | Publication 87360672 Order the manual at mid-west-tech.com >

LOADER BUCKET - WITH TEETH, SEGMENTS AND SKID PADS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION WELDED ON BUCKET COMPONENTS ARE NOT SERVICE SEPARATELY
1		{87367338}		1	BUCKET ASSEMBLY; 1.9 Cubic Meters (2.5 Cubic Yards); Order From Whole Goods; Incl. 2-13
1		{87367340}		1	BUCKET ASSEMBLY; 2 Cubic Meters (2.75 Cubic Yards); Order From Whole Goods; Incl. 2-13
1		{418471A1}		1	BUCKET ASSEMBLY; 1.9 Cubic Meters (2.5 Cubic Yards); Use With ACS Coupler;Order From Whole Goods; Incl. 2-13
1		{434537A1}		1	BUCKET ASSEMBLY; 1.9 Cubic Meters (2.5 Cubic Yards); Use With JRB Coupler;Order From Whole Goods; Incl. 2-13
		REF			INSTRUCTION BOLT ON SKID PAD
2		360939A1		2	PLATE Bottom; Bolt On
3		420-21236		8	BOLT 3/4 x 2-1/4 in
4		425-1612		8	NUT 3/4
		REF			INSTRUCTION BUCKET TEETH AND CUTTING EDGE SEGMENTS
5		373354A1		7	EDGE, CUTTING
6		254825A1		6	TEETH Center; 25mm Plate
6A		233792A1		1	PIN
		NSS			NOT SERVICED SEPARATELY Shank
6B		127555A1		X	TOOTH Standard
6B		254822A1		X	TOOTH Abrasion; Not Illustrated
6B		254823A1		X	TOOTH Penetration; Not Illustrated
7		76082151		1	TOOTH Corner; Left
8		368526A1		1	TOOTH Corner; Right
9		420-21244		18	BOLT, PLOW #3; 3/4 x 2-3/4in
10		425-1612		30	NUT 3/4-10
11		426-1252		6	BOLT 3/4 x 3-1/4 in
12		426-1244		6	BOLT 3/4 x 2-3/4 in
13		496-11081		12	WASHER 13/16 X 1-1/2 X 0.134 IN

MidWestTech | New Holland W130 Wheel Loader Parts Catalog | Publication 87360672 Order the manual at mid-west-tech.com >