NEW HOLLAND

WHEEL LOADER

W130B TIER 3

PARTS CATALOG

87481028 EN-US
Replaces 87519731 NA

Issued 01Dec 07
Revised 01 Feb 09

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland W130B Tier 3 Wheel Loader Parts Catalog | Publication 87481028

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01 -01	DIA
02 -01	MOUNTING, ENGINE
02 -02	RADIATOR - HOSES AND TUBES
02 -03	COOLER, CHARGE AIR
02 -04	COOLER, CHARGE AIR - HOSES AND TUBES
02 -05	FAN DRIVE
02 -06	AIR CLEANER - AIR INTAKE PARTS
02 -06A	AIR CLEANER ASSY
02 -06B	AIR CLEANER - AIR INTAKE PARTS - SA SERIES
02 -07	AIR CLEANER ASSY - PRECLEANER ASSY
02 -08	MUFFLER - EXHAUST SYSTEM
02 -09	OIL FILL, ENGINE
02 -10	OIL PUMP - ENGINE
02 -11	OIL FILTERS - ENGINE
02 -12	OIL FILTER AND COOLER
02 -13	OIL PUMP, PAN
02 -14	OIL PUMP, PAN - DRAIN LINE - COVER
02 -15	BREATHER - ENGINE
02 -16	TURBOCHARGER - DRAIN LINE
02 -17	TURBOCHARGER
02 -18	WATER PUMP
02 -19	WATER PUMP - TENSIONER ASSY
02 -20	CYLINDER BLOCK
02 -21	CYLINDER BLOCK - PLUG ASSY
02 -22	CYLINDER BLOCK - STIFFENER
02 -23	CYLINDER HEAD
02 -24	CYLINDER HEAD - ASSEMBLY
02 -25	CYLINDER HEAD - COVERS
02 -26	CRANKSHAFT
02 -27	CRANKSHAFT - PULLEY
02 -28	FLYWHEEL - ENGINE
02 -29	FLYWHEEL HOUSING
02 -30	GEAR COVER - REAR HOUSING
02 -31	GEAR COVER - PLATE
02 -32	FRONT GEAR COVER
02 -33	ROCKER ARMS
02 -33A	ROCKER ARMS - ASSEMBLY
02 -34	CAMSHAFT
02 -35	PISTON
02 -36	CONNECTING ROD
02 -37	INTAKE MANIFOLD
02 -38	EXHAUST MANIFOLD
02 -39	COOLING SYSTEM - ENGINE
02 -40	THERMOSTAT - ENGINE COOLING SYSTEM
02 -41	ENGINE - LIFT HOOKS
02 -42	ENGINE - BLOCK HEATER
03 -01	FUEL LINES - COOLER, FUEL
03 -02	FILTER, FUEL - WATER SEPARATOR
03 -03	FILTER, FUEL
03 -04	FUEL TANK FILLER - SENDER
03 -04A	FUEL TANK - BREATHER

MidWestTech | New Holland W130B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03 -05	FUEL INJECTION PUMP
03 -06	FUEL INJECTION SYSTEM
03 -07	FUEL INJECTION SYSTEM - INJECTOR
03 -08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03 -09	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03 -10	FUEL INJECTION SYSTEM - HARNESS, ENGINE
03 -11	FUEL INJECTION SYSTEM - DRAIN LINE
04 -01	STARTER
04 -02	ALTERNATOR
04 -02A	ALTERNATOR - MOUNTING WITH AIR CONDITIONING
04 -02B	ALTERNATOR - MOUNTING WITHOUT AIR CONDITIONING
04 -03	HARNESS, FRONT - Z-BAR
04 -03A	HARNESS, FRONT - TC
04 -04	HARNESS - PANEL, CONTROL
04 -05	HARNESS, ENGINE
04 -06	HARNESS, ENGINE - THROTTLE CONTROL
04 -07	HARNESS, ENGINE - FUSES AND RELAYS
04 -08	HARNESS - ROOF - CAB/CANOPY
04 -09	HARNESS - TRANSMISSION
04 -10	HARNESS - GRID HEATER
04 -11	GRID HEATER
04 -12	HARNESS - JOYSTICK STEERING
04 -13	PANEL, CONTROL - SWITCHES
04 -14	PANEL, CONTROL - FUSE AND RELAY MOUNTING
04 -15	CAB - FUSES AND RELAYS
04 -16	ELECTRICAL - TRANSMISSION CONTROL
04 -17	HARNESS - STEERING, AUXILIARY
04 -18	MOUNTING - LAMP, FRONT
04 -19	LAMP ASSY - LAMP, FRONT
04 -20	MOUNTING - LAMP, REAR
04 -21	LAMP ASSY - LAMPS, REAR COMBINATION
04 -22	CAB - WORK LAMPS
04 -22A	CANOPY - WORK LAMPS
04 -23	BEACON ASSY, ROTATING - MOUNTING
04 -23A	ROTATING BEACON COMPONENTS
04 -24	CAB - WIPER, FRONT
04 -24A	CAB - WIPER, REAR
04 -25	RADIO
04 -25A	RADIO - 12 VOLT INSTALLATION
04 -26	BATTERY - STANDARD
04 -26A	BATTERY - HEAVY DUTY
04 -26B	BATTERY - CABLES
04 -27	WINDSHIELD WASHER MOUNTING
04 -28	HORN, FRONT
05 -01	CAB/CANOPY - STEERING WHEEL
05 -02	CAB/CANOPY - STEERING COLUMN (87546449)
05 -02A	CAB/CANOPY - STEERING COLUMN (87497535)
05 -03	CAB - STEERING COLUMN - ACCESSORY, SWITCHES
05 -04	CAB - STEERING COLUMN - COVERS
05 -05	CANOPY - STEERING COLUMN - ACCESSORY, SWITCHES
05 -06	CANOPY - STEERING COLUMN - COVERS

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05 -07	STEERING - HYDRAULICS
05 -08	STEERING - HYDRAULICS - AUXILIARY
05 -09	STEERING - HYDRAULICS - CYLINDER
05 -10	JOYSTICK STEERING - JOYSTICK CONTROL AND HARNESS
05 -11	JOYSTICK STEERING - ARMREST, JOYSTICK CONTROL
05 -12	JOYSTICK STEERING - HYDRAULICS
05 -13	JOYSTICK STEERING - HYDRAULICS - AUXILIARY
05 -14	CYLINDER ASSY - STEERING
05 -15	VALVE ASSY - STEERING CONTROL
05 -16	VALVE ASSY - JOYSTICK STEERING
05 -17	VALVE ASSY - JOYSTICK STEERING, PVFC
05 -18	VALVE ASSY - STEERING, AUXILIARY
05 -19	PUMP - STEERING, AUXILIARY
06 -01	MOUNTING - TRANSMISSION - TRANSMISSION FILL TUBE
06 -02	HYDRAULICS - TRANSMISSION
06 -03	TRANSMISSION - FILTER, OIL AND FILLER COVER - PRIOR TO P.I.N. N8F203848
06 -04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - PRIOR TO P.I.N. N8F203848
06 -05	TRANSMISSION - INPUT SHAFT - PRIOR TO P.I.N. N8F203848
06 -06	TRANSMISSION ASSY - HOUSING - PRIOR TO P.I.N. N8F203848
06 -07	TRANSMISSION ASSY - HOUSING TUBES - PRIOR TO P.I.N. N8F203848
06 -08	TRANSMISSION - CLUTCH ASSY, FIRST - PRIOR TO P.I.N. N8F203848
06 -09	TRANSMISSION - CLUTCH ASSY, SECOND - PRIOR TO P.I.N. N8F203848
06 -10	TRANSMISSION - CLUTCH ASSY, THIRD - PRIOR TO P.I.N. N8F203848
06 -11	TRANSMISSION - CLUTCH ASSY, FOURTH - PRIOR TO P.I.N. N8F203848
06 -12	TRANSMISSION - CLUTCH ASSY, FORWARD - PRIOR TO P.I.N. N8F203848
06 -13	TRANSMISSION - CLUTCH ASSY, REVERSE - PRIOR TO P.I.N. N8F203848
06 -14	TRANSMISSION - SHAFT, OUTPUT - PRIOR TO P.I.N. N8F203848
06 -15	TRANSMISSION - POWER TAKE OFF - PRIOR TO P.I.N. N8F203848
06 -16	TRANSMISSION - VALVE PLATES - PRIOR TO P.I.N. N8F203848
06 -17	TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N8F203848
06 -18	TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N8F203848
06 -19	TRANSMISSION - VALVE, REGULATOR AND OIL PUM - PRIOR TO P.I.N. N8F203848
06 -20	TRANSMISSION - SENSOR, SPEED AND PUMP COVER - PRIOR TO P.I.N. N8F203848
06 -21	TRANSMISSION - FILTER, OIL AND FILLER COVER - P.I.N. N8F203848 AND AFTER
06 -22	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - P.I.N. N8F203848 AND AFTER
06 -23	TRANSMISSION - INPUT SHAFT - P.I.N. N8F203848 AND AFTER
06 -24	TRANSMISSION ASSY - HOUSING - P.I.N. N8F203848 AND AFTER
06 -25	TRANSMISSION ASSY - HOUSING TUBES - P.I.N. N8F203848 AND AFTER
06 -26	TRANSMISSION - CLUTCH ASSY, FIRST - P.I.N. N8F203848 AND AFTER
06 -27	TRANSMISSION - CLUTCH ASSY, SECOND - P.I.N. N8F203848 AND AFTER
06 -28	TRANSMISSION - CLUTCH ASSY, THIRD - P.I.N. N8F203848 AND AFTER
06 -29	TRANSMISSION - CLUTCH ASSY, FOURTH - P.I.N. N8F203848 AND AFTER
06 -30	TRANSMISSION - CLUTCH ASSY, FORWARD - P.I.N. N8F203848 AND AFTER
06 -31	TRANSMISSION - CLUTCH ASSY, REVERSE - P.I.N. N8F203848 AND AFTER
06 -32	TRANSMISSION - SHAFT, OUTPUT - P.I.N. N8F203848 AND AFTER
06 -33	TRANSMISSION - POWER TAKE OFF - P.I.N. N8F203848 AND AFTER
06 -34	TRANSMISSION - VALVE PLATES - P.I.N. N8F203848 AND AFTER
06 -35	TRANSMISSION - VALVE, CONTROL - P.I.N. N8F203848 AND AFTER
06 -36	TRANSMISSION - VALVE, CONTROL - P.I.N. N8F203848 AND AFTER

MidWestTech | New Holland W130B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >

HYDRAULICS - BRAKE, MAIN - AXLE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, ILLUSTRATION A - FRONT AXLE, ILLUSTRATION B - REAR AXLE
1		700-305		2	ELBOW, 90°, 13/16"-18 ORFS x M18 x 1.5 ORB, Incl. Refs. 1A, 1B
1A		238-6014		1	O-RING, -014, 90 Duro, .489" ID x .070" Thk, Face Seal
1B		637-63153		1	O-RING, CI 6, 15.3MM ID x 2.2 Thk
2		701-416		1	TEE, 13/16"-16 ORFS x 13/16"-16 Fem Sw Run, Incl. Refs. 2A
2A		238-6014		2	O-RING, -014, 90 Duro, .489" ID x .070" Thk, Face Seal
3		701-320		1	ELBOW, 90°, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Incl. Refs. 3A, 3B
3A		238-6014		1	O-RING, -014, 90 Duro, .489" ID x .070" Thk, Face Seal
3B		637-63153		1	O-RING, CI 6, 15.3MM ID x 2.2 Thk
4		386735A1	BSN N8F203848	1	TUBE ASSY., Front Axle Brake; Used With Front Axle 87358580
4A		87552628	ASN N8F203848	1	TUBE, Front Axle Brake; Used With Front Axle 87550687
5		87689318		1	HOSE ASSY., Front Axle Brake; 3168mm (124 - 3/4 in)
6		627-10030		1	BOLT, Hex, M10 x 30, 10.9, Full Thd
7		895-11010		2	WASHER, M10 x 20 x 2
8		515-24222		2	CLAMP, 7/8", Insul, 7/16" Bolt
9		832-10410		2	NUT, LOCK, M10 x 1.5, CI 8
10		87553873	BSN N8F203848	1	HOSE, Rear Axle Brake; 1081 mm (42 - 9/16 in); Used With Rear Axle 87358583
10A		87587480	ASN N8F203848	1	HOSE ASSY., Rear Axle Brake; 910 mm (35 - 13/16 in); Used With Rear Axle 87550688
11		386823A1	BSN N8F203848	1	TUBE ASSY., Rear Axle Brake; Used With Rear Axle 87358583
11A		87552630	ASN N8F203848	1	TUBE, Rear Axle Brake; Used With Rear Axle 87550688

MidWestTech | New Holland W130B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >

HYDRAULICS - LOADER BUCKET (TC LOADER) - LEFT SIDE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, TC LOADER BUCKET
1		87447892		1	BRACKET, Tilt Tubes Left Side
2		87447897		1	TUBE ASSY., Tilt Base Left Side
3		87452605		1	TUBE ASSY., Tilt Head Left Side
4		87445800		1	TUBE ASSY., Tilt Rod End Left Side
5		87445804		1	TUBE ASSY., Tilt Rod Right Left Side
6		87452747		2	BLOCK, Tube Mounting
7		367489A1		2	BLOCK, Mounting
8		238-6021		2	O-RING, -021, 90 Duro, .926" ID x .070" Thk, Face Seal
9		827-10070		4	BOLT, Hex, M10 x 70, 10.9
10		827-10090		4	BOLT, Hex, M10 x 90, 10.9
11		627-10020		2	BOLT, Hex, M10 x 20, 10.9, Full Thd
12		700-105		1	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Incl. Ref. 12A
12A		238-6021		1	O-RING, -021, 90 Duro, .926" ID x .070" Thk, Face Seal
13		701-366		2	ELBOW, 45°, 1 7/16"-12. ORFS, Blkhd, Incl. Ref. 13A
13A		238-6021		2	O-RING, -021, 90 Duro, .926" ID x .070" Thk, Face Seal
14		367658A1		2	PLATE, Clamp Cover
15		8500858		2	PLATE, Clamp Cover
16		87304928		1	HOSE ASSY., Tilt Base; 2273mm (89-1/2 in)
17		87304926		1	HOSE ASSY., Tilt Rod; 2252mm (88-3/4 in)
18		895-11010		4	WASHER, M10 x 20 x 2
19		895-15010		2	WASHER, M11 x 24 x 2
20		701-908		2	NUT, LOCK, 1 7/16"-12, ORFS Blkhd, Incl. Ref. 20A
20A		238-6021		1	O-RING, -021, 90 Duro, .926" ID x .070" Thk, Face Seal
21		832-10410		4	NUT, LOCK, M10 x 1.5, Cl 8

MidWestTech | New Holland W130B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >

SEAT ASSY, AIR SUSPENSION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, LOWER SEAT ASSEMBLY, AIR SUSPENSION
		87398042		1	SEAT ASSY., Incl. Refs. 1 - 54 , Incl. Parts on Figure 09-42C
		87584095		1	SUSPENSION, SEAT, Cloth, Lower Seat Assembly; Incl. Refs. 1 - 54
1		82035095		1	CONTROL, Kit, Incl. Control Mechanism, Mounting Parts
		82035111		1	KIT, Incl. Refs 2 - 5
2		NSS		1	NOT SERVICED SEPARATELY, Isolator
3		82035052		2	BUSHING
4		87585124		2	BOLT, SPECIAL, BOLT, Shoulder M8 x 33
5		NSS		1	NOT SERVICED SEPARATELY, Guide
		82035123		1	HANDLE, Kit, Incl. Refs. 6 - 8
6		NSS		1	NOT SERVICED SEPARATELY, Handle
7		82035087		2	SCREW
8		82035065		3	RIVET, 4 x 16.9 mm
9		85817486		1	COVER, Kit, Incl. (2) Mounting Screws
		82035122		1	SUSPENSION, Kit, Incl. Refs. 10 - 15, Also Incl. (2) Roller Kits, (2) Single Rollers, and (2) 4 x 16.9 Rivets, Which Are Not Illustrated
10		82035081		1	PLUG
11		NSS		1	NOT SERVICED SEPARATELY, Suspension
		71486982		1	LEVER & PIN ASSY, Kit, Incl. Refs 12 - 15
12		NSS		1	NOT SERVICED SEPARATELY, Lever and Pin
13		87584172		2	SPRING, Tension
14		NSS		1	NOT SERVICED SEPARATELY, Screw
15		NSS		1	NOT SERVICED SEPARATELY, Washer
		82035073		1	HANDLE, Kit, Incl. Refs 16, 17
16		NSS		1	NOT SERVICED SEPARATELY, Handle
17		82035087		1	SCREW
		82035079		1	SHOCK ABSORBER, Kit, Incl. Refs. 18 - 20
18		NSS		1	NOT SERVICED SEPARATELY, Shock Absorber
19		85817560		1	WASHER, E-Clip
20		NSS		1	NOT SERVICED SEPARATELY, Washer

MidWestTech | New Holland W130B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >