NEW HOLLAND

WHEEL LOADER

W190B TIER 3

PARTS CATALOG

87481030 EN-US
Replaces 87364204 NA

Issued 01Aug 06
Revised 01 Feb 09

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland W190B Tier 3 Wheel Loader Parts Catalog | Publication 87481030

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01 -01	DIA
02 -01	ENGINE - MOUNTING
02 -02	RADIATOR - MOUNTING
02 -03	FAN DRIVE
02 -04	COOLANT RECOVERY SYSTEM
02 -05	AIR CLEANER - AIR INTAKE PARTS
02 -06	AIR CLEANER ASSY
02 -07	MUFFLER - EXHAUST AND INTAKE
02 -08	ENGINE
02 -09	OIL FILL, ENGINE
02 -10	OIL PUMP - ENGINE
02 -11	OIL FILTERS - ENGINE
02 -12	OIL FILTER AND COOLER
02 -13	OIL PAN
02 -14	OIL PAN DRAIN LINE AND COVER
02 -15	BREATHER - ENGINE
02 -16	TURBOCHARGER SYSTEM
02 -17	TURBOCHARGER
02 -18	WATER PUMP
02 -19	WATER PUMP - CONTROL
02 -20	CYLINDER BLOCK
02 -21	CYLINDER BLOCK - PLUG ASSY
02 -22	CYLINDER BLOCK
02 -23	FLYWHEEL HOUSING
02 -24	GEAR COVER - REAR HOUSING
02 -25	FRONT GEAR COVER
02 -26	GEAR COVER - PLATE
02 -27	CYLINDER HEAD - COVERS
02 -28	CYLINDER HEAD - VALVE MECHANISM
02 -29	CYLINDER HEAD
02 -30	MANIFOLD - INTAKE
02 -31	MANIFOLD - EXHAUST
02 -32	CAMSHAFT
02 -33	CRANKSHAFT
02 -34	CRANKSHAFT - PULLEY
02 -35	FLYWHEEL - ENGINE
02 -36	CONNECTING ROD
02 -37	PISTONS
02 -38	COOLING SYSTEM - ENGINE
02 -39	THERMOSTAT - ENGINE COOLING SYSTEM
02 -40	TURBOCHARGER DRAIN LINE
02 -41	ENGINE - LIFT HOOK
02 -42	ENGINE - BLOCK HEATER
03 -01	FUEL LINES - FILTER, IN-LINE FUEL
03 -02	FILTER, FUEL - WATER SEPARATOR
03 -03	FILTER, FUEL
03 -04	FUEL TANK - FILLER - SENDER
03 -05	FUEL INJECTION PUMP
03 -06	FUEL INJECTION SYSTEM
03 -07	FUEL INJECTION SYSTEM - INJECTOR
03 -08	FUEL INJECTION SYSTEM - FUEL, SUPPLY

MidWestTech | New Holland W190B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03 -09	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03 -10	FUEL INJECTION SYSTEM - HARNESS, ENGINE
03 -11	FUEL INJECTION SYSTEM - DRAIN LINE
04 -01	STARTER
04 -02	ALTERNATOR - MOUNTING WITHOUT AIR CONDITIONING
04 -03	ALTERNATOR - MOUNTING WITH AIR CONDITIONING
04 -04	ALTERNATOR
04 -05	BATTERY - STANDARD
04 -06	BATTERY - HEAVY DUTY
04 -07	CABLES, BATTERY
04 -08	HARNESS - PANEL, CONTROL
04 -08A	PANEL, CONTROL - FUSE AND RELAY MOUNTING
04 -08B	CAB - FUSES AND RELAYS
04 -08C	PANEL, CONTROL - FUSE AND RELAY MOUNTING - IF USED
04 -08D	PANEL, CONTROL - SWITCHES
04 -08E	ELECTRICAL - TRANSMISSION CONTROL - OPTIONS
04 -09	HARNESS - ENGINE
04 -10	HARNESS - GRID HEATER
04 -11	HARNESS, REAR CHASSIS - HARNESS, THROTTLE CONTROL
04 -12	HARNESS, FRONT
04 -13	HARNESS, FRONT
04 -14	HARNESS - ROOF - CAB/CANOPY
04 -15	HARNESS, REAR - RELAY PANEL
04 -16	HARNESS - TRANSMISSION
04 -17	HARNESS - STEERING, AUXILIARY
04 -18	HARNESS - JOYSTICK STEERING
04 -19	MOUNTING - LAMP, FRONT
04 -19A	MOUNTING - LAMP, FRONT - SIDE MARKER
04 -20	MOUNTING - LAMP, REAR
04 -21	MOUNTING - LAMP, REAR - EUROPE
04 -22	LAMP ASSY - LAMP, FRONT
04 -23	LAMP ASSY - LAMPS, REAR COMBINATION
04 -24	CAB - WORK LAMPS
04 -24A	CANOPY - WORK LAMPS
04 -25	WINDSHIELD WASHER MOUNTING
04 -26	CAB - WIPER, FRONT
04 -27	CAB - WIPER, REAR
04 -28	RADIO
04 -29	RADIO - 12 VOLT INSTALLATION
04 -30	BEACON ASSY, ROTATING - MOUNTING
04 -30A	ROTATING BEACON COMPONENTS
05 -01	CAB/CANOPY - STEERING WHEEL
05 -02	CAB/CANOPY - STEERING COLUMN (87546449)
05 -02A	CAB/CANOPY - STEERING COLUMN (87497535)
05 -03	CAB - STEERING COLUMN - ACCESSORY, SWITCHES
05 -04	CAB - STEERING COLUMN - COVERS
05 -05	CANOPY - STEERING COLUMN - ACCESSORY, SWITCHES
05 -06	CANOPY - STEERING COLUMN - COVERS
05 -07	STEERING - HYDRAULICS
05 -08	STEERING - HYDRAULICS - AUXILIARY
05 -09	STEERING, STANDARD - HYDRAULICS - CYLINDER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05 -10	STEERING, STANDARD - HYDRAULICS - CYLINDER
05 -10A	STEERING, STANDARD - HYDRAULICS - CYLINDER
05 -11	JOYSTICK STEERING - JOYSTICK CONTROL AND HARNESS
05 -12	JOYSTICK STEERING - ARMREST, JOYSTICK CONTROL
05 -13	JOYSTICK STEERING - HYDRAULICS
05 -14	JOYSTICK STEERING - HYDRAULICS - AUXILIARY
05 -15	CYLINDER ASSY - STEERING
05 -16	VALVE ASSY - STEERING CONTROL
05 -17	VALVE ASSY - JOYSTICK STEERING
05 -18	VALVE ASSY - JOYSTICK STEERING, PVFC
05 -19	VALVE ASSY - STEERING, AUXILIARY
05 -20	PUMP - STEERING, AUXILIARY
06 -01	MOUNTING - TRANSMISSION
06 -02	HYDRAULICS - TRANSMISSION
06 -03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06 -04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - PRIOR TO P.I.N. N7F203144
06 -05	TRANSMISSION ASSY - HOUSING - PRIOR TO P.I.N. N7F203144
06 -06	TRANSMISSION ASSY - HOUSING TUBES - PRIOR TO P.I.N. N7F203144
06 -07	TRANSMISSION - CLUTCH ASSY, FIRST - PRIOR TO P.I.N. N7F203144
06 -08	TRANSMISSION - CLUTCH ASSY, SECOND - PRIOR TO P.I.N. N7F203144
06 -09	TRANSMISSION - CLUTCH ASSY, THIRD - PRIOR TO P.I.N. N7F203144
06 -10	TRANSMISSION - CLUTCH ASSY, FOURTH - PRIOR TO P.I.N. N7F203144
06 -11	TRANSMISSION - CLUTCH ASSY, FORWARD - PRIOR TO P.I.N. N7F203144
06 -12	TRANSMISSION - CLUTCH ASSY, REVERSE - PRIOR TO P.I.N. N7F203144
06 -13	TRANSMISSION - SHAFT, OUTPUT - PRIOR TO P.I.N. N7F203144
06 -14	TRANSMISSION - POWER TAKE OFF - PRIOR TO P.I.N. N7F203144
06 -15	TRANSMISSION - VALVE PLATES - PRIOR TO P.I.N. N7F203144
06 -16	TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N7F203144
06 -17	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP - PRIOR TO P.I.N. N7F203144
06 -18	TRANSMISSION - SENSOR, SPEED AND PUMP COVER - PRIOR TO P.I.N. N7F203144
06 -19	TRANSMISSION - FILTER, OIL AND FILLER COVER - PRIOR TO P.I.N. N7F203144
06 -20	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - P.I.N. N7F203144 AND AFTER
06 -21	TRANSMISSION ASSY - HOUSING - P.I.N. N7F203144 AND AFTER
06 -22	TRANSMISSION ASSY - HOUSING TUBES - P.I.N. N7F203144 AND AFTER
06 -23	TRANSMISSION - CLUTCH ASSY, FIRST - P.I.N. N7F203144 AND AFTER
06 -24	TRANSMISSION - CLUTCH ASSY, SECOND - P.I.N. N7F203144 AND AFTER
06 -25	TRANSMISSION - CLUTCH ASSY, THIRD - P.I.N. N7F203144 AND AFTER
06 -26	TRANSMISSION - CLUTCH ASSY, FOURTH - P.I.N. N7F203144 AND AFTER
06 -27	TRANSMISSION - CLUTCH ASSY, FORWARD - P.I.N. N7F203144 AND AFTER
06 -28	TRANSMISSION - CLUTCH ASSY, REVERSE - P.I.N. N7F203144 AND AFTER
06 -29	TRANSMISSION - SHAFT, OUTPUT - P.I.N. N7F203144 AND AFTER
06 -30	TRANSMISSION - POWER TAKE OFF - P.I.N. N7F203144 AND AFTER
06 -31	TRANSMISSION - VALVE PLATES - P.I.N. N7F203144 AND AFTER
06 -32	TRANSMISSION - VALVE, CONTROL - P.I.N. N7F203144 AND AFTER
06 -33	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP - P.I.N. N7F203144 AND AFTER
06 -34	TRANSMISSION - SENSOR, SPEED AND PUMP COVER - P.I.N. N7F203144 AND AFTER
06 -35	TRANSMISSION - FILTER, OIL AND FILLER COVER - P.I.N. N7F203144 AND AFTER

MidWestTech | New Holland W190B Tier 3 Wheel Loader Parts Catalog | Publication 8748... Order the manual at mid-west-tech.com >