NEW HOLLAND

CRAWLER DOZER

D95

PARTS CATALOG

87519745 NA
Replaces 87359318 NA

Revised 01Nov06
Issued 01Nov05

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland D95 Crawler Dozer Parts Catalog | Publication 87519745

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-04	RADIATOR ASSY
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK
02-12	CYLINDER BLOCK
02-13	OIL PAN
02-14	CYLINDER BLOCK - COVERS
02-15	CYLINDER BLOCK - COVERS
02-16	CYLINDER BLOCK - COVERS
02-17	BREATHER - ENGINE
02-18	CYLINDER HEAD
02-19	CYLINDER HEAD - COVERS
02-20	CYLINDER HEAD - VALVE MECHANISM
02-21	MANIFOLD - INTAKE
02-22	MANIFOLD - EXHAUST
02-23	CRANKSHAFT
02-24	PISTONS - CONNECTING ROD
02-25	PISTONS - CONNECTING ROD
02-26	FLYWHEEL - ENGINE
02-27	PULLEY - CRANKSHAFT
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03-02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03-03	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION SYSTEM
03-09	FUEL INJECTION SYSTEM
03-10	FUEL FILTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-11	FUEL PUMP
03-12	FUEL INJECTION SYSTEM
03-13	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04-03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS
04-07	BATTERY, DUAL - CAB
04-08	HARNESS, ENGINE - FUSES AND RELAYS
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB (SIAC CAB WITH STATIONARY SIDE REAR WINDOW)
04-13A	HARNESS, FRONT CONSOLE AND SWITCHES - CAB (MCLAUGHLIN CAB W/TILT OUT SIDE REAR WINDOW)
04-14	HARNESS, CANOPY - HARNESS, MICROCONTROLLER
04-15	HARNESS, CAB - HARNESS, MICROCONTROLLER (SIAC CAB WITH STATIONARY SIDE REAR WINDOW)
04-15A	HARNESS, MCLAUGHLIN CAB/ CANOPY ROPS - HARNESS, MICROCONTROLLER
04-16	CONSOLE, FRONT - CANOPY, ROPS
04-17	CONSOLE, FRONT - CAB (SIAC CAB WITH STATIONARY SIDE REAR WINDOW)
04-17A	CONSOLE, FRONT - CAB (MCLAUGHLIN CAB W/TILT OUT SIDE REAR WINDOW)
04-18	INSTRUMENT CLUSTER
04-19	HARNESS, LAMP - CANOPY, ROPS (W/ ROUNDED CONNECTORS)
04-19A	HARNESS, LAMP - CANOPY, ROPS (W/ SHROUD CONNECTORS)
04-20	HARNESS, LAMP - CAB (SIAC CAB WITH STATIONARY SIDE REAR WINDOW)
04-20A	HARNESS, LAMP - CAB (MCLAUGHLIN CAB W/TILT OUT SIDE REAR WINDOW)
04-21	ALARM, BACKUP - HORN
04-23	GRID HEATER - CABLES (W/O TEMP. SWITCH CONNNECTIONS; IF USED)
04-23A	GRID HEATER - CABLES (W/ TEMP. SWITCH CONNNECTIONS; IF USED)
04-24	GRID HEATER - SYSTEM CONTROL (W/O TEMP. SWITCH CONNNECTIONS; IF USED)
04-24A	GRID HEATER - SYSTEM CONTROL (W/ TEMP. SWITCH CONNNECTIONS; IF USED)
04-25	WIPER, FRONT - CAB (SIAC CAB WITH STATIONARY SIDE REAR WINDOW)
04-25A	WIPER, FRONT - CAB (MCLAUGHLIN CAB W/TILT OUT SIDE REAR WINDOW)
04-26	WIPER, REAR - CAB (SIAC CAB WITH STATIONARY SIDE REAR WINDOW)
04-26A	WIPER, REAR - CAB (MCLAUGHLIN CAB W/TILT OUT SIDE REAR WINDOW)
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02	FRAME, TRACK - COVERS
05-02A	FRAME, TRACK - COVERS (W/ 12 MM LARGER CUTOUT; IF USED)
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-10	TRACK CHAIN, SEALED AND LUBRICATED
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY
06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - COMBINATION
06-14	PUMP ASSY - COMBINATION
07-01	BRAKES - PEDALS AND LINKAGE
07-02	BRAKE LINES
07-03	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-02A	PUMP ASSY, HYDRAULIC - MODELS WITH PTO
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN

Order the manual at mid-west-tech.com >