KOBELCO

PARTS CATALOG

EXCAVATOR

235SR-2

235SRLC-2

87578855 NA

Issued: 01May07

APPLICABLE:
235SR-2. . . . . YF05-02001~
235SRLC-2 . . . . . YU05-02001~

MidWestTech | Kobelco 235SR-2, 235SRLC-2 Excavator Parts Catalog | Publication 87578855

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-001	00	FILTER, FUEL - FILTER, OIL
02-001	00	FRAME ASSEMBLY, UPPER (YF52F00067F1, 63F1)
02-001	01	FRAME ASSEMBLY, UPPER (YF52F00071F1)
02-002	00	COUNTERWEIGHT INSTAL (YF60C00009F1, 12F1)
02-003	00	COUNTERWEIGHT INSTAL (YF60C00016F1, 13P1)
02-004	00	ENGINE ASSY (YF02P00003F1)
02-005	00	ENGINE INSTAL (YB02P00009F1)
02-005	01	ENGINE INSTAL (YB02P00009F1)
02-006	00	RADIATOR INSTAL (YB05P00014F1)
02-007	00	RADIATOR - COOLANT RECOVERY SYSTEM (YB05P00008F1 RAD. GROUP)
02-007	01	RADIATOR AND CONNECTIONS (YB05P00008F1 RAD. GROUP)
02-008	00	RADIATOR ASSY (YB05P00019F1)
02-008	01	RADIATOR ASSY - INSULATION (YB05P00019F1)
02-009	00	AIR CLEANER ASSY (YB11P00002F1)
02-010	00	MUFFLER ASSY (YB12P00005F1)
02-011	00	FUEL LINES (YF21P00004F1)
02-012	00	TANK INSTAL, FUEL (YF20P00010F1)
02-013	00	TANK INSTAL, HYDRAULIC (YF33H00011F1, 17F1)
02-014	00	POWER TAKE-OFF ASSY (YF30P00004F1)
02-015	00	MOTOR INSTAL, SWING (YF32W00002F1)
02-016	00	CONTROL VALVE INSTAL (YF64H00035F1)
02-016	01	CONTROL VALVE INSTAL - NIBBLER AND BREAKER (YN64H00338F1)
02-017	00	HYDRAULICS - PUMP TO CONTROL VALVE (YF30H00007F1)
02-017	01	HYDRAULICS - PUMP TO CONTROL VALVE (YF30H00007F1, 05F1)
02-018	00	HYDRAULICS - UPPER / SWING MOTOR TO CYLINDER (YF03H00027F1, 22F1)
02-018	01	HYDRAULICS - UPPER / SWING MOTOR TO CYLINDER - CLAMPS AND RETAINERS (YF03H00027F1, 22F1)
02-018	02	HYDRAULICS - UPPER / AT CONTROL VALVE
02-018	03	HYDRAULIC LINES, UPPER - NIBBLER AND BREAKER
02-019	00	HYDRAULIC - SWIVEL
02-020	00	HYDRAULICS - RETURN (YF32H00008F1, 06F1)
02-020	01	HYDRAULICS - RETURN (YF32H00008F1, 06F1)
02-021	00	CONTROLS, OPERATOR (YB03M00037F1)
02-021	01	COVER ASSY, OPERATOR CONTROLS (YB03M00037F1)
02-022	00	CONTROL BOX ASSY (YB03M00036F1)
02-023	00	GRIP ASSY (YN03M01870F1)
02-024	00	RADIO INSTALLATION (YN54E00010F1)
02-025	00	ARM REST (YN25M01183F1)
02-026	00	LEVER ASSY, PROPEL (YN50M00015F1)
02-027	00	PEDAL ASSY (YN55M00004F1)
02-028	00	CONTROL LINES, REMOTE (YN68H00022F1)
02-028	01	CONTROL LINES, REMOTE (YN68H00022F1)
02-028	02	CONTROL LINES, REMOTE (YN68H00022F1)
02-028	03	CONTROL LINES, REMOTE - NIBBLER AND BREAKER (YF368H00025F1, YF64H00056F1)
02-028	04	CONNECTOR ASSY - NIBBER & BREAKER (YN43H01646F1)
02-029	00	CONTROL LINES, MAIN (YF06H00028F1, 29F1)
02-029	01	CONTROL LINES, MAIN (YF06H00028F1, 19F1, 23F1, 24F1)
02-030	00	CONTROL LINES, VALVE (YF64H00095F1, 62F1)
02-030	01	CONTROL LINES, VALVE (YF64H00095F1, 47F1)
02-030	02	CONTROL LINES, VALVE - NIBBLER AND BREAKER (YF64H00039F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-031	00	CONTROL LINES, PUMP (YF06H00015F1, 14F1)
02-032	00	CONTROL LINES, PROPEL (YF62H0005F1, 56F1)
02-032	01	CONTROL LINES, PROPEL (YF62H0005F1)
02-033	00	PLATE INSTALL, FLOOR (YB03M00029F1)
02-034	00	MIRROR INSTAL (YF52C00006F1)
02-035	00	MIRROR INSTAL (YF52C00005F1)
02-036	00	CAB INSTALL (YB02C00062F1, 63F1, YB54C00001F1)
02-037	00	INSULATION INSTAL (YB26C00001F1)
02-038	00	CAB ASSY (YB02C00064F1)
02-038	01	CAB ASSY (YB02C00064F1)
02-038	02	CAB ASSY (YB02C00064F1)
02-038	03	CAB ASSY (YB02C00064F1)
02-039	00	GUARD ASSY (YB02C01110F1) - WINDOW ASSY, ROOF
02-040	00	WINDOW ASSY, FRONT
02-041	00	CAB DOOR (YB51C00004F1)
02-042	00	SEAT INSTALLATION (YN25M00025F1, 62F1)
02-043	00	SEAT BELT ASSY (YN25M00053F1)
02-044	00	GUARD INSTAL (YF21C00020F1, 25F1)
02-044	01	GUARD INSTAL (YF21C00020F1, 25F1)
02-044	02	GUARD INSTAL (YF21C00020F1, 25F1)
02-045	00	GUARD INSTAL (YF21C01257F1, 763F1, 673F1,628F1, 576F1)
02-045	01	GUARD INSTAL (YF21C01740F1, 333F1, 712F1)
02-046	00	GUARD INSTAL (YF21C00026F1)
02-046	01	GUARD INSTAL (YF21C00026F1)
02-047	00	GUARD INSTAL (YF21C01634F1, 636F1, 768F1, 641F1)
02-047	01	GUARD INSTAL (YF21C01647F1, 649F1, 652F1, 658F1, 298F1)
02-048	00	GUARD INSTAL (YF21C00023F1, 27F1)
02-048	01	GUARD INSTAL (YF21C00022F1, 23F1)
02-049	00	GUARD INSTAL (YF22C01327F1, 262F1, 0014F1, 1377F1)
02-049	01	GUARD INSTAL (YF22C01338F1)
02-050	00	GUARD INSTAL (YF21C00034F1)
02-050	01	GUARD INSTAL (YF21C00034F1)
02-051	00	COVER ASSY, UNDER
02-052	00	INSTRUMENT PANEL ASSEMBLY (YB17M00015F1)
02-052	01	INSTRUMENT PANEL ASSEMBLY (YB17M00015F1)
02-052	02	INSTRUMENT PANEL ASSEMBLY (YB17M00015F1, YN50E00021F1)
02-053	00	GAUGE ASSY, CLUSTER (YN59S00021F2)
02-054	00	CONTROLLER INSTALLATION (YF22E00039F1)
02-055	00	RELAY BOX ASSY (YN24E00016F1)
02-056	00	BATTERY ASSY (YF72E00003F1)
02-057	00	AIR CONDITIONER (YB20M00010F1)
02-057	01	AIR CONDITIONER (YB20M00010F1)
02-057	02	AIR CONDITIONER (YB20M00010F1)
02-058	00	AIR CONDITIONER ASSY (YB20M00011F1)
02-059	00	DRIER ASSY, AIR (YB96V00005F1)
02-060	00	COMPRESSOR ASSY, AIR (YX91V00001F1)
02-061	00	CONDITIONER ASSY, AIR (YN20M00107F2)
02-061	01	CONDITIONER ASSY, AIR (YN20M00107F2)
02-062	00	ELECT ASSY, UPP (YB03E00003F1)
02-063	00	LAMP MOUNTING, UPP (YB80E00004F1)
02-064	00	LAMP ASSY (YT80S00002F1)

MidWestTech | Kobelco 235SR-2, 235SRLC-2 Excavator Parts Catalog | Publication 87578... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-065	00	LAMP INSTAL (YB80E00009F1)
02-065	01	LAMP INSTAL (YB80E00009F1)
02-066	00	HARNESS ASSY, UPPER (YB13E00032F1)
02-067	00	HARNESS ASSY, UPPER (YB13E00023F1) 1 OF 11
02-067	01	HARNESS ASSY, UPPER (YB13E00023F1) 2 OF 11
02-067	02	HARNESS ASSY, UPPER (YB13E00023F1) 3 OF 11
02-067	03	HARNESS ASSY, UPPER (YB13E00023F1) 4 OF 11
02-067	04	HARNESS ASSY, UPPER (YB13E00023F1) 5 OF 11
02-067	05	HARNESS ASSY, UPPER (YB13E00023F1) 6 OF 11
02-067	06	HARNESS ASSY, UPPER (YB13E00023F1) 7 OF 11
02-067	07	HARNESS ASSY, UPPER (YB13E00023F1) 8 OF 11
02-067	08	HARNESS ASSY, UPPER (YB13E00023F1) 9 OF 11
02-067	09	HARNESS ASSY, UPPER (YB13E00023F1) 10 OF 11
02-067	10	HARNESS ASSY, UPPER (YB13E00023F1) 11 OF 11
02-068	00	HARNESS ASSY, CAB (YB14E00018F1)
02-069	00	HARNESS ASSEMBLY, UPP PLATE, FLOOR (YB13E00025F1)
02-070	00	HARNESS ASSY, ENGINE (YB16E00002F1)
02-071	00	ALARM ASSY
03-001	00	LOW GROUP, FRAME ASSY (LQ02F00072F1)
03-002	00	RING ASSY, SLEWING (YF40F00008F1)
03-003	00	IDLER ASSY, CRAWLER (LQ52D00024F1)
03-003	01	IDLER ASSY, CRAWLER (LQ52D00025F1)
03-004	00	IDLER ASSY (YN52D00009F1)
03-005	00	IDLER ADJUST ASSY (LQ54D00010F1)
03-006	00	TRACK ROLLER ASSY (LQ64D00030F1)
03-007	00	UPPER ROLLER ASSY (YN64D00032F1)
03-008	00	SHOE ASSY (LQ60D00030F3)
03-009	00	HYDRAULIC LINES, LOW (LQ02H00027F1)
03-009	01	HYDRAULIC LINES, LOW (YN19H00054F1, LQ12H00010F1)
04-001	00	BOOM GROUP, 5.65M (18FT 6in) (YF02B00054F1)
04-001	01	BOOM GROUP, 5.65M (18FT 6in) (YF02B00054F1)
04-002	00	BOOM ASSY, HD 5.65M (18FT 6in) (YF02B00053F1)
04-003	00	HYDRAULIC LINES, BOOM (YF42H00039F1 & YF42H00040F1)
04-003	01	HYDRAULIC LINES, BOOM (YF42H00039F1 & YF42H00040F1)
04-003	02	HYDRAULIC LINES, BOOM - NIBBLER AND BREAKER (YF42H00035F1)
04-004	00	LIGHT INSTALLATION (BOOM) (YN80E00011F1)
04-005	00	LIGHT ASSY. (YW80S00001F1)
04-006	00	ARM GROUP 2.94M (9FT 8in) (YN12B00880F1)
04-006	01	ARM GROUP 2.94M (9FT 8in) (YN12B00880F1)
04-007	00	ARM ASSEMBLY, 2.94M (9FT 8in) (YN12B00821F1)
04-008	00	HYDRAULIC LINES, ARM 2.94 (9FT 8in) (YN12B00801F1)
04-008	01	HYDRAULIC LINES, ARM 2.94 (9FT 8in) - NIBBLER AND BREAKER (YN43H00204F1)
04-009	00	BUCKET INSTALLATION (YN61B00007F1)
05-001	00	TOOL & ACCESSORY (YN01T00151F5)
05-002	00	ELEMENT KIT (YF30T00003F3)
06-001	00	MIRROR INSTAL (YN52C00032F1)
06-002	00	CAP ASSY (YN02B01737F1)
07-001	00	NAME PLATE INSTAL (YF22T00053F1, 53F2)
07-001	01	NAME PLATE INSTAL (YF22T00053F1, 53F2)
07-002	00	NAME PLATE INSTAL - CAB (YF22T00052F1)
07-002	01	NAME PLATE INSTAL - CAB (YF22T00052F1)

MidWestTech | Kobelco 235SR-2, 235SRLC-2 Excavator Parts Catalog | Publication 87578... Order the manual at mid-west-tech.com >