CASE

PROFESSIONAL PARTNER

PARTS CATALOG
LOADER BACKHOE
580M SERIES 3

67632283 NA

Issued 01Mar 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - MOUNTING
02-02	DEAERATION SYSTEM - MOUNTING
02-04	AIR CLEANER - AIR INTAKE PARTS
02-05	AIR CLEANER ASSY
02-06	MUFFLER, ASPIRATED - EXHAUST SYSTEM
02-07	ENGINE - MOUNTING
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CRANKCASE COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CRANKCASE COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	EXHAUST MANIFOLD
02-21	CRANKSHAFT
02-22	CONNECTING ROD
02-23	PISTON - ENGINE
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE OIL DIPSTICK
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	HEAT EXCHANGER - ENGINE
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-41	ENGINE - LIFT HOOK
02-42	ALTERNATOR MOUNTING
03-01	FUEL LINES, RESERVOIR
03-02	CONTROLS - THROTTLE, HAND
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION PUMP
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	INJECTION EQUIPMENT - PIPING
03-08	FUEL FILTER
03-09	FUEL PUMP
03-10	PIPING - FUEL
03-11	FUEL INJECTION SYSTEM
04-01	STARTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-02	ALTERNATOR
04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY, SINGLE
04-06	BATTERY, DUAL - COLD START
04-06A	COLD START GRID HEATER
04-07	HARNESS, FRONT CONSOLE - SWITCHES
04-08	HARNESS, FRONT CONSOLE - MOUNTING
04-09	HARNESS, SIDE CONSOLE - SWITCHES
04-10	INSTRUMENT PANEL, FRONT - COVERS
04-11	INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)
04-12	INSTRUMENT CLUSTER
04-13	ELECTRICAL - LAMPS, ROPS CANOPY
04-14	ELECTRICAL - LAMPS, ROPS CAB
04-15	LAMP ASSY (ROPS CANOPY MODELS)
04-16	HORN - ALARM, BACKUP
04-17	BEACON, ROTATING (CAB OR CANOPY MODELS)
04-18	ANTENNA, RADIO - HARNESS, RADIO
04-19	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, UNI-DIRECTIONAL
04-20	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, WITH PILOT CONTROLS
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING
05-02A	HYDRAULICS - STEERING (COMFORT STEER)
05-03	STEERING COLUMN
05-04	AXLE, FRONT (86990837) - MOUNTING
05-05	AXLE, FRONT (86990837) - HOUSING
05-06	AXLE, FRONT (86990837) - HOUSING, SWIVEL
05-07	AXLE, FRONT (86990837) - CYLINDER, STEERING
05-08	AXLE, FRONT (86990837) - HUB AND BEARINGS
05-09	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE - MOUNTING
06-02	AXLE, FRONT DRIVE - HOUSING
06-03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06-04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06-05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06-06	AXLE, FRONT DRIVE - PLANETARY
06-07	AXLE, FRONT DRIVE - DIFFERENTIAL
06-08	AXLE, FRONT DRIVE - RING AND PINION
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION
06-11	TRANSMISSION - MOUNTING
06-12	TRANSMISSION ASSY, 2WD - FILTER, OIL
06-13	TRANSMISSION ASSY, 2WD - HOUSING
06-14	TRANSMISSION ASSY, 2WD - PUMP, OIL
06-15	TRANSMISSION ASSY, 2WD - SHIFTER MECHANISM
06-16	TRANSMISSION ASSY, 2WD - SHAFT, REVERSE & PRIMARY
06-17	TRANSMISSION ASSY, 2WD - SHAFT, INPUT & PTO
06-18	TRANSMISSION ASSY, 2WD - SHAFT, SECONDARY
06-19	TRANSMISSION ASSY, 2WD - VALVE, CONTROL
06-20	TRANSMISSION ASSY, 4WD - FILTER, OIL
06-21	TRANSMISSION ASSY, 4WD - HOUSING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-22		TRANSMISSION ASSY, 4WD - PUMP, OIL
06-23		TRANSMISSION ASSY, 4WD - SHIFTER MECHANISM
06-24		TRANSMISSION ASSY, 4WD - SHAFT, REVERSE & PRIMARY
06-25		TRANSMISSION ASSY, 4WD - SHAFT, INPUT & PTO
06-26		TRANSMISSION ASSY, 4WD - SHAFT, SECONDARY
06-27		TRANSMISSION ASSY, 4WD - SHAFT, OUTPUT
06-28		TRANSMISSION ASSY, 4WD - VALVE, CONTROL
06-29		TRANSMISSION ASSY, 4WD - VALVE, SOLENOID
06-30		WHEELS, REAR - TIRES
06-31		AXLE, REAR DRIVE - MOUNTING
06-32		AXLE, REAR - DIFFERENTIAL LOCK
06-33		87395372 AXLE, REAR DRIVE - HOUSING
06-34		87395372 AXLE, REAR DRIVE - DIFFERENTIAL
06-35		87395372 AXLE, REAR DRIVE - RING AND PINION
06-36		87395372 AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06-37		87395372 AXLE, REAR DRIVE - PLANETARY
06-38		DRIVE SHAFT, REAR AXLE
07-01		TRANSMISSION ASSY, 2WD - BRAKE, PARKING
07-01	01	TRANSMISSION ASSY, 4WD - BRAKE, PARKING
07-02		AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-03		BRAKE - PEDALS
07-04		HYDRAULICS - BRAKE MASTER CYLINDER
07-05		BRAKE LINES TO TRANSMISSION
07-06		BRAKE LINES TO AXLES
07-07		CYLINDER ASSY - BRAKE MASTER
08-01		HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08-02		HYDRAULICS - LOADER VALVE AND FILTER TO BACKHOE VALVE
08-03		HYDRAULICS - COOLER, RETURN LINES AND FILTER
08-04		HYDRAULICS - CYLINDER, LOADER LIFT
08-05		HYDRAULICS - CYLINDER, LOADER BUCKET
08-06		HYDRAULICS - CYLINDER, LOADER CLAM
08-07		HYDRAULICS - CYLINDER, LOADER CLAM
08-07A		HYDRAULICS - LOADER CLAM, AT ACCUMULATOR W/ ELECTRICAL (MODELS WITHOUT PILOT CONTROLS)
08-07B		HYDRAULICS - LOADER CLAM, AT ACCUMULATOR W/ ELECTRICAL (MODELS WITH PILOT CONTROLS)
08-08		HYDRAULICS - CYLINDER, BACKHOE STABILIZER (WITHOUT PILOT CONTROLS)
08-08A		HYDRAULICS - CYLINDER, BACKHOE STABILIZER (WITH PILOT CONTROLS)
08-09		HYDRAULICS - CYLINDER, BACKHOE SWING (WITHOUT PILOT CONTROLS)
08-09A		HYDRAULICS - CYLINDER, BACKHOE SWING (WITH PILOT CONTROLS)
08-10		HYDRAULICS - CYLINDER, BACKHOE BOOM
08-10A		HYDRAULICS - BACKHOE BOOM LOCK AND ELECTRICAL CIRCUIT
08-11		HYDRAULICS - CYLINDER, BACKHOE DIPPER
08-12		HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITHOUT EXTENDABLE DIPPER)
08-13		HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITH EXTENDABLE DIPPER)
08-14		HYDRAULICS - CYLINDER, BACKHOE EXTENDABLE DIPPER
08-15		HYDRAULICS - VALVE, PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT DIPPER, W/O AUX HYDS)

Order the manual at mid-west-tech.com >