CASE

PROFESSIONAL PARTNER

PARTS CATALOG
EXCAVATOR

CX130B
TIER 3

87632296 NA

Issued 01Jan 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE MOUNTING
02-02	ENGINE OIL SUPPLY LINES
02-03	AIR CLEANER
02-04	EXHAUST SYSTEM - MUFFLER
02-05	RADIATOR AND CONNECTIONS
02-06	RADIATOR ASSY
02-07	PACKAGE SEALS- LARGE - ENGINE
02-08	PACKAGE SEALS - SMALL - ENGINE
02-09	COVER - CYLINDER HEAD
02-10	CYLINDER HEAD
02-11	CYLINDER HEAD, STUDS
02-12	CYLINDER BLOCK
02-13	CYLINDER BLOCK
02-14	OIL PAN
02-15	CAMSHAFT - VALVE MECHANISM
02-16	CAMSHAFT - GEARS AND CHAIN
02-17	PISTONS AND CRANKSHAFT
02-18	ENGINE FLYWHEEL HOUSING
02-19	ENGINE FLYWHEEL HOUSING, STUDS
02-20	ENGINE MOUNTING
02-21	INTAKE PIPE
02-22	EXHAUST PIPE
02-23	BREATHER
02-24	WATER PUMP SYSTEM
02-25	ENGINE WATER CIRCUIT - THERMOSTAT
02-26	ENGINE WATER CIRCUIT
02-27	BELT AND VENTILATOR - FAN GUARD
02-28	TURBOCHARGER
02-29	OIL COOLER - ENGINE
02-30	OIL PUMP
02-31	OIL CIRCUIT
02-32	EXHAUST GAS RECIRCULATION SYSTEM
02-33	BRACKET - FAN GUARD
03-01	FUEL TANK
03-02	FUEL LINES
03-03	FUEL FILLING PUMP - OPTIONAL
03-04	FUEL SYSTEM - FUEL INJECTION PUMP
03-05	FUEL SYSTEM
03-06	FUEL FILTER
03-07	FUEL SYSTEM - PLUG
04-01	ELECTRICAL ACCESSORIES - ENGINE - STARTER AND ALTERNATOR
04-02	ELECTRICAL ACCESSORIES - ENGINE - ELECTRONIC CONTROLLED
04-03	ELECTRICAL ACCESSORIES - ENGINE - HARNESS
04-04	ELECTRICAL ACCESSORIES - ENGINE - SWITCH
04-04A	BRACKET
04-05	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-05A	HARNESS, MAIN - CLAMPS AND RETAINERS
04-06	HARNESS, MAIN - RELAY PANEL
04-07	ELECTRICAL - CAB
04-08	TRAVEL ALARM
04-09	CONVERTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-10	CAB ELECTRICAL - WIPER, WINDSHIELD
04-11	HORN
04-12	LAMP, WORK (BOOM)
04-13	CONTROLLER
04-14	BATTERY - CABLES
04-15	RADIO
04-16	WINDSHIELD WASHER
04-17	LAMP, WORK (CAB)
04-18	LAMP, WORK (CAB W/GUARD)
05-01	UNDERCARRIAGE
05-02	UNDERCARRIAGE (LONG)
05-03	GUIDE, CHAIN
05-04	UNDERCARRIAGE COVER, LOWER
05-05	TRACK CHAINS, 500 MM, SEAL
05-06	TRACK CHAINS, 500 MM, M SEAL HOLE
05-07	TRACK CHAINS, 600 MM, M SEAL
05-08	TRACK CHAINS, 600 MM, M SEAL NO HOLE
05-09	TRACK CHAINS, 700 MM, SEAL
05-10	TRACK CHAINS, 700 MM, M SEAL NO HOLE
05-11	TRACK CHAINS, 500 MM, SEAL - RUBBER
05-12	TRACK CHAINS, 500 MM, M SEAL - RUBBER
05-13	TRACK CHAINS, 500 MM, M SEAL NO HOLE
05-14	TRACK - IDLER
05-15	TRACK - ADJUSTER CYLINDER
05-16	TRACK - ROLLER, UPPER
05-17	TRACK - ROLLER, LOWER
05-18	TRACK - ROLLER, UPPER, OPTIONAL
05-19	UNDERCARRIAGE - MODELS WITH DOZER BLADE
06-01	TRACK DRIVE ASSY
06-02	MOTOR ASSY - PISTON
06-03	MOTOR ASSY - TRACK DRIVE
06-04	MOTOR ASSY - GEAR ASSY, REDUCTION
06-05	HYDRAULICS - TRACK DRIVE
06-06	HYDRAULICS - TRACK DRIVE, OPTIONAL
06-07	HYDRAULICS - TRAVEL
08-01	HYDRAULIC RESERVOIR
08-02	HYDRAULIC RESERVOIR - PRESSURE SWITCH
08-03	PUMP ASSY, HYDRAULIC - STANDARD - COUPLING
08-04	PUMP ASSY, HYDRAULIC - OPTIONAL - COUPLING
08-05	HYDRAULICS - PUMP SUCTION LINE
08-06	HYDRAULICS - RESERVOIR RETURN
08-07	HYDRAULICS - DRAIN LINE
08-08	HYDRAULICS - CONTROL VALVE SUPPLY
08-09	HYDRAULICS - SWING
08-10	HYDRAULICS - BOOM
08-11	HYDRAULICS - ARM AND BUCKET
08-12	HYDRAULICS - ARM CYLINDER LINE
08-13	HYDRAULICS - BUCKET LINE
08-14	HYDRAULIC LINES - ARM - OPTIONAL
08-15	PILOT CONTROL LINES, TRAVEL - STANDARD
08-16	PILOT CONTROL LINES, ATTACHMENT - STANDARD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-17	PILOT CONTROL LINES, PARTITION - STANDARD
08-18	PILOT CONTROL LINES, CONTROL VALVE - STANDARD
08-19	PILOT CONTROL LINES, TRAVEL - TWO WAY
08-20	PILOT CONTROL LINES, ATTACHMENT - TWO WAY
08-21	PILOT CONTROL LINES, PARTITION - TWO WAY
08-22	PILOT CONTROL LINES, CONTROL VALVE - TWO WAY
08-23	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-24	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-25	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-26	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, PEDAL ACTIVATED
08-27	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, PEDAL ACTIVATED
08-28	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, HAND OPERATED
08-29	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, HAND OPERATED
08-30	HYDRAULIC LINES - BOOM - OPTIONAL
08-31	HYDRAULIC LINES - ARM (LONG) - OPTIONAL
08-32	HYDRAULIC LINES - BOOM
08-33	SELECTOR VALVE, CONTROL VALVE - TWO WAY
08-34	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, PEDAL ACTIVATED
08-35	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, PEDAL ACTIVATED
08-36	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, PEDAL ACTIVATED
08-37	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, TRIGGER ACTIVATED
08-38	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, TRIGGER ACTIVATED
08-39	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, TRIGGER ACTIVATED
08-40	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT, HAND OPERATED
08-41	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT, HAND OPERATED
08-42	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT, HAND OPERATED
08-43	HYDRAULICS, AUXILIARY - SECOND ACTING CIRCUIT, PEDAL ACTIVATED
08-44	HYDRAULICS, AUXILIARY - SECOND ACTING CIRCUIT, HAND OPERATED
08-45	SECOND OPTION LINE, BOOM
08-46	SECOND OPTION LINE, ARM
08-47	HYDRAULIC CIRCUIT - PLUG, BLANK-OFF (STANDARD)
08-48	HYDRAULIC CIRCUIT - OPTIONAL (SINGLE ACTING) - PLUG, BLANK-OFF
08-49	HYDRAULIC CIRCUIT - OPTIONAL (3-WAY) - PLUG, BLANK-OFF
08-50	HYDRAULIC CIRCUIT - OPTIONAL (3-WAY - SMALL FLOW) - PLUG, BLANK-OFF -
08-51	SWING MOTOR - MOUNTING
08-52	HYDRAULICS - JOINT, SWIVEL CENTER - MODELS WITH DOZER BLADE
08-53	HYDRAULICS - CONTROL VALVE SUPPLY (2ND)
08-54	HYDRAULICS - JOINT, SWIVEL CENTER
08-55	CONTROL VALVE - SUPPORT (STD)
08-56	CONTROL VALVE - SUPPORT
08-57	KNJ14640 VALVE ASSY - CONTROL
08-58	KNJ14640 VALVE ASSY - CONTROL
08-59	KNJ14640 VALVE ASSY - CONTROL
08-60	KNJ14640 VALVE ASSY - CONTROL
08-66	PLUG
08-67	PLUG
08-68	PLUG
08-69	PLUG
08-70	VALVE, PILOT - PILOT CONTROL LINES
08-71	HYDRAULICS - BUCKET LINE - LONG ARM
08-72	VALVE, CONTROL - TRAVEL

Order the manual at mid-west-tech.com >