CASE

PROFESSIONAL PARTNER

PARTS CATALOG
EXCAVATOR

CX135SR
TIER 3

87632298 NA

Issued 01Feb08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01		ENGINE MOUNTING
02-02		ENGINE OIL SUPPLY LINES
02-03		AIR CLEANER
02-04		EXHAUST SYSTEM - MUFFLER
02-05		RADIATOR AND CONNECTIONS
02-05A		RADIATOR ASSY
02-06		PACKAGE SEALS - ENGINE
02-07		PACKAGE SEALS - ENGINE
02-08		COVER - CYLINDER HEAD
02-09		COVER - CYLINDER HEAD
02-10		CYLINDER HEAD
02-11		CYLINDER HEAD
02-12		CYLINDER BLOCK
02-13		CYLINDER BLOCK
02-14		OIL PAN
02-15		CAMSHAFT - VALVE MECHANISM
02-16		CAMSHAFT - VALVE MECHANISM
02-17		PISTONS AND CRANKSHAFT
02-18		ENGINE FLYWHEEL HOUSING
02-19		ENGINE FLYWHEEL HOUSING
02-20		ENGINE MOUNTING
02-21		INTAKE PIPE
02-22		EXHAUST PIPE
02-23		BREATHER
02-24		WATER PUMP SYSTEM
02-25		ENGINE WATER CIRCUIT - THERMOSTAT
02-26		ENGINE WATER CIRCUIT
02-27		BELT AND VENTILATOR - FAN GUARD
02-28		TURBOCHARGER
02-29		OIL COOLER - ENGINE
02-30		OIL PUMP
02-31		OIL CIRCUIT
02-32		EXHAUST GAS RECIRCULATION SYSTEM
02-33		BRACKET - FAN GUARD
03-01		FUEL TANK
03-02	01	FUEL LINES - HOSES
03-02	02	FUEL LINES
03-03		FUEL FILLING PUMP - OPTIONAL
03-04		FUEL SYSTEM - FUEL INJECTION PUMP
03-05		FUEL SYSTEM
03-06		FUEL FILTER
03-07		FUEL SYSTEM
04-01		HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-02		HARNESS, MAIN - RELAY PANEL
04-03		ELECTRICAL COMPONENTS & HARNESS, CAB
04-04		ELECTRICAL - CAB - GAUGES
04-05		BATTERIES
04-06		LAMP, WORK - CAB
04-07		LAMP, WORK - BOOM
04-08		HORN
04-09		CONVERTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-10	CONTROLLER
04-11	RADIO
04-12	WINDSHIELD WASHER
04-13	TRAVEL ALARM
04-14	HARNESS, LAMP, WORK - BOOM
04-15	ELECTRICAL ACCESSORIES - ENGINE - STARTER AND ALTERNATOR
04-16	ELECTRICAL ACCESSORIES - ENGINE - ELECTRONIC CONTROLLED
04-17	ELECTRICAL ACCESSORIES - ENGINE - HARNESS
04-18	ELECTRICAL ACCESSORIES - ENGINE - SWITCH
04-19	BRACKET
05-01	UNDERCARRIAGE
05-02	UNDERCARRIAGE COVER, LOWER
05-03	TRACK - IDLER
05-04	TRACK - ADJUSTER CYLINDER
05-05	TRACK - ROLLER, UPPER
05-06	TRACK - ROLLER, LOWER
05-07	TRACK CHAINS, 500 MM, M SEAL - RUBBER
05-08	TRACK CHAINS, 500 MM, M SEAL HOLE
05-09	TRACK CHAINS, 600 MM, M SEAL NO HOLE
05-10	TRACK CHAINS, 700 MM, M SEAL NO HOLE
06-01	TRACK DRIVE ASSY
06-02	MOTOR ASSY - PISTON
06-03	MOTOR ASSY - TRACK DRIVE
06-04	MOTOR ASSY - GEAR ASSY, REDUCTION
06-05	HYDRAULICS - TRACK DRIVE
06-06	HYDRAULICS - TRACK DRIVE - MODELS WITH DOZER BLADE
08-01	HYDRAULIC RESERVOIR
08-02	PUMP AND COUPLING - MODELS WITHOUT DOZER BLADE
08-03	PUMP AND COUPLING - MODELS WITH DOZER BLADE
08-04	PUMP SUCTION LINE - MODELS WITHOUT DOZER BLADE
08-05	PUMP SUCTION LINE - MODELS WITH DOZER BLADE
08-06	HYDRAULICS - CONTROL VALVE SUPPLY
08-07	HYDRAULICS - JOINT, SWIVEL CENTER
08-08	SWING MOTOR - MOUNTING
08-09	HYDRAULICS - BOOM
08-10	HYDRAULICS- DRAIN LINE - MULTI
08-11	HYDRAULICS - RETURN & OIL COOLER LINE
08-12	CONTROL VALVE - SUPPORT
08-13	HYDRAULICS - SWING
08-14	HYDRAULICS - ARM AND BUCKET
08-15	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-16	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-17	VALVE, SOLENOID - PILOT PRESSURE, RETURN LINES
08-18	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-19	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-20	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-21	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-22	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-23	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-24	KMJ10660 VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08-25	KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-26		KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE
08-27		KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE
08-28		KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE
08-29		KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE
08-30		KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE
08-31		KMJ10690 VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE
08-32		PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08-33		PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08-34		PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08-35		PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08-36		PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-37		PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-38		PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-39		PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-40		HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08-41		HYDRAULICS - TRAVEL
08-41	01	HYDRAULICS - TRAVEL - WITH DOZER BLADE
08-42		HYDRAULICS - TRAVEL
08-42	01	HYDRAULICS - TRAVEL - WITH DOZER BLADE
08-43		PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08-44		VALVE ASSY, REMOTE CONTROL
08-45		VALVE ASSY - HAND CONTROL
08-46		HYDRAULICS - BUCKET, 2,85 METER (9 FT 4 IN) ARM
08-47		CYLINDER ASSY - BUCKET
08-48		HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-49		HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-50		HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-51		VALVE ASSY, DIRECTIONAL
08-52		VALVE ASSY - AUXILIARY CONTROL
08-53		VALVE, SOLENOID
08-54		HYDRAULICS, OPTION LINE - SINGLE ACTING AND MULTI-PURPOSE + 3 WAY VALVE CIRCUITS
08-55		VALVE ASSY - PEDAL CONTROL
08-56		HYDRAULIC RESERVOIR - PRESSURE SWITCH
08-57		PLUG
08-58		PLUG
08-59		PLUG
08-60		PLUG
08-61		PLUG
08-62		PLUG
08-63		PLUG
08-64		PLUG
08-65		HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT
08-66		HYDRAULICS, AUXILIARY ATTACHMENT - BOOM LINE
08-67		HYDRAULICS - BOOM CYLINDER, MODELS WITH LOAD HOLD
08-68		HYDRAULICS - BOOM CYLINDER, MODELS WITH LOAD HOLD
08-69		VALVE LOCK - BOOM CYLINDER (KNV12850)
08-70		BOOM CYLINDER - RIGHT - (HBCV)
08-71		BOOM CYLINDER - LEFT - (HBCV)
08-72	01	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD
08-72	02	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD

Order the manual at mid-west-tech.com >

ENGINE FLYWHEEL HOUSING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
0-11		REF		1	INSTRUCTION, See Figure 02-10
0-12		REF		1	INSTRUCTION, See Figure 02-12
0-40		REF		1	INSTRUCTION, See Figure 03-04
1		87596939		1	CASE
32		87596945		1	GASKET
36A		87595866		1	SCREW
36B		87595292		16	SCREW
36C		87595463		1	SCREW
36D		87595806		2	SCREW
36E		87595839		1	SCREW
36F		87596055		3	SCREW
38		87379458		2	PIN
49		87596967		1	GASKET
50A		87596974		5	STUD
51		87596979		14	SCREW
54		87596984		1	COVER
63		87596985		1	COVER
64		87596993		1	GASKET
79		87597000		1	BRACKET
80A		87595267		1	NUT
80B		87595267		1	NUT
81A		87683451		2	STUD
81B		87597006		2	STUD
98		87595428		2	NUT
99A		87597074		1	STUD
99B		87597075		1	STUD
103		87597076		1	SEAL
123		87597078		1	COVER
124		87595938		3	SCREW
172		87597081		1	RING
175		355280A1		1	SEAL, OIL
185		87595918		5	SCREW
620		87597632		1	GASKET
620		87597643		1	GASKET
620		87597645		1	GASKET

MidWestTech | Case CX135SR Tier 3 Excavator Parts Catalog | Publication 87632298NA Order the manual at mid-west-tech.com >

ELECTRICAL ACCESSORIES - ENGINE - STARTER AND ALTERNATOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
0-11		REF		1	INSTRUCTION, See Figure 02-10
0-12		REF		1	INSTRUCTION, See Figure 02-12
0-20		REF		1	INSTRUCTION, See Figure 02-18
0-22		REF		1	INSTRUCTION, See Figure 02-20
0-25		REF		1	INSTRUCTION, See Figure 02-21
1		87560087		1	MOTOR, STARTER
2		87709229		1	ALTERNATOR
4		87597117		2	SCREW
16		87599818		1	SCREW
23		426067A1		1	NUT
129		87386231		1	SENDER, TEMPERATURE
293		86990207		1	CABLE
327		87595926		1	SENSOR, Incl. 766
611		87599841		1	BRACKET
766		87595936		1	GASKET
782A		87595952		1	SCREW
782B		87595938		1	SCREW
796A		87600394		1	SENSOR
797		87378549		1	SENSOR

MidWestTech | Case CX135SR Tier 3 Excavator Parts Catalog | Publication 87632298NA Order the manual at mid-west-tech.com >

PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
94		154467A1		1	O-RING
100		KHJ2746		1	HOSE ASSY.
101		KHJ2102		1	HOSE ASSY.
102		KHJ2344		1	HOSE ASSY.
103		KHJ2349		1	HOSE ASSY.
104		KHJ2145		1	HOSE ASSY.
105		KHJ2132		2	TEE
106		154467A1		1	O-RING
107		162525A1		2	STUD
108		154467A1		1	O-RING
109		167517A1		2	TEE
110		154467A1		1	O-RING
111		KHJ1266		1	ADAPTER
112		150498A1		8	MOUNTING CLIP
113		167795A1		2	CAP
114		152127A1		1	CONNECTOR, HYD., 1/4" NPT O-Ring x 1/4" NPT
115		154467A1		1	O-RING
116		KHJ2179		1	HOSE ASSY.
117		KHJ2131		1	TEE
118		154467A1		1	O-RING
119		KMJ2716		1	TUBE ASSY.
120		KHJ2181		1	HOSE ASSY.
121		150913A1		1	ELBOW, 90°, 1/4" O-Ring x 1/4"
122		154467A1		1	O-RING
123		KHJ2350		1	HOSE ASSY.
124		KHJ2415		1	VALVE, CUSHION, See Figure 08 - 83
125		KMJ2716		1	TUBE ASSY.
126		KHJ2131		1	TEE
127		154467A1		1	O-RING
128		162525A1		1	STUD
129		154467A1		1	O-RING
130		KHJ2142		1	HOSE ASSY.
131		150913A1		1	ELBOW, 90°, 1/4" O-Ring x 1/4"
132		154467A1		1	O-RING
133		150498A1		1	MOUNTING CLIP

MidWestTech | Case CX135SR Tier 3 Excavator Parts Catalog | Publication 87632298NA Order the manual at mid-west-tech.com >