

SPX Series Patriot Sprayer SPX3310

Operators Manual

87651684

CASE IH

MidWestTech | Case SPX3310 Patriot Sprayer Operator's Manual | Publication 87651684

Order the manual at mid-west-tech.com >

Introduction . . . 3
To the Owner . . . 3
SPX Series Patriot Sprayer . . . 3
Manual Storage Compartment . . . 4
Product Identification and Serial Numbers . . . 4
Identification Number Locations . . . 4

Safety Instructions . . . 9
Safety . . . 9
Personal Safety . . . 9
Safety Rules . . . 10
Machine Operation and Roll-Over Safety . . . 12
Transporting Safety . . . 12
Battery Safety . . . 13
Electrical Line Safety . . . 13
Noise Level Safety . . . 13
Hazardous Chemicals . . . 13
Maintenance Safety . . . 14
Tire Inflation . . . 15
Hand Signals . . . 16
Safety Decals . . . 18
First Aid Kit . . . 24
Read Operators Manual . . . 24
Fire Extinguisher . . . 24
Cleaning Cab Windows . . . 24
Seat Belt . . . 24
Sprayer Warning Lights and SMV Symbol . . . 25

Operating Instructions . . . 29
Pre-Operation Check List . . . 29
System Overview and Operation . . . 30
Cab Identification - Top View . . . 30
Cab Identification - Seat Perspective . . . 31
Dash Controls Identification . . . 33
Control Panel Identification . . . 35
Hydrostatic and Throttle Control Identification . . . 36
Air Suspension Seat Adjustment . . . 37
Cab Pressurization . . . 38
Hydraulic System . . . 40
Hydraulic Tank . . . 40
Hydraulic Filters . . . 40
Hydraulic Wheel Motors . . . 40
Hydraulic Auxiliary Tandem Pump . . . 40
Tandem Hydrostatic Pump . . . 40
Electric/Hydraulic 8 Bank Solenoid Valve . . . 41
Hydraulic Indicating Lights (Diagnostic System) . . . 41
Cold Start Filter Bypass . . . 41
Booms . . . 42
To unfold booms . . . 43
To fold booms . . . 43
Axle Adjustment . . . 44
Rephase the Steering Cylinders . . . 44

MidWestTech | Case SPX3310 Patriot Sprayer Operator's Manual | Publication 87651684 Order the manual at mid-west-tech.com >

Spray System . . . 45
Liquid Pump . . . 45
Sparge Control . . . 46
Spray System Operation . . . 46
Nozzle Calibration . . . 48
Boom Shut-off . . . 49
Controller Settings, Case IH SCS 4600 . . . 50
PWM Valve Tuning Chart . . . 51
Product Tank . . . 52
Pumping Station . . . 52
Rinse Kit . . . 55
Chemical Eductor (Optional) . . . 56
Foam Marker . . . 57
Case IH Engine . . . 58
Component Locations . . . 58
Before Starting the Engine . . . 59
Run in Procedure . . . 59
Normal Starting Procedure . . . 60
Stopping the Engine . . . 60
Cold Temperature Operation . . . 61
Warming the Engine and Hydraulic Fluid . . . 61
Engine Coolant Heater . . . 62
Engine Starting In Cold Weather . . . 62
Parking & Emergency Brake Operation . . . 63
Ladder . . . 64
Road Travel . . . 64
Transporting a Vehicle . . . 65
Locking Booms . . . 65
Loading the Machine onto a Transport Trailer . . . 65
Unloading the Machine from a Transport Trailer . . . 65
Towing The Machine . . . 66
Traction Assist . . . 66
Options . . . 66
Active Suspension . . . 66
AIM Command (Optional) . . . 67
Learning to Operate the Machine . . . 71

Maintenance . . . 77
Lubricants and Capacities . . . 77
Engine . . . 77
Cooling System . . . 77
Fuel Tank . . . 77
Hydraulic System . . . 77
Hub Lubricant . . . 77
Quick Reference Maintenance Schedule . . . 77
Hourly Maintenance . . . 77
Recommended Break-In Maintenance . . . 78
Recommended Maintenance Schedule . . . 78
As Required Maintenance . . . 80
Periodic Maintenance . . . 80
Machine Maintenance . . . 80
Product Tank . . . 81
Cab Maintenance . . . 81

MidWestTech | Case SPX3310 Patriot Sprayer Operator's Manual | Publication 87651684 Order the manual at mid-west-tech.com >

Trailing Arm Pivot Area . . . 81
Fuel System . . . 82
Biodiesel Fuel . . . 82
Fuel Conditioner . . . 82
Engine Oil . . . 86
Radiator and Coolers . . . 88
Coolant . . . 88
Engine Air Filter . . . 91
Hydraulic System . . . 92
Spray System Recalibration . . . 97
Brake Operation . . . 97
Indicators, Switches and Lights . . . 97
Wheels and Tires . . . 98
Safety Equipment . . . 100
Boom Cylinders and Joints . . . 101
Boom Center Support . . . 101
Steering Knuckle . . . 102
Strut and Axle Assembly . . . 102
Battery . . . 103
Loose Bolts and Parts . . . 105
Cab Outside Air Filter . . . 105
Hub Lubricant . . . 106
Hydraulic Hoses and Electrical Wiring . . . 107
Engine Air Intake Hoses . . . 107
Engine Fan Belt Check and/or Replace . . . 107
A/C Compressor Belt Check and/or Replace . . . 107

As Required Maintenance . . . 108
Air Conditioning System . . . 108
Booms . . . 108
Boom Strainers . . . 109
Flow Meter . . . 109
Control Linkages - Hydrostatic Pump . . . 110
Push-Pull Cable . . . 110
Hydrostatic Pump . . . 111
Auxiliary Pump and Wheel Motors . . . 111
Hydraulic Pump or Motor Failure . . . 111

Machine Storage . . . 115
Storing the Machine . . . 115
Removing from Storage . . . 117

Troubleshooting . . . 121
Troubleshooting Procedures . . . 121
Theoretical Situations . . . 122
Hydraulic System . . . 122
Hydraulic Liquid Pump . . . 127
General Wiring System . . . 127
Cab Pressurization . . . 130
AIM Command (if equipped) . . . 131
Fuse Identification . . . 133
Relay Identification . . . 134

Appendix . . . 137
Product Specifications . . . 137
Service Record . . . 139

MidWestTech | Case SPX3310 Patriot Sprayer Operator's Manual | Publication 87651684 Order the manual at mid-west-tech.com >