NEW HOLLAND

EXCAVATOR

E135B TIER 3

PARTS CATALOG

ASN YH05-07078~

87659327 NA

Issued 01Jan08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland E135B Tier 3 Excavator Parts Catalog | Publication 87659327

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	00	FUEL FILTER & OIL FILTER ELEMENTS
02-01	01	UPPER FRAME ASSEMBLY, PAGE 1 OF 2
02-01	02	UPPER FRAME ASSEMBLY, PAGE 2 OF 2
02-02	01	COUNTERWEIGHT INSTALLATION (YY60C00056F1), PART 1 OF 2
02-02	02	COUNTERWEIGHT INSTALLATION (YY60C00056F1), PART 2 OF 2
02-03	00	COUNTERWEIGHT INSTALLATION (YY60C00065F1)
02-04	00	ENGINE ASSEMBLY
02-05	01	ENGINE INSTALLATION (YY02P00017F1), PAGE 1 OF 2
02-05	02	ENGINE INSTALLATION (YY02P00017F1), PAGE 2 OF 2
02-06	00	RADIATOR INSTALLATION (YY05P00028F1)
02-07	01	RADIATOR GROUP (YY05P00026F1), PAGE 1 OF 2
02-07	02	RADIATOR GROUP (YY05P00026F1), PAGE 2 OF 2
02-08	00	RADIATOR ASSEMBLY (YY05P00031F1)
02-09	00	AIR CLEANER ASSEMBLY (YY11P00009F1)
02-09-01	00	AIR CLEANER - COMPONENTS (YY11P00008F1)
02-10	00	MUFFLER ASSEMBLY (YY12P00010F1)
02-11	01	FUEL LINES (YY21P00010F1), PAGE 1 OF 2
02-11	02	FUEL LINES (YY21P00010F1), PAGE 2 OF 2
02-12	01	TANK INSTALLATION, FUEL (YY20P00037F1), PAGE 1 OF 2
02-12	02	TANK INSTALLATION, FUEL (YY20P00037F1), PAGE 2 OF 2
02-13	00	HYDRAULIC TANK ASSEMBLY (YY33H00049F1)
02-14	00	POWER TAKE OFF ASSEMBLY (YY30P00009F1)
02-15	00	SWING MOTOR INSTALLATION (YY32W00003F2)
02-15-01	00	SWING MOTOR ASSEMBLY (YY15V00021F1)
02-16	00	VALVE INSTALLATION (MAIN HYDRAULIC VALVE) (YY64H00129F1)
02-17	01	HYDRAULIC LINES, PUMP (YY30H00031F1), PAGE 1 OF 2
02-17	02	HYDRAULIC LINES, PUMP (YY30H00031F1), PAGE 2 OF 2
02-18	01	HYDRAULIC LINES, UPPER (YY03H00103F1), PAGE 1 OF 2
02-18	02	HYDRAULIC LINES, UPPER (YY03H00103F1), PAGE 2 OF 2
02-19	00	HYDRAULIC LINES, SWIVEL (YY19H00031F1)
02-20	01	HYDRAULIC LINES, RETURN (YY32H00026F1), PAGE 1 OF 3
02-20	02	HYDRAULIC LINES, RETURN (YY32H00026F1), PAGE 2 OF 3
02-20	03	HYDRAULIC LINES, RETURN (YY32H00026F1), PAGE 3 OF 3
02-21	01	CONTROLS, OPERATOR (YY03M00052F1), PAGE 1 OF 2
02-21	02	CONTROLS, OPERATOR (YY03M00052F1), PAGE 2 OF 2
02-22	00	CONTROL BOX ASSEMBLY (YB03M00036F1)
02-23	00	GRIP ASSEMBLY (YN03M01974F1)
02-24	00	RADIO INSTALLATION & SWITCH INSTALLATION (YN54E00010F1 & LV50E00001F1)
02-25	00	ARM REST & CLAMP ASSEMBLY (YN25M01183F1 & YN12P01163F1)
02-26	00	LEVER ASSEMBLY, PROPEL (YN50M00015F1)
02-27	01	CONTROL LINES, REMOTE, PAGE 1 OF 3
02-27	02	CONTROL LINES, REMOTE, PAGE 2 OF 3
02-27	03	CONTROL LINES, REMOTE, PAGE 3 OF 3
02-28	01	CONTROL LINES, REMOTE, PAGE 1 OF 3
02-28	02	CONTROL LINES, REMOTE, PAGE 2 OF 3
02-28	03	CONTROL LINES, REMOTE, PAGE 3 OF 3
02-29	01	CONTROL LINES, MAIN (YY06H00061F1), PAGE 1 OF 2
02-29	02	CONTROL LINES, MAIN (YY06H00061F1), PAGE 2 OF 2
02-30	01	CONTROL LINES, VALVE (YY64H00125F1), PAGE 1 OF 2
02-30	02	CONTROL LINES, VALVE (YY64H00125F1), PAGE 2 OF 2
02-31	00	CONTROL LINES, VALVE (YY64H00162F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-32	00	CONTROL LINES, PUMP (YY06H00041F1)
02-33	01	CONTROL LINES, PROPEL (YY62H00009F1 & YF64H00056F1), PAGE 1 OF 2
02-33	02	CONTROL LINES, PROPEL (YY62H00009F1 & YF64H00056F1), PAGE 2 OF 2
02-34	00	PLATE INSTALLATION, FLOOR (YY03M00046F1)
02-35	00	MIRROR INSTALLATION (FRONT) (YY52C00012F1)
02-36	00	MIRROR INSTALLATION (REAR) (YY52C00014F1)
02-37	00	CAB INSTALLATION (YY02C00024F1)
02-38	00	CAB INSULATION INSTALLATION (YY26C00001F1)
02-39	01	CAB ASSEMBLY (YY02C00026F1%KL), PAGE 1 OF 4
02-39	02	CAB ASSEMBLY (YY02C00026F1%KL), PAGE 2 OF 4
02-39	03	CAB ASSEMBLY (YY02C00026F1%KL), PAGE 3 OF 4
02-39	04	CAB ASSEMBLY (YY02C00026F1%KL), PAGE 4 OF 4
02-40	00	WINDOW ASSEMBLY, ROOF (YY02C01040F1%KL)
02-41	00	WINDOW ASSEMBLY, FRONT (YN50C00005F1)
02-42	00	DOOR ASSEMBLY, CAB (YB51C00004F1%KL)
02-43	00	SEAT INSTALLATION (YN25M00072F1)
02-43-01	01	SEAT, PNEUMATIC CUSHIONING HEATED - COMPONENTS (YN25M00068F1)
02-44	00	SEAT BELT ASSEMBLY (YN25M00053F1)
02-45	01	GUARD INSTALLATION (YY21C00093F1), PAGE 1 OF 4
02-45	02	GUARD INSTALLATION (YY21C00093F1), PAGE 2 OF 4
02-45	03	GUARD INSTALLATION (YY21C00093F1), PAGE 3 OF 4
02-45	04	GUARD INSTALLATION (YY21C00093F1), PAGE 4 OF 4
02-46	00	GUARD INSTALLATION, FRONT (YY21C00085F1)
02-47	00	GUARD ASSEMBLY, HANDRAIL (YY21C00095F1)
02-48	01	GUARD ASSEMBLY, RIGHT-HAND SIDE (YY21C00082F1), PAGE 1 OF 2
02-48	02	GUARD ASSEMBLY, RIGHT-HAND SIDE (YY21C00082F1), PAGE 2 OF 2
02-49	00	GUARD ASSEMBLY, BOOM BASE (YY21C00081F1)
02-50	01	GUARD ASSEMBLY, LEFT-HAND SIDE (YY21C00086F1), PAGE 1 OF 2
02-50	02	GUARD ASSEMBLY, LEFT-HAND SIDE (YY21C00086F1), PAGE 2 OF 2
02-51	00	GUARD ASSEMBLY, TOP (YY21C00061F1)
02-52	01	GUARD ASSEMBLY, REAR (YY21C00091F1), PAGE 1 OF 2
02-52	02	GUARD ASSEMBLY, REAR (YY21C00091F1), PAGE 2 OF 2
02-53	00	COVER ASSEMBLY, UNDER (YY24C00014F1)
02-54	01	PANEL ASSEMBLY, INSTRUMENT (YB17M00015F1), PAGE 1 OF 3
02-54	02	PANEL ASSEMBLY, INSTRUMENT (YB17M00015F1), PAGE 2 OF 3
02-54	03	PANEL ASSEMBLY, INSTRUMENT (YB17M00015F1), PAGE 3 OF 3
02-55	00	GAUGE ASSEMBLY, CLUSTER (YN59S00021F2)
02-56	00	CONTROLLER INSTALLATION (YY22E00112F1)
02-57	00	RELAY BOX ASSEMBLY (YY24E00008F1)
02-58	00	BATTERY INSTALLATION (YY72E00006F1)
02-59	01	CONDITIONER ASSEMBLY, AIR (YY20M00017F1), PAGE 1 OF 3
02-59	02	CONDITIONER ASSEMBLY, AIR (YY20M00017F1), PAGE 2 OF 3
02-59	03	CONDITIONER ASSEMBLY, AIR (YY20M00017F1), PAGE 3 OF 3
02-60	00	CONDITIONER ASSEMBLY, AIR (YN20M00113F1)
02-61	00	DRIER ASSEMBLY, AIR (YY96V00009F1)
02-62	00	COMPRESSOR ASSEMBLY, AIR (YX91V00001F1)
02-63	01	CONDITIONER ASSEMBLY, AIR (YN20M00107F2), PAGE 1 OF 2
02-63	02	CONDITIONER ASSEMBLY, AIR (YN20M00107F2), PAGE 2 OF 2
02-64	00	ELECTRICAL ASSEMBLY, UPPER (HORN, BATTERY RELAY) (YY03E00006F1)
02-65	00	LIGHT INSTALLATION (FRONT) (YY80E00008F1)
02-66	00	LIGHT ASSEMBLY (YT80S00002F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-67	00	TAIL LAMP ASSEMBLY (YY80E00013F1)
02-68	01	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 1 OF 11
02-68	02	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 2 OF 11
02-68	03	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 3 OF 11
02-68	04	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 4 OF 11
02-68	05	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 5 OF 11
02-68	06	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 6 OF 11
02-68	07	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 7 OF 11
02-68	08	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 8 OF 11
02-68	09	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 9 OF 11
02-68	10	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 10 OF 11
02-68	11	HARNESS ASSEMBLY, UPPER (YY13E00052F1), PAGE 11 OF 11
02-69	00	HARNESS ASSEMBLY, CAB (YB14E00018F1)
02-70	00	HARNESS ASSEMBLY, UPPER (FLOOR PLATE) (YY13E00041F1)
02-71	00	HARNESS ASSEMBLY, ENGINE (YY16E00005F1)
03-01	00	LOWER GROUP
03-02	00	SLEWING RING ASSEMBLY (YY40F00008F1)
03-03	00	IDLER ASSEMBLY, CRAWLER (YY52D00010F1)
03-04	00	IDLER ASSEMBLY (YY52D00007F1)
03-05	00	IDLER ADJUST ASSEMBLY (YY54D00003F1)
03-06	00	TRACK ROLLER ASSEMBLY (YY64D00028F1)
03-07	00	ROLLER ASSEMBLY, UPPER (YY64D00004F1)
03-08	00	SHOE ASSEMBLY (YY60D00029F1, F2, F3, F4 & F5)
03-09	01	HYDRAULIC LINES, LOWER (YY02H00054F1 & YY19H00030F1 & YY12H00004F1), PAGE 1 OF 2
03-09	02	HYDRAULIC LINES, LOWER (YY02H00054F1 & YY19H00030F1 & YY12H00004F1), PAGE 2 OF 2
03-10	00	STEP INSTALLATION (YN41C00006F1, F2 & F3)
03-11	00	PLATE ASSEMBLY (YY02F01300P1)
04-01	01	BOOM GROUP, 4.68M (15FT-4IN), PAGE 1 OF 2
04-01	02	BOOM GROUP, 4.68M (15FT-4IN), PAGE 2 OF 2
04-02	00	BOOM ASSEMBLY, 4.68M (15FT-4IN)
04-03	01	HYDRAULIC LINES, BOOM - 4.68M (15FT-4IN), PAGE 1 OF 2
04-03	02	HYDRAULIC LINES, BOOM - 4.68M (15FT-4IN), PAGE 2 OF 2
04-04	00	LIGHT INSTALLATION, BOOM
04-05	00	LIGHT ASSEMBLY (YW80S00001F1)
04-06	01	ARM GROUP, LONG 2.84M (9FT-4IN), PAGE 1 OF 2
04-06	02	ARM GROUP, LONG 2.84M (9FT-4IN), PAGE 2 OF 2
04-07	00	ARM ASSEMBLY, LONG 2.84M (9FT-4IN) (YY12B00379F1)
04-08	00	HYDRAULIC LINES, ARM 2.84M (9FT-4IN)
04-09	00	BUCKET INSTALLATION (LP61B00008F1)
05-01	00	TOOLS & ACCESSORIES (YY01T00015F3)
05-02	00	ELEMENT KIT (YY30T00004F3)
06-01	00	VALVE INSTALLATION (NIBBLER & BREAKER) (YY64H00130F1)
06-02	00	HYDRAULIC LINES, UPPER (NIBBLER & BREAKER) (YY03H00089F1 & YY03H00104F1)
06-03	00	CONTROLS, OPERATOR (NIBBLER & BREAKER) (YY55M00003F1)
06-04	00	CONTROL LINES, VALVE (NIBBLER & BREAKER) (YY64H00096F1)
06-05	00	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (YY68H00081F1 & YF64H00056F1)
06-06	00	HYDRAULIC LINES, BOOM (NIBBLER & BREAKER) 4.68M (15FT-4IN) (YY42H00166F1)

Order the manual at mid-west-tech.com >

CONTROLLER INSTALLATION (YY22E00112F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Controller Installation, YY22E00112F1
		{}			Controller Installation, YB22E00021F1, Incls. Refs. A1 - A14
A1		{YB22E01027P1}		1	Support
A3		YN50S00047P1		1	SWITCH, Toggle (Swing Parking Brake Release)
A4		YN22M01014P1		1	LABEL, Decal, Release Lock and Normal
A7		ZM73C08020		5	BOLT, M08x1.25x20mm (Incls. Washer)
A9		ZM61C06025		7	BOLT, M06x1.0x25mm (Incls. Washer & Lockwasher)
A10		ZM41C03008		4	BOLT, M03x0.5x08mm (Incls. Washer & Lockwasher)
A11		ZM61C04012		1	BOLT, M04x0.7x12mm (Incls. Washer & Lockwasher)
A12		YX50S00001F1		1	SWITCH, Toggle
A13		YV22E01002P1		1	LABEL, Decal, KPSS/Release
A14		LC22E01001D1		1	RESISTOR, 16ohm
		{}			Controller Installation, YY22E00087F1, Incls. Refs. B1 - B5
B1		{VA32F98-10115}		1	Controller -- Mitsubishi Engine Parts
B2		{YY22E01054P1}		1	Bracket
B3		{YY22E01056P1}		1	Bracket
B4		ZM61C06016		4	BOLT, M06x1.0x16mm (Incls. Washer & Lockwasher)
B5		ZM61C06025		4	BOLT, M06x1.0x25mm (Incls. Washer & Lockwasher)
		{}			Controller Assembly, YY22E00111F1, Incls. Refs. C1 & C2
C1		YN22E00214F1		1	CONTROL
C2		NA		1	NOT SERVICED, Software
		{}			Relay Box Assembly, YY24E00009F1, Incls. Refs. D1 & D2
D1		YY24E00008F1		1	FUSE BOX, Relay Box Assembly -- See Figure 02-56
D2		{YY73E01009P1}		1	Label
		{}			Flasher Relay Assembly, YN24E00017F1, Incls. Refs. E2 & E5

MidWestTech | New Holland E135B Tier 3 Excavator Parts Catalog | Publication 87659327 Order the manual at mid-west-tech.com >

HYDRAULIC LINES, ARM (NIBBLER & BREAKER) 2.84M (9FT-4IN) (YY43H00134F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Arm Hydraulic Lines (Nibbler & Breaker) 2.84M (9ft-4in), YY43H00134F1
1		YY43H01342P1		1	TUBE
2		YY43H01343P1		1	TUBE
3		ZX50H16165		1	HOSE, FLEXIBLE, 1650mm Long (64-31/32 in)
4		ZX50H12160		1	TUBE, Hose -- 1600mm Long (63 in)
5		YW43H01044P1		2	BRACKET
6		24100P1006F1		2	VALVE, Assembly, Stop -- Incls. Refs. 6-1 - 6-11
6-1		2436P230		1	BODY, VALVE
6-2		2436T304		1	VALVE
6-3		2418T8945D1		1	SPACER, ID 40 x OD 60 x Th 3.2mm
6-4		ZR16X04000		1	RING, Retainer -- ID 37 x OD 40 x Th 1.8mm
6-5		ZS23C06010		1	SCREW, M06x1.0x10mm
6-6		ZD11G04000		2	O-RING, ID 39.40 ± 0.37 x OD 45mm
6-7		ZD12G04000		1	O-RING, ID 39.40 ± 0.37 x OD 45mm
6-8		ZD75G04000		1	BACK-UP RING, ID 40 x OD 45 x Th 1.25mm
6-9		ZD12G03500		1	O-RING, ID 34.40 ± 0.33 x OD 40mm
6-10		ZD85G03500		1	RING, Back-Up -- ID 35 x OD 40 x Th 1.25mm
6-11		ZE82T04000		1	PLUG, 1/4" PT
7		HG23H12012G1		2	CONNECTOR, HYD., (Incls. O-Ring ZD12P02400)
		ZD12P02400		1	O-RING, (Part of HG23H12012G1), ID 23.70 ± 0.24 x OD 30mm, Not Shown
8		YN42H02357P1		4	CLAMP, Ø18.5x65x52mm
9		YN42H02363P1		4	CLAMP, Ø23x65x52mm
10		YN42H02319P1		2	BUSHING, ID 27.20 x OD 34 x 83mm Long
11		YN43H01524P1		2	BUSHING, ID 34 x OD 43 x 83mm Long
12		ZD12A01800		3	O-RING, ID 18.77 ± 0.12 x OD 22.33mm
13		ZD12A02100		1	O-RING, ID 23.52 ± 0.15 x OD 27.08mm
14		ZM73C12030		8	BOLT, M12x1.75x30mm (Incls. Washer)
15		ZM73C12045		4	BOLT, M12x1.75x45mm (Incls. Washer)
16		ZS18C08025		8	SCREW, M08x1.25x25mm
17		YN43H01151P1		8	WASHER, ID 8.5 x OD 23 x Th 4.5mm

MidWestTech | New Holland E135B Tier 3 Excavator Parts Catalog | Publication 87659327 Order the manual at mid-west-tech.com >

INTAKE MANIFOLD (AIR HEATER)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Intake Manifold (Air Heater)
1		VA32B6606200		1	HEATER, Air Assembly
2		VA3433004200		1	GASKET, Air Heater

MidWestTech | New Holland E135B Tier 3 Excavator Parts Catalog | Publication 87659327 Order the manual at mid-west-tech.com >