CASE

PROFESSIONAL PARTNER

PARTS CATALOG
VIBRATORY ROLLER

SV210
TIER 3

87659333 NA

Issued 01Aug 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	01	PICTORIAL INDEX / COMPLETE CAB / SMOOTH DRUM
01-02	01	PICTORIAL INDEX / COMPLETE CAB / PAD FOOT DRUM
01-03	01	PICTORIAL INDEX / PLATFORM CANOPY / SMOOTH DRUM
01-04	01	PICTORIAL INDEX / PLATFORM CANOPY / PAD FOOT DRUM
01-05	01	FILTERS, QUICK REFERENCE (GROUP 547) (ND138865)
02-01	01	ENGINE INSTALLATION (A) (GROUP 106) (ND138823)
02-02	01	ENGINE INSTALLATION (B) (GROUP 106) (ND138823)
02-03	01	RADIATOR INSTALLATION (GROUP 126) (ND138825)
02-04	01	DRAIN, RADIATOR (GROUP 129) (ND126744)
02-05	01	FAN INSTALLATION (GROUP 117) (ND138836)
02-07	01	GUARD, FAN (GROUP 591) (ND138841)
02-07	02	GUARD, FAN W/AC (GROUP 592) (ND138842)
02-08	01	ENGINE AIR FILTRATION AND EXHAUST (GROUP 136) (ND138824)
02-09	01	PRECLEANER (GROUP 190) (ND103113)
02-09	02	COVER, AIR INLET (GROUP 192) (ND138860)
03-01	01	CAP, FUEL TANK (GROUP 90) (ND107486)
03-02	01	SCREEN, FUEL FILL (GROUP 474) (ND126771)
03-03	01	LOCK, FUEL FILL (GROUP 92) (ND107501)
04-01	01	ELECTRICAL INSTALLATION (GROUP408) (ND139597)
04-02	01	DASHBOARD (GROUP 408-1) (ND139561)
04-03	01	WIRING, CAB (GROUP 410) (ND133648)
04-04	01	WIPER ASSY, REAR (GROUP 410-1) (ND029818)
04-05	01	WIPER, REAR (GROUP 410-1-11) (ND065202)
04-06	01	WIPER, FRONT (GROUP 410-10) (ND065207)
04-07	01	HEADLAMPS, CAB (GROUP 421) (ND139579)
04-07	02	HEADLAMPS, CANOPY (GROUP 411) (ND139592)
04-08	01	LAMPS, INDICATOR (GROUP 412) (ND140912)
04-11	01	METER, COMPACTION (GROUP 682) (ND124799)
04-12	01	BEACON, ROTATING (GROUP 413) (ND139619)
04-13	01	BACK UP ALARM (GROUP 415) (ND120305)
04-14	01	ELECTRICAL - TILTING, CAB AND ENGINE HOOD (GROUP 416) (ND139611)
04-15	01	SIGNAL DIODE, HOOD TILT (GROUP 417) (ND104573)
04-16	01	ELECTRICAL - ANTI-SLIP CONTROL (GROUP 418) (ND139599)
04-18	01	SHIELD, ALTERNATOR (GROUP 595) (ND138844)
04-19	01	BULBS AND FUSES, QUICK REFERENCE (GROUP 540) (ND138866)
04-20	01	ELECTRICAL PARTS (GROUP 414) (ND139601)
04-21	01	DISPLAY, ELECTRONIC (GROUP 428) (ND139623)
05-01	01	CONTROL, STEERING (GROUP 188) (ND126681)
05-02	01	STEERING, HYDRAULIC CIRCUIT (GROUP 336) (ND139577)
05-03	01	CYLINDER, STEERING (GROUP 372) (ND131849)
06-02	01	REDUCTION GEAR ASSY (GROUP 30-7) (ND101766)
06-03	01	DRUM DRIVE, FRONT (GROUP 31) (ND138827)
06-05	01	DRUM DRIVE, FRONT (GROUP 33) (ND138828)
06-06	01	DRIVE OF REAR WHEELS (GROUP 95) (ND104270)
06-07	01	REDUCTION GEAR ASSY (GROUP 95-1) (ND101398)
06-08	01	DRIVE OF REAR WHEELS (GROUP 98) (ND109308)
06-09	01	WHEELS, REAR (GROUP 43) (ND133166)
07-01	01	VALVE, HYDRAULIC LOCK (GROUP 317) (ND139575)
07-02	02	HYDRAULIC HIGH TRACTION ANTI-SLIP (GROUP 319) (ND139576)
07-02	03	VALVE, HYDRAULIC ANTI-SLIP (GROUP 318-HD) (ND139625)
07-02	04	VALVE, HYDRAULIC HIGH TRACTION (GROUP 318-HT) (ND139626)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-01	01	TANK, HYDRAULIC W/ ELECTRIC PUMP (GROUP 362) (ND121823)
08-02	01	HYDRAULIC LINES - DRUM VIBRATION (GROUP 320) (ND104262)
08-03	01	HYDRAULIC SYSTEM OF TRAVEL, DRUM (B) (GROUP 305) (ND139572)
08-04	01	HYDRAULIC LINES - FRONT DRUM DRIVE (GROUP 310) (ND139573)
08-06	01	HYDRAULIC LINES - FRONT DRUM DRIVE ATCH (GROUP 312) (ND139574)
08-07	01	HYDRAULIC SYSTEM OF TRAVEL, REAR (A) (GROUP 305) (ND139572)
08-08	01	HYDRAULICS - TILTING, HOOD AND PLATFORM (GROUP 380) (ND139578)
08-09	01	CYLINDER, HYDRAULIC PLATFORM LIFT (GROUP 381-3) (ND103132)
08-10	01	SEALS, HYDRAULIC PLATFORM LIFT CYLINDER (GROUP 381-3-14) (ND102044)
08-11	01	CYLINDER, HYDRAULIC HOOD LIFT RH (GROUP 381-1) (ND139595)
08-13	01	CYLINDER, HYDRAULIC HOOD LIFT LH (GROUP 381-2) (ND139596)
08-14	01	PUMP, HYDRAULIC HAND (GROUP 381-17 / 381-17-1 / 381-17-2) (ND067870 - ND102694 - ND102695)
08-15	01	LINES, HYDRAULIC DIAGNOSTIC (GROUP 390) (ND139580)
08-16	01	PUMP, HYDRAULIC (GROUP 122) (ND138838)
08-17	01	MOTOR, HYDRAULIC VIBRATION (GROUP 1-35) (ND104361)
08-18	01	DOZER BLADE, HYDRAULICS (GROUP 345) (ND110345)
09-01	01	FRAME, REAR (GROUP 73) (ND138821)
09-02	01	DRAWBAR, REAR (GROUP 476) (ND131910)
09-03	01	BATTERY HOLD DOWN & FUEL TANK PARTS (GROUP 473) (ND131884)
09-04	01	HOLDER, BATTERY (GROUP 473-2) (ND112489)
09-05	01	COVER, HYDRAULIC TANK (GROUP 468) (ND126701)
09-06	01	TOOL BOX (GROUP 493) (ND131879)
09-07	01	DOOR, TOOL BOX (GROUP 493-1) (ND131902)
09-08	01	COVER, HYDRAULIC PUMP (GROUP 471) (ND131858)
09-09	01	LOCK, ARTICULATION JOINT (GROUP 487) (ND131871)
09-10	01	DOOR, ACCESS RH (GROUP 484) (ND132354)
09-11	01	DOOR, ACCESS LH (GROUP 483) (ND132353)
09-12	01	STEP, UPPER LH (GROUP 464) (ND126699)
09-13	01	STEP, LH (GROUP 463) (ND132985)
09-14	01	STEP, RH (GROUP 462) (ND131873)
09-15	01	STEPS, PLATFORM ACCESS STEPS LH (GROUP 460) (ND131851)
09-16	01	STEPS, PLATFORM ACCESS RH (GROUP 461) (ND131852)
09-17	01	COVER, BATTERY (GROUP 211) (ND 138835)
09-18	01	COVER, REAR DRIVE MOTOR (GROUP 467) (ND131877)
09-19	01	COVER (GROUP 469) (ND126703)
09-20	01	PANEL, NOISE REDUCTION (GROUP 207) (ND131862)
09-22	01	ARTICULATED JOINT (GROUP 63) (ND132996)
09-23	01	HOLDER, HOSE (GROUP 67) (ND138864)
09-24	01	LOCK, LINKAGE JOINT (GROUP 68) (ND104289)
09-25	01	FRAME, DRUM (GROUP 53) (ND104895)
09-26	01	DRAWBAR, FRONT (GROUP 477) (ND131908)
09-27	01	SCRAPER, SMOOTH DRUM (GROUP 55) (ND104245)
09-28	01	SCRAPER, PAD FOOT DRUM (GROUP 57) (ND104877)
09-29	01	STEP, DRUM FRAME (GROUP 585) (ND111466)
09-30	01	VIBRATORY DRUM, SMOOTH (GROUP 1) (ND104240)
09-31	01	MOUNTING (GROUP 15) (ND109337)
09-32	01	MOUNTINGS (GROUP 16) (ND109336)
09-33	01	VIBRATORY DRUM, PAD FOOT (GROUP 10) (ND104879)
09-34	01	SEGMENTS, PAD FOOT ADAPTING (GROUP 560) (ND104268)
09-35	01	CLAMPS, FIXING (GROUP 560-2) (ND054304)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

09-36	01	VIBRATOR, DRUM (GROUP 21) (ND104252)
09-37	01	PLATFORM (GROUP 150) (ND001504)
09-38	01	INSULATOR, PLATFORM (GROUP 155) (ND012015)
09-39	01	PIPE, COMPLETE (GROUP 155-3) (ND108074)
09-40	01	FLOOR MAT, PLATFORM (GROUP 157) (ND104899)
09-41	01	FRAME, CAB (GROUP 160) (ND001404)
09-42	01	FOPS INSTALLATION, CAB (GROUP 161) (ND103115)
09-43	01	TRIM, CAB (GROUP 167) (ND104884)
09-44	01	GLASS & DOOR PARTS, CAB (GROUP 165-A) (ND001506-A)
09-45	01	AIR FILTRATION, CAB (GROUP 165-B) (ND001506-B)
09-46	01	COMPONENTS, CAB (GROUP 165-C) (ND001506-C)
09-47	01	PLATFORM CANOPY (GROUP 155 P) (ND106157)
09-48	01	SEAT ASSY (GROUP 158) (ND126721)
09-49	01	PANEL (GROUP 158-1) (ND115395)
09-50	01	LEVER, CONTROL (GROUP 408-41) (ND119476)
09-51	01	PLATFORM MOUNTING (GROUP 170) (ND104276)
09-52	01	COVER INSTALLATION, PLATFORM (GROUP 183) (ND011314)
09-53	01	COVER (GROUP 184) (ND108203)
09-54	01	ROPS INSTALLATION (GROUP 570) (ND104241)
09-55	01	ROPS - FOPS INSTALLATION (GROUP 572) (ND106351)
09-56	01	SEATBELT, RETRACTABLE (3") (GROUP 695) (ND107455)
09-57	01	DOZER BLADE (GROUP 551) (ND109307)
09-58	01	LOCK, DOZER BLADE (GROUP 557) (ND109313)
09-59	01	CONTROL, DOZER BLADE (GROUP 559) (ND109737)
09-60	01	VENTILATION, CAB (GROUP 169) (ND137760)
09-61	01	WATER HEATING (GROUP 600) (ND012032)
09-62	01	HEATING UNIT (GROUP 600-1) (ND126713)
09-64	01	HEATER CONNECTION, ENGINE (GROUP 606) (ND138839)
09-65	01	HOOD, ENGINE (GROUP 200) (ND135164)
09-66	01	HOOD, MOUNTING (GROUP 205) (ND138826)
09-67	01	FENDERS (GROUP 210) (ND137761)
09-68	01	MEDALLION, CASE (GROUP 512) (ND121986)
09-69	01	TIRE INFLATION (GROUP 635) (ND108210)
09-70	01	DECALS (GROUP 510 / 69 / 514) (ND104963) (ND111482) (ND137767)
09-71	01	AIR CONDITIONING (GROUP 618) (ND139629)

Order the manual at mid-west-tech.com >

PICTORIAL INDEX / PLATFORM CANOPY / PAD FOOT DRUM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
10		REF			INSTRUCTION, Vibrating Drum, Pad Foot
15		REF			INSTRUCTION, Rubber Mounting
16		REF			INSTRUCTION, Rubber Mountings
20		REF			INSTRUCTION, Vibrator, Drum - SV208
21		REF			INSTRUCTION, Vibrator, Drum - SV210
31		REF			INSTRUCTION, Drum Drive, Front
33		REF			INSTRUCTION, Drum Drive, Front - ATC / ATCH
43		REF			INSTRUCTION, Wheel Assy
52		REF			INSTRUCTION, Frame, Drum - SV208
53		REF			INSTRUCTION, Frame, Drum - SV210
57		REF			INSTRUCTION, Drum Scraper, Pad Foot
63		REF			INSTRUCTION, Articulation Joint
67		REF			INSTRUCTION, Hose Holder
68		REF			INSTRUCTION, Lock, Articulation Joint
73		REF			INSTRUCTION, Frame, Rear
90		REF			INSTRUCTION, Cap, Fuel Tank
92		REF			INSTRUCTION, Lock, Fuel
95		REF			INSTRUCTION, Drive Of Rear Wheels
98		REF			INSTRUCTION, Drive Of Rear Axle
106		REF			INSTRUCTION, Engine Mounting
117		REF			INSTRUCTION, Fan Mounting
126		REF			INSTRUCTION, Radiator Installation
129		REF			INSTRUCTION, Drain, Radiator
136		REF			INSTRUCTION, Engine - Air Filtration And Exhaust
155P		REF			INSTRUCTION, Platform, Canopy
158		REF			INSTRUCTION, Seat Assy
170		REF			INSTRUCTION, Platform Mounting
183		REF			INSTRUCTION, Cover
184		REF			INSTRUCTION, Cover Mounting
188		REF			INSTRUCTION, Steering Control
190		REF			INSTRUCTION, Precleaner, Air
192		REF			INSTRUCTION, Cover, Air Inlet
200		REF			INSTRUCTION, Hood, Engine
205		REF			INSTRUCTION, Hood, Mounting Hardware
211		REF			INSTRUCTION, Cover, Battery

MidWestTech | Case SV210 Tier 3 Vibratory Roller Parts Catalog | Publication 87659333NA Order the manual at mid-west-tech.com >

LOCK, DOZER BLADE (GROUP 557) (ND109313)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, LOCK, DOZER BLADE (ND109313) (GROUP 557)
1		ND030285		2	PIN
2		ND096261		2	TIE-ROD
6		REF		2	INSTRUCTION, CLAMPING (ND109344)
7		ND098233		2	PIN
11		ND021171		2	SCREW
15		ND021846		2	NUT
19		ND029308		2	WASHER
20		ND029247		2	WASHER
21		ND029275		2	WASHER
25		ND029392		2	PIN, SPLIT (COTTER)

MidWestTech | Case SV210 Tier 3 Vibratory Roller Parts Catalog | Publication 87659333NA Order the manual at mid-west-tech.com >

TIRE INFLATION (GROUP 635) (ND108210)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, TIRE INFLATION (ND108210) (GROUP 635)
1		72190890		1	HOSE, FLEXIBLE

MidWestTech | Case SV210 Tier 3 Vibratory Roller Parts Catalog | Publication 87659333NA Order the manual at mid-west-tech.com >