CASE

PARTS CATALOG

LOADER LANDSCAPER

570MXT
SERIES 3
TIER 3

87659341 NA

Issued 01May 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - MOUNTING
02-02	DEAERATION SYSTEM - MOUNTING
02-04	AIR CLEANER - AIR INTAKE PARTS
02-05	AIR CLEANER - PRECLEANER ASSY
02-06	MUFFLER - EXHAUST SYSTEM
02-07	ENGINE MOUNTING
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CRANKCASE COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CRANKCASE COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	EXHAUST MANIFOLD
02-21	CRANKSHAFT
02-22	CONNECTING ROD
02-23	PISTON - ENGINE
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE OIL DIPSTICK
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	HEAT EXCHANGER - ENGINE
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-41	ENGINE - LIFT HOOK
03-01	FUEL TANK AND LINES
03-02	CONTROLS - THROTTLE, HAND
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION PUMP
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	INJECTION EQUIPMENT - PIPING
03-08	FUEL FILTER
03-09	FUEL PUMP
03-10	PIPING - FUEL
03-11	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR

MidWestTech | Case 570MXT Series 3, Tier 3 Loader Landscaper Parts Catalog | Publicati... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY - CABLES
04-06	BATTERY, DUAL
04-06A	COLD START GRID HEATER
04-07	HARNESS, FRONT CONSOLE AND SWITCHES
04-08	HARNESS, SIDE CONSOLE - MOUNTING AND CONNECTIONS
04-09	HARNESS, SIDE CONSOLE - SWITCHES
04-10	INSTRUMENT PANEL, FRONT - COVERS
04-11	INSTRUMENT PANEL, SIDE - SWITCHES AND COVERS
04-12	INSTRUMENT CLUSTER
04-13	ELECTRICAL - LAMPS, ROPS CANOPY (STANDARD)
04-14	ELECTRICAL - LAMPS, SHORT ROPS CANOPY WITH MINIMAL ROOF
04-15	ELECTRICAL - LAMPS, ROPS CAB
04-16	LAMP ASSY - ROPS CANOPY MODELS
04-17	LAMP ASSY- ROPS CANOPY MODELS
04-18	LAMP ASSY - CAB MODELS
04-19	HORN - ALARM, BACKUP
04-20	BEACON, ROTATING
04-21	ANTENNA, RADIO - HARNESS, RADIO
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING
05-03	STEERING COLUMN
05-04	AXLE, FRONT (86990837) (2WD) - MOUNTING (IF USED)
05-05	AXLE, FRONT (86990837) (2WD) - HOUSING (IF USED)
05-06	AXLE, FRONT (86990837) (2WD) - HOUSING, SWIVEL (IF USED)
05-07	AXLE, FRONT (86990837) (2WD) - CYLINDER, STEERING (IF USED)
05-08	AXLE, FRONT (86990837) (2WD) - HUB AND BEARINGS (IF USED)
05-09	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE (4WD) - MOUNTING (IF USED)
06-02	AXLE, FRONT DRIVE (4WD) - HOUSING (IF USED)
06-03	AXLE, FRONT DRIVE (4WD) - HOUSING, SWIVEL (IF USED)
06-04	AXLE, FRONT DRIVE (4WD) - CYLINDER, STEERING (IF USED)
06-05	AXLE, FRONT DRIVE (4WD) - SHAFTS, AXLE (IF USED)
06-06	AXLE, FRONT DRIVE (4WD) - PLANETARY (IF USED)
06-07	AXLE, FRONT DRIVE (4WD) - DIFFERENTIAL (IF USED)
06-08	AXLE, FRONT DRIVE (4WD) - RING AND PINION (IF USED)
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION
06-12	TRANSMISSION - MOUNTING
06-13	TRANSMISSION ASSY - FILTER, OIL
06-14	TRANSMISSION ASSY (2WD) - HOUSING
06-15	TRANSMISSION ASSY (4WD) - HOUSING
06-16	TRANSMISSION ASSY - PUMP, OIL
06-17	TRANSMISSION ASSY - SHIFTER MECHANISM
06-18	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06-19	TRANSMISSION ASSY - SHAFT, INPUT
06-20	TRANSMISSION ASSY - SHAFT, SECONDARY
06-21	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06-22	TRANSMISSION ASSY - VALVE, CONTROL
06-23	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID

MidWestTech | Case 570MXT Series 3, Tier 3 Loader Landscaper Parts Catalog | Publicati... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-24	WHEELS, REAR - TIRES
06-24A	WHEEL WEIGHTS
06-25	AXLE, REAR DRIVE - MOUNTING
06-26	AXLE, REAR - DIFFERENTIAL LOCK
06-27	AXLE, REAR DRIVE - HOUSING
06-28	AXLE, REAR DRIVE - DIFFERENTIAL
06-29	AXLE, REAR DRIVE - RING AND PINION
06-30	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06-31	AXLE, REAR DRIVE - PLANETARY
06-32	DRIVE SHAFT, REAR AXLE
07-01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-02	AXLE, REAR DRIVE - BRAKE, PARKING
07-03	BRAKE - PEDALS
07-04	HYDRAULICS - BRAKE MASTER CYLINDER
07-05	CYLINDER ASSY - BRAKE MASTER
07-06	CONTROLS - BRAKE, PARKING
08-01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08-02	HYDRAULICS - CYLINDER, LOADER LIFT
08-03	HYDRAULICS - CYLINDER, LOADER BUCKET
08-04	HYDRAULICS - CYLINDER, LOADER CLAM
08-05	HYDRAULICS - CYLINDER, LOADER CLAM
08-06	HYDRAULICS - RIDE CONTROL
08-07	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08-08	HYDRAULICS - COUPLER, LOADER TOOL QUICK, AT LOADER LIFT FRAME
08-09	VALVE, COUPLER - LOADER TOOL
08-10	HYDRAULICS - HITCH, THREE POINT
08-11	HYDRAULICS - HITCH LOCK VALVE, THREE POINT
08-12	HYDRAULICS - VALVE, LASER CONTROL (MODELS WITH THREE POINT HITCH LOCK VALVE)
08-13	PUMP, EQUIPMENT HYDRAULIC
08-14	VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE)
08-15	VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE)
08-16	VALVE ASSY - HITCH, THREE POINT (FOUR SPOOL CONTROL VALVE)
08-17	VALVE ASSY - HITCH, THREE POINT (FIVE SPOOL CONTROL VALVE)
08-18	VALVE SECTION - HITCH INLET
08-19	VALVE SECTION - HITCH LIFT
08-20	VALVE SECTION - HITCH LIFT
08-21	VALVE SECTION - HITCH PITCH, TILT AND IMPLEMENT
08-22	VALVE, LOCK - HITCH, THREE POINT
08-23	ACCUMULATOR ASSY - RIDE CONTROL
08-24	FILTER ASSY, OIL
08-25	CYLINDER ASSY - LOADER LIFT
08-26	CYLINDER ASSY - LOADER BUCKET
08-27	CYLINDER ASSY - LOADER CLAM
08-28	CYLINDER ASSY - HITCH LIFT, THREE POINT
08-29	CYLINDER ASSY - HITCH TILT, THREE POINT
08-30	CYLINDER ASSY - HITCH PITCH, THREE POINT
09-01	CONTROLS - LOADER LIFT AND BUCKET
09-02	CONTROLS - LOADER CLAM

MidWestTech | Case 570MXT Series 3, Tier 3 Loader Landscaper Parts Catalog | Publicati... Order the manual at mid-west-tech.com >