NEW HOLLAND

TRACTOR LOADER

U80B TIER 3

PARTS CATALOG

87659342 NA

Issued 01July 08

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland U80B Tier 3 Tractor Loader Parts Catalog | Publication 87659342

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - MOUNTING
02-02	DEAERATION SYSTEM - MOUNTING
02-04	AIR CLEANER - AIR INTAKE PARTS
02-05	AIR CLEANER ASSY
02-06	MUFFLER - EXHAUST SYSTEM
02-07	ENGINE MOUNTING
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CRANKCASE COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CRANKCASE COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	EXHAUST MANIFOLD
02-21	CRANKSHAFT
02-22	CONNECTING ROD
02-23	PISTON - ENGINE
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE OIL DIPSTICK
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	HEAT EXCHANGER - ENGINE
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-41	ENGINE - LIFT HOOK
03-01	FUEL LINES, RESERVOIR - FILTER, IN-LINE FUEL
03-02	CONTROLS - THROTTLE, HAND
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION PUMP
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	INJECTION EQUIPMENT - PIPING
03-08	FUEL FILTER
03-09	FUEL PUMP
03-10	PIPING - FUEL
03-11	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY

MidWestTech | New Holland U80B Tier 3 Tractor Loader Parts Catalog | Publication 87659... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY - CABLES AND CUTOFF SWITCH
04-06	BATTERY, DUAL
04-06A	COLD START GRID HEATER
04-07	HARNESS, FRONT CONSOLE - SWITCHES
04-08	HARNESS, SIDE CONSOLE - MOUNTING AND CONNECTIONS
04-09	HARNESS, SIDE CONSOLE - SWITCHES
04-10	INSTRUMENT PANEL, FRONT - COVERS
04-11	INSTRUMENT PANEL, SIDE - SWITCHES AND COVERS
04-12	INSTRUMENT CLUSTER
04-13	ELECTRICAL - LAMPS, ROPS CANOPY
04-14	ELECTRICAL - LAMPS, ROPS CAB
04-15	LAMP ASSY - CAB MODELS
04-16	HORN - ALARM, BACKUP
04-17	BEACON, ROTATING
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING
05-03	STEERING COLUMN
05-04	AXLE, FRONT (2WD) - MOUNTING
05-05	AXLE, FRONT (2WD) - HOUSING
05-06	AXLE, FRONT (2WD) - HOUSING, SWIVEL
05-07	AXLE, FRONT (2WD) - CYLINDER, STEERING
05-08	AXLE, FRONT (2WD) - HUB AND BEARINGS
05-09	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE (4WD) - MOUNTING
06-02	AXLE, FRONT DRIVE (4WD) - HOUSING
06-03	AXLE, FRONT DRIVE (4WD) - HOUSING, SWIVEL
06-04	AXLE, FRONT DRIVE (4WD) - CYLINDER, STEERING
06-05	AXLE, FRONT DRIVE (4WD) - SHAFTS, AXLE
06-06	AXLE, FRONT DRIVE (4WD) - PLANETARY
06-07	AXLE, FRONT DRIVE (4WD) - DIFFERENTIAL
06-08	AXLE, FRONT DRIVE (4WD) - RING AND PINION
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION
06-11	TRANSMISSION - MOUNTING
06-12	TRANSMISSION ASSY - FILTER, OIL
06-13	TRANSMISSION ASSY (2WD) - HOUSING
06-14	TRANSMISSION ASSY (4WD) - HOUSING
06-15	TRANSMISSION ASSY - PUMP, OIL
06-16	TRANSMISSION ASSY - SHIFTER MECHANISM
06-17	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06-18	TRANSMISSION ASSY - SHAFT, INPUT
06-19	TRANSMISSION ASSY - SHAFT, SECONDARY
06-20	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06-21	TRANSMISSION ASSY - VALVE, CONTROL
06-22	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID
06-23	WHEELS, REAR - TIRES
06-23A	WHEEL WEIGHTS
06-24	AXLE, REAR DRIVE - MOUNTING
06-25	AXLE, REAR - DIFFERENTIAL LOCK

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-26	AXLE, REAR DRIVE - HOUSING
06-27	AXLE, REAR DRIVE - DIFFERENTIAL
06-28	AXLE, REAR DRIVE - RING AND PINION
06-29	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06-30	AXLE, REAR DRIVE - PLANETARY
06-31	DRIVE SHAFT, REAR AXLE
07-01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-02	AXLE, REAR DRIVE - BRAKE, PARKING
07-03	BRAKE - PEDALS
07-04	HYDRAULICS - BRAKE MASTER CYLINDER
07-05	CYLINDER ASSY - BRAKE MASTER
07-06	CONTROLS - BRAKE, PARKING
08-01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08-02	HYDRAULICS - CYLINDER, LOADER LIFT
08-03	HYDRAULICS - CYLINDER, LOADER BUCKET
08-04	HYDRAULICS - CYLINDER, LOADER CLAM
08-05	HYDRAULICS - CYLINDER, LOADER CLAM
08-06	HYDRAULICS - RIDE CONTROL
08-07	HYDRAULICS - COUPLER, LOADER TOOL QUICK - AT SOLENOID VALVE
08-07A	HYDRAULICS - COUPLER, LOADER TOOL QUICK - CONTROL VALVE TO FILTER
08-08	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08-09	VALVE, COUPLER (87435909) - LOADER TOOL
08-10	HYDRAULICS - HITCH, THREE POINT
08-11	HYDRAULICS - HITCH LOCK VALVE, THREE POINT
08-12	HYDRAULICS - VALVE, LASER CONTROL (MODELS WITH THREE POINT HITCH LOCK VALVE)
08-13	PUMP, EQUIPMENT HYDRAULIC
08-14	VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE)
08-15	VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - WITH BUILT-IN PRIORITY VALVE)
08-16	VALVE ASSY - HITCH, THREE POINT (FOUR SPOOL CONTROL VALVE)
08-17	VALVE ASSY - HITCH, THREE POINT (FIVE SPOOL CONTROL VALVE)
08-18	VALVE SECTION - HITCH INLET
08-19	VALVE SECTION - HITCH LIFT
08-20	VALVE SECTION - HITCH LIFT
08-21	VALVE SECTION - HITCH PITCH, TILT AND IMPLEMENT
08-22	VALVE, LOCK - HITCH, THREE POINT
08-23	ACCUMULATOR ASSY - RIDE CONTROL
08-24	FILTER ASSY, OIL
08-25	CYLINDER ASSY - LOADER LIFT
08-26	CYLINDER ASSY- LOADER BUCKET
08-27	CYLINDER ASSY - LOADER CLAM
08-28	CYLINDER ASSY - HITCH LIFT, THREE POINT
08-29	CYLINDER ASSY - HITCH TILT, THREE POINT
08-30	CYLINDER ASSY - HITCH PITCH, THREE POINT
09-01	CONTROLS - LOADER LIFT AND BUCKET
09-02	CONTROLS - LOADER CLAM
09-03	CONTROLS - LOADER SELF-LEVELING
09-04	FRAME - LOADER LIFT
09-05	FRAME - LOADER LINKAGE

Order the manual at mid-west-tech.com >

CYLINDER BLOCK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		4894218		4	SCREW
3		2852689		1	SWITCH, PRESSURE
4		4899009		1	PLUG, M10 x 1; Incl. Ref 5
5		4899072		1	O-RING
6		4895392		2	PLUG, 18 x 1.5; Incl. Ref 7
7		4895393		1	O-RING
8		4895049		2	DOWEL
9		4895180		8	TAPPET
10		2852202		4	NOZZLE, LUB. OIL JET, Incl. Ref 1
11		REF		1	INSTRUCTION, PISTON; See Figure 02-23
12		REF		1	INSTRUCTION, CAMSHAFT; See Figure 02-28
14		4895623		1	PLUG
15		4895625		1	O-RING

MidWestTech | New Holland U80B Tier 3 Tractor Loader Parts Catalog | Publication 87659... Order the manual at mid-west-tech.com >

BUCKET, LOADER CLAM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF		1	INSTRUCTION, 87455462 Bucket; 2083 mm (82 in), Includes 86981877, 175156A1, Ref 1 - 28, With Hydraulics, Also Includes Figure 08-05, Ref 1 - 29, Order Through Parts Marketing
		86981877		1	BUCKET, 4 IN 1, 2083 mm (82 in), Includes 411668A1, 175156A1, (2) 86981766, Ref 1 - 14, Without Hydraulics, Order Through Parts Marketing
		411668A1		1	BUCKET, Includes 175156A1, Ref 1 - 6, 8 - 14
		175156A1		1	SHELL, Incl. Ref 1, 2
1		NSS		1	NOT SERVICED SEPARATELY, Clam Assy
2		D31140		4	BUSHING
3		142300A1		2	BLADE, HALF
4		86624951		20	BOLT, CARRIAGE, 3/4"-10 x 2", G8
5		86518194		20	NUT, 3/4"-10, G8
6		86624958		2	BOLT, Hex Flg, M10 x 110, 8.8
7		86981766		2	PIN, PIVOT, 101.6 mm lg
8		412141		2	NUT, LOCK, M10 x 1.5, Cl 8
9		80710		2	NIPPLE, LUBE, 1/8"-27 x .66 lg
		376286A2		1	BUCKET, BLADE; Incl. Ref 10, 11
10		NSS		1	NOT SERVICED SEPARATELY, Blade Assy, Dozer
11		D129264		8	BUSHING
12		121920A1		1	EDGE
13		86624957		10	BOLT, CARRIAGE, 5/8"-11 x 2", G8, Full Thd
14		86625067		10	NUT, 5/8"-11, G8
15		86981765		2	PIN
16		120074		2	BOLT, Hex, M10 x 90, 8.8
17		86624176		2	WASHER, M10 x 20 x 2
18		412141		2	NUT, LOCK, M10 x 1.5, Cl 8
19		86981764		2	PIN
20		120073		2	BOLT, Hex, M10 x 80, 8.8
21		86624176		2	WASHER, M10 x 20 x 2
22		412141		2	NUT, LOCK, M10 x 1.5, Cl 8
23		86982720		1	DECAL, 0-2-4, Clam Bucket Opening Indicator
24		86981762		1	GUARD, Pilot Operated Check Valve
25		120070		2	BOLT, Hex, M10 x 60, 8.8

MidWestTech | New Holland U80B Tier 3 Tractor Loader Parts Catalog | Publication 87659... Order the manual at mid-west-tech.com >

CAB - AIR CONDITIONING, CONDENSER, RECEIVER-DRIER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87479017		1	HOSE ASSY., 3150 mm, Receiver Drier to Cab; Incl. Ref 2
2		128483A1		2	O-RING, 5/16 ID x 1/16
3		191704A1		1	LOOM, 460 mm (18-1/8 in)
4		86984155		1	RECEIVER-DRYER
5		214-1464		2	CLAMP, HOSE, #64, 3.56/4.50 Type F Worm
6		87471549		1	HOSE ASSY., 436 mm, Condenser to Drier; Incl. Ref 7 - 9
7		128483A1		3	O-RING, 5/16 ID x 1/16
8		1250594C1		1	CORE, Valve, High Pressure Switch
9		122081A1		1	FITTING, Switch
10		232948A1		1	SWITCH, PRESSURE, High Pressure
11		L18337		10	STRAP, CABLE, 9.95"-12.1" lg
12		(87590156)		1	1350 mm; Compressor to Condenser; Incl. Ref 13 - 17
13		128484A1		1	O-RING, 7/16 D x 1/16
14		128485A1		1	O-RING, 9/16 ID x 1/16
15		1999926C1		1	FITTING, PIPE
16		1250594C1		1	CORE, Valve
17		122554A1		1	CAP, Sealing Cap
18		(87726951)		1	Guard, 1200 mm (47-1/4 in)
19		87430122		1	COMPRESSOR, AIRCOND., Component Parts Not Serviced Separately, See Figure 09-66 for Mounting
20		87479024		1	HOSE ASSY., 2800 mm, Cab to Compressor; Incl. Ref 21 - 24
21		128485A1		2	O-RING, 9/16 ID x 1/16
22		1999927C1		1	FITTING, PIPE
23		1250594C1		1	CORE, Valve
24		122553A1		1	CAP, Sealing
26		87546291		1	CONDENSER
27		614-8020		6	BOLT, Hex, M8 x 20, 8.8
28		895-15008		2	WASHER, M8 x 20 x 1.6
29		833-40408		2	NUT, M8, U
30		(87726950)		1	Guard, 1200 mm (47-1/4 in)
31		(87740948)		1	Bracket, Pivot
32		(87740950)		1	Bracket, Supporting

MidWestTech | New Holland U80B Tier 3 Tractor Loader Parts Catalog | Publication 87659... Order the manual at mid-west-tech.com >