CASE

PROFESSIONAL PARTNER

PARTS CATALOG
WHEEL LOADER

521E
TIER 3

87659892 EN-US

Replaces 87519730 NA

Issued 01Feb 03
Revised 01Feb 09

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	DIA
02-01	MOUNTING, ENGINE
02-02	RADIATOR - HOSES AND TUBES
02-03	COOLER, CHARGE AIR
02-04	COOLER, CHARGE AIR - HOSES AND TUBES
02-05	FAN DRIVE
02-06	AIR CLEANER - AIR INTAKE PARTS
02-06A	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-08A	MUFFLER - EXHAUST SYSTEM - ASPIRATOR
02-09	OIL FILL, ENGINE
02-10	OIL PUMP - ENGINE
02-11	OIL FILTER - ENGINE
02-12	OIL FILTER AND COOLER
02-13	OIL PUMP, PAN
02-14	OIL PUMP, PAN - DRAIN LINE - COVER
02-15	BREATHER - ENGINE
02-16	TURBOCHARGER - DRAIN LINE
02-17	TURBOCHARGER
02-18	WATER PUMP
02-19	WATER PUMP - TENSIONER ASSY
02-20	CYLINDER BLOCK
02-21	CYLINDER BLOCK - PLUG ASSY
02-23	CYLINDER HEAD
02-24	CYLINDER HEAD - ASSEMBLY
02-24A	PIPING - ENGINE COOLING SYSTEM
02-25	CYLINDER HEAD - COVERS
02-26	CRANKSHAFT
02-27	CRANKSHAFT - PULLEY
02-28	DYNAMIC BALANCER, GEARS & SHAFTS
02-28A	DYNAMIC BALANCER, GEARS & SHAFTS
02-29	FLYWHEEL HOUSING
02-29A	FLYWHEEL - ENGINE
02-30	GEAR COVER - REAR HOUSING
02-31	GEAR COVER - PLATE
02-32	FRONT GEAR COVER
02-33	ROCKER ARMS
02-33A	ROCKER ARMS - ASSEMBLY
02-34	CAMSHAFT
02-35	PISTONS
02-36	PISTONS - CONNECTING ROD
02-37	INTAKE MANIFOLD
02-38	EXHAUST MANIFOLD
02-39	COOLING SYSTEM - ENGINE
02-40	THERMOSTAT - ENGINE COOLING SYSTEM
02-41	ENGINE - LIFT HOOKS
02-42	ENGINE - BLOCK HEATER
03-01	FUEL LINES
03-02	FILTER, FUEL - WATER SEPARATOR
03-03	FILTER, FUEL
03-04	FUEL TANK FILLER - SENDER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-04A	FUEL TANK - BREATHER
03-05	FUEL INJECTION PUMP
03-06	FUEL INJECTION SYSTEM
03-07	FUEL INJECTION SYSTEM - INJECTOR
03-08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03-09	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03-10	FUEL INJECTION SYSTEM - HARNESS, ENGINE
03-11	FUEL INJECTION SYSTEM - DRAIN LINE
04-01	STARTER
04-02	ALTERNATOR - MOUNTING
04-02A	ALTERNATOR - BELT
04-03	HARNESS, FRONT - Z-BAR
04-03A	HARNESS, FRONT - XT
04-04	HARNESS - PANEL, CONTROL - CAB
04-05	HARNESS - ENGINE AND REAR CHASSIS
04-06	HARNESS, ENGINE - THROTTLE CONTROL
04-07	HARNESS, ENGINE - FUSES AND RELAYS
04-08	HARNESS - ROOF - CAB/CANOPY
04-09	HARNESS, HOOD - ALARM, BACKUP
04-10	HARNESS, TRANSMISSION
04-11	HARNESS - GRID HEATER
04-11A	GRID HEATER
04-12	HARNESS - JOYSTICK STEERING
04-13	PANEL, CONTROL - SWITCHES
04-14	PANEL, CONTROL - FUSE AND RELAY MOUNTING
04-15	CAB - FUSES AND RELAYS
04-16	ELECTRICAL - TRANSMISSION CONTROL
04-17	ELECTRICAL - STEERING, AUXILIARY
04-18	MOUNTING - LAMPS, FRONT
04-19	LAMP ASSY - LAMPS, FRONT
04-20	MOUNTING - LAMPS, REAR COMBINATION
04-21	CAB/CANOPY - WORK LAMPS
04-21A	WORK LAMPS
04-22	BEACON ASSY, ROTATING - MOUNTING
04-22A	ROTATING BEACON COMPONENTS
04-23	CAB - WIPER, FRONT
04-23A	CAB - WIPER, REAR
04-24	RADIO - 12 VOLT
04-24A	RADIO - 12 VOLT INSTALLATION
04-25	BATTERY MOUNTING
04-26	BATTERY - CABLES
04-27	LICENSE PLATE LIGHT
04-28	WINDSHIELD WASHER MOUNTING
04-29	HORN, FRONT
05-01	CAB/CANOPY - STEERING WHEEL
05-02	CAB/CANOPY - STEERING COLUMN (76303625)
05-02A	CAB/CANOPY - STEERING COLUMN (87497543)
05-03	CAB - STEERING COLUMN - ACCESSORY
05-04	CAB - STEERING COLUMN - COVERS, SWITCHES
05-05	CANOPY - STEERING COLUMN - ACCESSORY
05-06	CANOPY - STEERING COLUMN - COVERS, SWITCHES

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-07	STEERING - HYDRAULICS
05-08	STEERING - HYDRAULICS - AUXILIARY
05-09	STEERING - HYDRAULICS - CYLINDER
05-10	JOYSTICK STEERING - JOYSTICK CONTROL AND HARNESS
05-11	JOYSTICK STEERING - ARMREST, JOYSTICK CONTROL
05-12	JOYSTICK STEERING - HYDRAULICS
05-13	JOYSTICK STEERING - HYDRAULICS - AUXILIARY
05-14	CYLINDER ASSY - STEERING
05-15	PUMP - STEERING, AUXILIARY
05-16	VALVE ASSY - JOYSTICK STEERING
05-17	VALVE ASSY - JOYSTICK STEERING, PVFC
05-18	VALVE ASSY - STEERING CONTROL
05-19	VALVE ASSY - STEERING, AUXILIARY
06-01	MOUNTING - TRANSMISSION - TRANSMISSION FILL TUBE
06-02	HYDRAULICS - TRANSMISSION
06-03	TRANSMISSION - FILTER, OIL AND FILLER COVER
06-04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT
06-05	TRANSMISSION - INPUT SHAFT
06-06	TRANSMISSION ASSY - HOUSING
06-07	TRANSMISSION ASSY - HOUSING TUBES
06-08	TRANSMISSION - CLUTCH ASSY, FIRST
06-09	TRANSMISSION - CLUTCH ASSY, SECOND
06-10	TRANSMISSION - CLUTCH ASSY, THIRD
06-11	TRANSMISSION - CLUTCH ASSY, FOURTH
06-12	TRANSMISSION - CLUTCH ASSY, FORWARD
06-13	TRANSMISSION - CLUTCH ASSY, REVERSE
06-14	TRANSMISSION - SHAFT, OUTPUT
06-15	TRANSMISSION - POWER TAKE OFF
06-16	TRANSMISSION - VALVE PLATES
06-17	TRANSMISSION - VALVE, CONTROL
06-18	TRANSMISSION - VALVE, CONTROL
06-19	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP
06-20	TRANSMISSION - SENSOR, SPEED AND PUMP COVER
06-21	AXLE, REAR - STOP
06-22	AXLE, FRONT - MOUNTING
06-22A	AXLE, FRONT - HOUSING
06-22B	AXLE, FRONT - DIFFERENTIAL CARRIER
06-22C	AXLE, FRONT - DIFFERENTIAL
06-22D	AXLE, FRONT - BRAKE
06-22E	AXLE, FRONT - HUB, PLANETARY
06-23	AXLE, REAR - MOUNTING
06-23A	AXLE, REAR - HOUSING
06-23B	AXLE, REAR - DIFFERENTIAL CARRIER
06-23C	AXLE, REAR - DIFFERENTIAL
06-23D	AXLE, REAR - BRAKE
06-23E	AXLE, REAR - HUB, PLANETARY
06-24	DRIVE SHAFT MOUNTING
06-25	DRIVE SHAFT, FRONT
06-26	DRIVE SHAFT, CENTER
06-27	DRIVE SHAFT, REAR
06-28	DRIVE SHAFT, ENGINE

Order the manual at mid-west-tech.com >