CASE

PROFESSIONAL PARTNER

PARTS CATALOG
WHEEL LOADER

721E
TIER 3

87659894

Issued -1Feb 09

MidWestTech | Case 721E Tier 3 Wheel Loader Parts Catalog | Publication 87659894

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	DIA
02-01	MOUNTING, ENGINE
02-02	RADIATOR - MOUNTING
02-03	FAN DRIVE
02-04	COOLANT RECOVERY SYSTEM
02-05	AIR CLEANER - AIR INTAKE PARTS
02-05A	AIR CLEANER - AIR INTAKE PARTS - COMMODITY KING
02-06	AIR CLEANER ASSY
02-07	MUFFLER - EXHAUST AND INTAKE
02-08	ENGINE
02-09	OIL FILL, ENGINE
02-10	OIL PUMP - ENGINE
02-11	OIL FILTER - ENGINE
02-12	OIL FILTER AND COOLER
02-13	OIL PUMP, PAN
02-14	OIL PUMP, PAN - DRAIN LINE
02-15	BREATHER - ENGINE
02-16	TURBOCHARGER SYSTEM
02-17	TURBOCHARGER
02-18	WATER PUMP
02-19	WATER PUMP - CONTROL
02-20	CYLINDER BLOCK
02-21	CYLINDER BLOCK - PLUG ASSY
02-22	CYLINDER BLOCK
02-23	FLYWHEEL HOUSING
02-24	GEAR COVER - REAR HOUSING
02-25	FRONT GEAR COVER
02-26	GEAR COVER - PLATE
02-27	CYLINDER HEAD - COVERS
02-28	ROCKER SHAFT
02-29	CYLINDER HEAD
02-30	INTAKE MANIFOLD
02-31	MANIFOLD - EXHAUST
02-32	CAMSHAFT
02-33	CRANKSHAFT
02-34	CRANKSHAFT - PULLEY
02-35	FLYWHEEL - ENGINE
02-36	CONNECTING ROD
02-37	PISTONS
02-38	COOLING SYSTEM - ENGINE
02-39	THERMOSTAT - ENGINE COOLING SYSTEM
02-40	TURBOCHARGER DRAIN LINE
02-41	ENGINE - LIFT HOOKS
02-42	ENGINE - BLOCK HEATER
03-01	FUEL LINES - FILTER, IN-LINE FUEL
03-02	FILTER, FUEL - WATER SEPARATOR
03-03	FILTER, FUEL
03-04	FUEL TANK FILLER - SENDER
03-05	FUEL INJECTION PUMP
03-06	FUEL INJECTION SYSTEM
03-07	FUEL INJECTION SYSTEM - INJECTOR

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03-09	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03-10	FUEL INJECTION SYSTEM - HARNESS, ENGINE
03-11	FUEL INJECTION SYSTEM - DRAIN LINE
04-01	STARTER
04-02	ALTERNATOR - MOUNTING WITHOUT AIR CONDITIONING
04-03	ALTERNATOR - MOUNTING WITH AIR CONDITIONING
04-04	ALTERNATOR ASSY
04-05	BATTERY
04-05A	BATTERY - HEAVY DUTY
04-06	BATTERY - CABLES
04-07	HARNESS - PANEL, CONTROL
04-07A	PANEL, CONTROL
04-07B	PANEL, CONTROL - RELAY
04-07C	PANEL, CONTROL - SWITCH
04-07D	CAB - FUSES AND RELAYS
04-07E	HARNESS - ROOF - CAB/CANOPY
04-07F	PANEL, CONTROL - FUSE AND RELAY MOUNTING - IF USED
04-07G	ELECTRICAL - TRANSMISSION CONTROL - OPTIONS
04-08	HARNESS - ENGINE
04-09	HARNESS - ENGINE - GRID HEATER
04-10	HARNESS, REAR CHASSIS - HARNESS, THROTTLE CONTROL
04-11	HARNESS, REAR - RELAY PANEL
04-12	HARNESS, FRONT
04-13	HARNESS, FRONT
04-14	HARNESS, HOOD - BACKUP ALARM
04-15	HARNESS - TRANSMISSION
04-16	HARNESS - JOYSTICK STEERING
04-17	HARNESS - STEERING, AUXILIARY
04-18	MOUNTING - LAMP, FRONT
04-18A	LAMP ASSY - LAMP, FRONT
04-19	LAMP ASSY- REAR LIGHTS AND MOUNTING
04-19A	LAMP ASSY- REAR LIGHTS AND MOUNTING - LCD
04-20	LAMP ASSY - LAMPS, REAR COMBINATION (OPTIONAL GUARD)
04-21	CAB/CANOPY - WORK LAMPS
04-21A	WORK LAMPS
04-22	LICENSE PLATE LIGHT
04-23	BEACON ASSY, ROTATING - MOUNTING
04-23A	ROTATING BEACON COMPONENTS
04-24	WINDSHIELD WASHER MOUNTING
04-25	CAB - WIPER, FRONT
04-26	CAB - WIPER, REAR
04-27	RADIO - 12 VOLT
04-28	RADIO - 12 VOLT INSTALLATION
05-01	CAB/CANOPY - STEERING WHEEL
05-02	CAB/CANOPY - STEERING COLUMN (76303625)
05-02A	CAB/CANOPY - STEERING COLUMN (87497543)
05-03	CAB - STEERING COLUMN - ACCESSORY
05-04	CAB - STEERING COLUMN - COVERS, SWITCHES
05-05	CANOPY - STEERING COLUMN - ACCESSORY
05-06	CANOPY - STEERING COLUMN - COVERS, SWITCHES

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-07	STEERING - HYDRAULICS
05-08	STEERING - HYDRAULICS
05-09	STEERING - HYDRAULICS - AUXILIARY
05-10	STEERING, STANDARD - HYDRAULICS - CYLINDER
05-11	JOYSTICK STEERING - JOYSTICK CONTROL AND HARNESS
05-12	JOYSTICK STEERING - ARMREST, JOYSTICK CONTROL
05-13	JOYSTICK STEERING - HYDRAULICS
05-14	JOYSTICK STEERING - HYDRAULICS - AUXILIARY
05-15	CYLINDER ASSY - STEERING
05-16	PUMP - STEERING, AUXILIARY
05-17	VALVE ASSY - JOYSTICK STEERING
05-18	VALVE ASSY - JOYSTICK STEERING, PVFC
05-19	VALVE ASSY - STEERING, AUXILIARY
05-20	VALVE ASSY - STEERING CONTROL
06-01	MOUNTING - TRANSMISSION
06-02	HYDRAULICS - TRANSMISSION
06-03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06-04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - PRIOR TO P.I.N. N8F203816
06-05	TRANSMISSION ASSY - HOUSING - PRIOR TO P.I.N. N8F203816
06-06	TRANSMISSION ASSY - HOUSING TUBES - PRIOR TO P.I.N. N8F203816
06-07	TRANSMISSION - CLUTCH ASSY, FIRST - PRIOR TO P.I.N. N8F203816
06-08	TRANSMISSION - CLUTCH ASSY, SECOND - PRIOR TO P.I.N. N8F203816
06-09	TRANSMISSION - CLUTCH ASSY, THIRD - PRIOR TO P.I.N. N8F203816
06-10	TRANSMISSION - CLUTCH ASSY, FOURTH - PRIOR TO P.I.N. N8F203816
06-11	TRANSMISSION - CLUTCH ASSY, FORWARD - PRIOR TO P.I.N. N8F203816
06-12	TRANSMISSION - CLUTCH ASSY, REVERSE - PRIOR TO P.I.N. N8F203816
06-13	TRANSMISSION - SHAFT, OUTPUT - PRIOR TO P.I.N. N8F203816
06-14	TRANSMISSION - POWER TAKE OFF - PRIOR TO P.I.N. N8F203816
06-15	TRANSMISSION - VALVE PLATES - PRIOR TO P.I.N. N8F203816
06-16	TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N8F203816
06-17	TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N8F203816
06-18	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP - PRIOR TO P.I.N. N8F203816
06-19	TRANSMISSION - SENSOR, SPEED AND PUMP COVER - PRIOR TO P.I.N. N8F203816
06-20	TRANSMISSION - FILTER, OIL AND FILLER COVER - PRIOR TO P.I.N. N8F203816
06-21	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - P.I.N. N8F203816 AND AFTER
06-22	TRANSMISSION ASSY - HOUSING - P.I.N. N8F203816 AND AFTER
06-23	TRANSMISSION ASSY - HOUSING TUBES - P.I.N. N8F203816 AND AFTER
06-24	TRANSMISSION - CLUTCH ASSY, FIRST - P.I.N. N8F203816 AND AFTER
06-25	TRANSMISSION - CLUTCH ASSY, SECOND - P.I.N. N8F203816 AND AFTER
06-26	TRANSMISSION - CLUTCH ASSY, THIRD - P.I.N. N8F203816 AND AFTER
06-27	TRANSMISSION - CLUTCH ASSY, FOURTH - P.I.N. N8F203816 AND AFTER
06-28	TRANSMISSION - CLUTCH ASSY, FORWARD - P.I.N. N8F203816 AND AFTER
06-29	TRANSMISSION - CLUTCH ASSY, REVERSE - P.I.N. N8F203816 AND AFTER
06-30	TRANSMISSION - SHAFT, OUTPUT - P.I.N. N8F203816 AND AFTER
06-31	TRANSMISSION - POWER TAKE OFF - P.I.N. N8F203816 AND AFTER
06-32	TRANSMISSION - VALVE PLATES - P.I.N. N8F203816 AND AFTER
06-33	TRANSMISSION - VALVE, CONTROL - P.I.N. N8F203816 AND AFTER

Order the manual at mid-west-tech.com >