CASE

PROFESSIONAL PARTNER

PARTS CATALOG
WHEEL LOADER

821E
TIER 3

87659896 EN-US

Replaces 87364141 N.A

Issued 01 Aug 06
Revised 01Feb 09

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-01	DIA
02-01	MOUNTING, ENGINE
02-02	RADIATOR - MOUNTING
02-03	FAN DRIVE
02-04	COOLANT RECOVERY SYSTEM
02-05	AIR CLEANER - AIR INTAKE PARTS
02-06	AIR CLEANER ASSY
02-07	MUFFLER - EXHAUST AND INTAKE
02-08	ENGINE
02-09	OIL FILL, ENGINE
02-10	OIL PUMP - ENGINE
02-11	OIL FILTER - ENGINE
02-12	OIL FILTER AND COOLER
02-13	OIL PUMP, PAN
02-14	OIL PUMP, PAN - DRAIN LINE
02-15	BREATHER - ENGINE
02-16	TURBOCHARGER SYSTEM
02-17	TURBOCHARGER
02-18	WATER PUMP
02-19	WATER PUMP - CONTROL
02-20	CYLINDER BLOCK
02-21	CYLINDER BLOCK - PLUG ASSY
02-22	CYLINDER BLOCK
02-23	FLYWHEEL HOUSING
02-24	GEAR COVER - REAR HOUSING
02-25	FRONT GEAR COVER
02-26	GEAR COVER - PLATE
02-27	CYLINDER HEAD - COVERS
02-28	CYLINDER HEAD - VALVE MECHANISM
02-29	CYLINDER HEAD
02-30	INTAKE MANIFOLD
02-31	MANIFOLD - EXHAUST
02-32	CAMSHAFT
02-33	CRANKSHAFT
02-34	CRANKSHAFT - PULLEY
02-35	FLYWHEEL - ENGINE
02-36	CONNECTING ROD
02-37	PISTONS
02-38	COOLING SYSTEM - ENGINE
02-39	THERMOSTAT - ENGINE COOLING SYSTEM
02-40	TURBOCHARGER DRAIN LINE
02-41	ENGINE - LIFT HOOKS
02-42	ENGINE - BLOCK HEATER
03-01	FUEL LINES - FILTER, IN-LINE FUEL
03-02	FILTER, FUEL - WATER SEPARATOR
03-03	FILTER, FUEL
03-04	FUEL TANK - FILLER - SENDER
03-05	FUEL INJECTION PUMP
03-06	FUEL INJECTION SYSTEM
03-07	FUEL INJECTION SYSTEM - INJECTOR
03-08	FUEL INJECTION SYSTEM - FUEL, SUPPLY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-09	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03-10	FUEL INJECTION SYSTEM - HARNESS, ENGINE
03-11	FUEL INJECTION SYSTEM - DRAIN LINE
04-01	STARTER
04-02	ALTERNATOR - MOUNTING WITHOUT AIR CONDITIONING
04-03	ALTERNATOR - MOUNTING WITH AIR CONDITIONING
04-04	ALTERNATOR ASSY
04-05	BATTERY
04-05A	BATTERY - HEAVY DUTY
04-06	BATTERY - CABLES
04-07	HARNESS - PANEL, CONTROL
04-07A	HARNESS - ROOF - CAB/CANOPY
04-07B	PANEL, CONTROL - SWITCH
04-07C	PANEL, CONTROL - FUSE AND RELAY MOUNTING - IF USED
04-07D	CAB - FUSES AND RELAYS
04-07E	ELECTRICAL - TRANSMISSION CONTROL - OPTIONS
04-08	HARNESS - ENGINE
04-08A	HARNESS - ENGINE - EUROPE
04-09	HARNESS - ENGINE - GRID HEATER
04-10	HARNESS, REAR CHASSIS - HARNESS, THROTTLE CONTROL
04-10A	HARNESS, REAR CHASSIS - HARNESS, THROTTLE CONTROL - EUROPE
04-11	HARNESS, REAR - RELAY PANEL
04-11A	HARNESS, REAR - RELAY PANEL - EUROPE
04-12	HARNESS, FRONT
04-13	HARNESS, FRONT
04-14	HARNESS, HOOD - BACKUP ALARM
04-14A	HARNESS, HOOD - BACKUP ALARM - EUROPE
04-15	HARNESS - TRANSMISSION
04-16	HARNESS - STEERING, AUXILIARY
04-17	HARNESS - JOYSTICK STEERING
04-18	MOUNTING - LAMP, FRONT
04-18A	MOUNTING - LAMP, FRONT
04-18B	LAMP ASSY - LAMP, FRONT
04-19	CAB/CANOPY - WORK LAMPS
04-19A	WORK LAMPS
04-20	REAR LIGHTS AND MOUNTING
04-20A	REAR LIGHTS AND MOUNTING - LCD
04-21	REAR LIGHTS AND MOUNTING - EUROPE
04-21A	LAMP ASSY - LAMPS, REAR COMBINATION - EUROPE
04-22	LICENSE PLATE LIGHT
04-23	BEACON ASSY, ROTATING - MOUNTING
04-23A	ROTATING BEACON COMPONENTS
04-24	WINDSHIELD WASHER MOUNTING
04-25	CAB - WIPER, FRONT
04-26	CAB - WIPER, REAR
04-27	RADIO - 12 VOLT
04-28	RADIO - 12 VOLT INSTALLATION
05-01	CAB/CANOPY - STEERING WHEEL
05-02	CAB/CANOPY - STEERING COLUMN (76303625)
05-02A	CAB/CANOPY - STEERING COLUMN (87497543)
05-03	CAB - STEERING COLUMN - ACCESSORY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-04	CAB - STEERING COLUMN - COVERS, SWITCHES
05-05	CANOPY - STEERING COLUMN - ACCESSORY
05-06	CANOPY - STEERING COLUMN - COVERS, SWITCHES
05-07	STEERING - HYDRAULICS
05-08	STEERING - HYDRAULICS - AUXILIARY
05-09	STEERING, STANDARD - HYDRAULICS - CYLINDER
05-10	STEERING, STANDARD - HYDRAULICS - CYLINDER
05-11	STEERING, STANDARD - HYDRAULICS - CYLINDER
05-12	JOYSTICK STEERING - JOYSTICK CONTROL AND HARNESS
05-13	JOYSTICK STEERING - ARMREST, JOYSTICK CONTROL
05-14	JOYSTICK STEERING - HYDRAULICS
05-15	JOYSTICK STEERING - HYDRAULICS - AUXILIARY
05-16	CYLINDER ASSY - STEERING
05-17	PUMP - STEERING, AUXILIARY
05-18	VALVE ASSY - JOYSTICK STEERING
05-19	VALVE ASSY - JOYSTICK STEERING, PVFC
05-20	VALVE ASSY - STEERING CONTROL
05-21	VALVE ASSY - STEERING, AUXILIARY
06-01	MOUNTING - TRANSMISSION
06-02	HYDRAULICS - TRANSMISSION
06-03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06-04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - PRIOR TO P.I.N. N7F203144
06-05	TRANSMISSION ASSY - HOUSING - PRIOR TO P.I.N. N7F203144
06-06	TRANSMISSION ASSY - HOUSING TUBES - PRIOR TO P.I.N. N7F203144
06-07	TRANSMISSION - CLUTCH ASSY, FIRST - PRIOR TO P.I.N. N7F203144
06-08	TRANSMISSION - CLUTCH ASSY, SECOND - PRIOR TO P.I.N. N7F203144
06-09	TRANSMISSION - CLUTCH ASSY, THIRD - PRIOR TO P.I.N. N7F203144
06-10	TRANSMISSION - CLUTCH ASSY, FOURTH - PRIOR TO P.I.N. N7F203144
06-11	TRANSMISSION - CLUTCH ASSY, FORWARD - PRIOR TO P.I.N. N7F203144
06-12	TRANSMISSION - CLUTCH ASSY, REVERSE - PRIOR TO P.I.N. N7F203144
06-13	TRANSMISSION - SHAFT, OUTPUT - PRIOR TO P.I.N. N7F203144
06-14	TRANSMISSION - POWER TAKE OFF - PRIOR TO P.I.N. N7F203144
06-15	TRANSMISSION - VALVE PLATES - PRIOR TO P.I.N. N7F203144
06-16	TRANSMISSION - VALVE, CONTROL - PRIOR TO P.I.N. N7F203144
06-17	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP - PRIOR TO P.I.N. N7F203144
06-18	TRANSMISSION - SENSOR, SPEED AND PUMP COVER - PRIOR TO P.I.N. N7F203144
06-19	TRANSMISSION - FILTER, OIL AND FILLER COVER - PRIOR TO P.I.N. N7F203144
06-20	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT - P.I.N. N7F203144 AND AFTER
06-21	TRANSMISSION ASSY - HOUSING - P.I.N. N7F203144 AND AFTER
06-22	TRANSMISSION ASSY - HOUSING TUBES - P.I.N. N7F203144 AND AFTER
06-23	TRANSMISSION - CLUTCH ASSY, FIRST - P.I.N. N7F203144 AND AFTER
06-24	TRANSMISSION - CLUTCH ASSY, SECOND - P.I.N. N7F203144 AND AFTER
06-25	TRANSMISSION - CLUTCH ASSY, THIRD - P.I.N. N7F203144 AND AFTER
06-26	TRANSMISSION - CLUTCH ASSY, FOURTH - P.I.N. N7F203144 AND AFTER
06-27	TRANSMISSION - CLUTCH ASSY, FORWARD - P.I.N. N7F203144 AND AFTER
06-28	TRANSMISSION - CLUTCH ASSY, REVERSE - P.I.N. N7F203144 AND AFTER
06-29	TRANSMISSION - SHAFT, OUTPUT - P.I.N. N7F203144 AND AFTER
06-30	TRANSMISSION - POWER TAKE OFF - P.I.N. N7F203144 AND AFTER
06-31	TRANSMISSION - VALVE PLATES - P.I.N. N7F203144 AND AFTER

Order the manual at mid-west-tech.com >

AXLE, REAR - HUB, PLANETARY - P.I.N. N8F203870 AND AFTER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87568458		1	AXLE, REAR, Incl. Parts On Figures 06-47 - 06-49, 06-50A, 06-51A; P.I.N. N8F203870 And After
		87757156		2	END ASSY, TRACK ROD, Incl. Parts On Fig. 06-50A, Incl. Refs. 1 - 22
1		84149185		1	HOUSING, Replaces 87757157
2		8603673		1	PLUG
3		384294A1		4	O-RING
4		8603610		1	GEAR, Ring
5		8603674		2	O-RING
6		8603562		1	SEAL
7		8603611		1	BEARING, ROLLER, TAPERED
8		8603612		1	BEARING, ROLLER
9		87521573		1	FLANGE, Output
10		8603565		1	NUT
11		384302A1		1	PIN
12		384303A1		1	COVER
13		331982A1		1	O-RING
14		8603614		1	GEAR, Shaft
15		87758635		3	GEAR, PLANETARY
16		87757159		1	PLANET CARRIER
17		384309A1		1	BOLT
18		87758637		3	BEARING, ROLLER, Inner
19		87758638		3	RING, Inner
20		8603575		1	PLUG, Brake Port; Incl. Ref. 20A
20A		8603208		1	O-RING

MidWestTech | Case 821E Tier 3 Wheel Loader Parts Catalog | Publication 87659896 Order the manual at mid-west-tech.com >

HEATER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
4A		87738375		1	BOX, Upper; No Longer Available, Order Box 87472438, Box 87474170, Box 87472439, Grommet 87476710, and Plug 87472441, Refs. 2B, 3B, 4B, 31A, 32A
4B		87472439		1	BOX, Upper
5		NSS		1	NOT SERVICED SEPARATELY, Right Fastening Bracket
6		NSS		1	NOT SERVICED SEPARATELY, Left Fastening Bracket
7		87643958		1	FLAP, Recirculation
8		87643957		2	BUSHING, For Recirculation Flap
9		87528689		1	MOTOR, ELECTRIC, SMALL
10		87529462		1	COVER, Inspection Trapdoor
11		NSS		13	NOT SERVICED SEPARATELY, Screw
12		87643954		1	TIE-ROD, Used With 87529617 Lever, Ref. 14
12A		87472436		1	TIE-ROD, Used With 87472437 Lever, Ref. 14A
13		87643955		2	BUSHING
14		87529617		1	LEVER, No Longer Available, Order 87472437 Lever and 87472436 Tie-Rod, Refs. 12A, 14A
14A		87472437		1	LEVER, Used With Heater 87472400
16		87528688		1	RESISTOR
17		87528687		1	BLOWER ASSY., Electric Fan
18		NSS		1	NOT SERVICED SEPARATELY, Bracket
20		NSS		2	NOT SERVICED SEPARATELY, Screw
21		NSS		2	NOT SERVICED SEPARATELY, Screw
22		87529485		1	CABLE, Heater; Used With Heater Unit 76303352
22		87727866		1	CABLE, Heater; Used With Heater Unit 87706153, 87472400
23		NSS		1	NOT SERVICED SEPARATELY, Fan Cable
26		NSS		4	NOT SERVICED SEPARATELY, Plug
27		87728778		1	SEAL
28		87577361		1	FOAM, Used With Heater Unit 76303352
28		87728776		1	SEAL, Used With Heater Unit 87706153, 87472400
29		87475866		1	CORE, Heater; Replaces 87529289; See Figure 09-69

MidWestTech | Case 821E Tier 3 Wheel Loader Parts Catalog | Publication 87659896 Order the manual at mid-west-tech.com >

DECALS - COMMON TO MODEL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		395895A1		1	DECAL, Hydraulic Fluid
2		87397077		1	DECAL, Fuse
3		87397076		1	DECAL, Fuse Location; If Used
3A		87647668		1	DECAL, Fuse Location; If Used
4		87397080		1	DECAL, Maintenance Chart
5		187864A1		2	DECAL, Lubrication
7		386741A2		1	DECAL, Hydraulic Fluid Temperature Level
8		329051A1		1	DECAL, Emergency Exit
9		87524649		1	DECAL, Battery Disconnect
10		139728A1		4	DECAL, Tie Down
11		8602227		1	DECAL, Transmission Fluid Level
12		379186A1		1	DECAL, 15W-40; No Longer Available, Order 87713879 Decal, Ref. 12A
13		304083A1		2	DECAL, Ride Control
12A		87713879		1	DECAL, 15W-40
14		365935A2		1	DECAL, 12 Volt
15		364741A1		1	DECAL, 24 Volt
16		87397078		1	DECAL, Fuse And Relay
17		139729A1		4	DECAL, Lift
18		387149A1		1	DECAL, Fluid Drains
19		E134402		1	DECAL, No Step
20		76085355		2	REFLECTOR, Amber; Not Illustrated
21		D55216		AR	STRIP, ANTI-SKID, 2 x 9 in; Anti-Skid; Not Illustrated
22		A59450		1	SIGN, WARNING, Slow Moving Vehicle; Uses Refs. 22A - 22D For Mounting
22A		614-6020		1	BOLT, Hex, M6 x 20, 8.8
22B		832-10406		1	NUT, LOCK, M6 x 1, Cl 8
22C		895-11006		1	WASHER, M6
22D		895-25006		1	WASHER, M6 x 18 x 1.6
23		87750555		1	DECAL, PCT
24		84128349		1	DECAL, Steering Warning

MidWestTech | Case 821E Tier 3 Wheel Loader Parts Catalog | Publication 87659896 Order the manual at mid-west-tech.com >