NEW HOLLAND

COMPACT WHEEL LOADER

W50BTC
W80BTC
TIER 3

OPERATOR'S MANUAL

87682591 NA

Issued 01May 06

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >

INDEX

SECTION 1

INTRODUCTION, SAFETY, PLATES AND DECALS 1-1

FOREWORD 1-1

SAFETY INSTRUCTIONS 1-2

GENERAL SAFETY INSTRUCTIONS 1-2

BEFORE OPERATING THE MACHINE 1-3

OPERATING THE MACHINE 1-5

PARKING THE MACHINE 1-8

MAINTENANCE AND ADJUSTMENTS 1-8

PREVENTION OF FIRE OR EXPLOSIONS 1-10

PREVENTION OF BURNS 1-11

PREVENTION OF RISKS ASSOCIATED WITH VIBRATIONS 1-12

PRECAUTIONS FOR WASTE DISPOSAL 1-13

COMPONENTS IDENTIFICATION PLATES 1-14

MAIN COMPONENTS 1-17

DECALS 1-18

NOISE LEVEL DECAL 1-18

POSITION OF DECALS 1-19

HAND SIGNALS 1-28

SECTION 2

CONTROLS AND INSTRUMENTS 2-1

CONTROLS AND INSTRUMENTS 2-1

INSTRUMENT CLUSTER AND LAMPS 2-5

CAB 2-8

OPERATOR'S COMPARTMENT CONTROLS 2-13

STARTER SWITCH KEY 2-13

HEATING 2-13

AIR CONDITIONING (OPTIONAL) 2-14

TURN SIGNAL LIGHTS, MAIN BEAMS, WINDSCREEN WIPER/WASHER AND HORN CONTROL LEVER 2-15

TRAVEL AND WORK CONTROL LEVER 2-18

BUCKET CONTROL LEVER 2-18

CONTROL LEVER ADDITIONAL FUNCTION 2-20

4 x 1 BUCKET (OPTIONAL) 2-20

LOCKING THE CONTROL LEVERS 2-20

RETURN TO DIG (OPTIONAL) 2-20

BRAKING AND STOPPING 2-21

STEERING COLUMN - ADJUSTMENT 2-22

OPERATOR'S SEAT 2-23

SEAT BELT 2-25

OPTIONAL CONTROLS 2-26

FRONT AND REAR WORK LIGHTS 2-26

ROTARY LIGHT 2-26

REVERSE ACOUSTIC SIGNAL 2-27

LOAD STABILIZATION SYSTEM 2-27

BATTERY MASTER SWITCH 2-28

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >

SECTION 3

OPERATING THE MACHINE **3-1**
GENERAL INSTRUCTIONS 3-1
BEFORE OPERATING THE MACHINE 3-1
OPERATING THE MACHINE 3-1
RUNNING-IN PERIOD 3-2
AFTER DAILY OPERATION - MACHINE PARKING 3-3
START-UP 3-4
ENGINE STOP 3-7
TRAVEL 3-8
BEFORE STARTING THE TRAVEL 3-8
STARTING 3-8
WORKING SPEED - CREEP SPEED (INCHING) 3-9
"HIGH SPEED" (OPTIONAL) 3-10
ROAD TRAVEL 3-11
MACHINE OUTFIT FOR TRAVEL ON PUBLIC HIGHWAYS 3-12
OPERATING THE MACHINE WITH COLD WEATHER 3-13
OPERATING THE MACHINE WITH HOT WEATHER 3-14
TOWING 3-15
TRANSPORT 3-17
WORKING ATTACHMENT 3-19
QUICK TOOL COUPLER 3-20
BUCKET TEETH - REPLACEMENT 3-22

SECTION 4

SUPPLIES AND MAINTENANCE CHART **4-1**
SUPPLY SUMMARIZING CHART 4-1
FUEL 4-2
HYDRAULIC OIL 4-3
SAFETY INSTRUCTIONS 4-4
MAINTENANCE INTERVALS CHART 4-6
HOURMETER 4-8
CHECKS BEFORE START-UP AND BEFORE EACH WORKING SHIFT (10 HOURS) 4-9
MACHINE GENERAL INSPECTION 4-9
SERVICE AND PARKING BRAKES 4-9
LIGHTS 4-9
CONTROLS AND LAMPS OPERATION 4-9
ENGINE OIL - LEVEL 4-10
COOLING SYSTEM LIQUID - LEVEL 4-10
HYDRAULIC OIL TANK - LEVEL 4-11
FUEL TANK - LEVEL 4-12
AIR CONDITIONING REFRIGERATING AGENT - LEVEL 4-13
SCREEN WASHER LIQUID - LEVEL 4-13
WEEKLY SERVICE (50 HOURS) 4-14
CAB AIR FILTER - CLEANING 4-14
AIR FILTER - CLEANING 4-15
DRIVE BELT - CHECK 4-18
FRONT AXLE - LEVEL CHECK 4-19
REAR AXLE - LEVEL CHECK 4-20

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >

TYRES - PRESSURE CHECK 4-21
WHEELS - NUTS TIGHTENING 4-23
GREASE NIPPLES - GREASING 4-24
ELECTRICAL SYSTEM - VOLTAGE AND CONTINUITY CHECK 4-26
MONTHLY SERVICE (250 HOURS) 4-27
REAR AXLE - GREASING 4-27
HEATING AND AIR CONDITIONING SYSTEM 4-28
SERVICE AFTER 500 HOURS 4-29
ENGINE OIL - CHANGE 4-29
ENGINE OIL FILTER - REPLACEMENT 4-31
FUEL FILTER - REPLACEMENT 4-32
SERVICE AFTER 1000 HOURS 4-33
CAB AIR FILTER - REPLACEMENT 4-33
ENGINE VALVE CLEARANCE - CHECK AND ADJUSTMENT 4-34
AIR INTAKE SYSTEM LINES - CHECK 4-34
AIR FILTER - REPLACEMENT 4-35
HYDRAULIC SYSTEM RETURN OIL FILTER - CHANGE 4-37
HYDRAULIC SYSTEM BREATHER FILTER - REPLACEMENT 4-38
BRAKE - PRESSURE CHECK 4-38
ACCUMULATOR - PRESSURE CHECK 4-40
BATTERIES - LEVEL CHECK AND TERMINAL CHARGE CHECK 4-42
HEATING SYSTEM FILTER - REPLACEMENT 4-44
FRONT AXLE - OIL CHANGE 4-44
REAR AXLE - OIL CHANGE 4-45
SERVICE AFTER 3000 HOURS 4-47
FUEL TANK - CLEANING 4-47
HYDRAULIC OIL TANK - CLEANING AND OIL CHANGE 4-48
DIESEL ENGINE - CLEANING 4-50
SERVICE IF NECESSARY 4-51
COOLERS - CLEANING 4-51
TYRES - REPLACEMENT 4-52
CONNECTORS AND LINES - REPLACEMENT 4-53
FUSES 4-54
RELAYS 4-55
BULBS - REPLACEMENT 4-56
ROTARY LIGHT 4-59
BRAKE SYSTEM - AIR BLEEDING 4-60
BATTERIES - REPLACEMENT 4-61
DRIVE BELT - REPLACEMENT 4-62
BUCKET TEETH - REPLACEMENT 4-63

SECTION 5


TROUBLESHOOTING 5-1
FAULTS INDICATED BY GAUGES 5-2
NO CURRENT / BATTERY 5-2
ENGINE OIL PRESSURE 5-3
BRAKE PRESSURE 5-3
ENGINE OIL TEMPERATURE 5-4
HYDRAULIC OIL TEMPERATURE 5-4
AIR FILTER CLOGGED 5-4
ENGINE WATER TEMPERATURE 5-5

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >

CONTROL LEVER ADDITIONAL FUNCTION

Control lever (1) can be used switching additional hydraulic functions, e.g. hydraulic quick tool coupler, bottom-dump bucket, sweeper attachment.

In the foremost position, control lever (1) has a lock facility, useful for sweeper operation.




36

4 x 1 BUCKET (OPTIONAL)

Control lever (1) initiates the following working movements:

- control lever (1) forwards - 4 x 1 bucket opening;
- control lever (1) backwards - 4 x 1 bucket closing.




37

LOCKING THE CONTROL LEVERS

Control levers (1) and (2) have a common mechanical locking device. With which the working hydraulic functions can be locked, e.g. for road travel.

Turn knob (3) counterclockwise until the marking aligns with the "locked" symbol.


Turn knob (3) clockwise until the marking aligns with the "unlocked" symbol.



38

RETURN TO DIG (OPTIONAL)


The "return to dig" function brings the bucket back from position (B) to working position (A). Only the boom must be lowered back manually.



39

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >

Remove the main filter element (4) with caution.



19

MAIN FILTER ELEMENT - CLEANING


Never clean filter elements by beating them against hard objects.

After three cleaning cycles or after one year of operation at the latest, the main filter element must be replaced.

Never clean filters with petrol and flammable or hot liquids.

Cleaning with compressed air is suitable if the filter element is to be re-used immediately.

The air pressure at the nozzle must not exceed 5 bars (73 psi).


20

Start cleaning the filter surface by blowing dry compressed air diagonally from outside into the filter element.


Finally blow compressed air inside the filter element.

Cleaning is finished when all visible dust has been removed from the element.

Checks

Checks before installation of the main filter element.

Check the filter paper with the help of a lamp bulb. Filter damage is indicated where the light shines brightly through the paper. If damaged, replace the main filter element immediately.


21

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >

NOISE

	W50BTC	W80BTC
External noise level L_{WA}	99 dB(A)	100 dB(A)
Internal noise level LpA	75 dB(A)	

WEIGHTS

		W50BTC	W80BTC
Engine	kg (lb)	300 (660)	
Front axle	kg (lb)	230 (506)	318 (700)
Rear axle (gearbox included) and travel motor	kg (lb)	312 (686)	315 (694)
Cab	kg (lb)	470 (1034)	
Variable-displacement pump	kg (lb)	30 (66)	
Hydraulic motor	kg (lb)	35 (77)	
Lifting equipment	kg (lb)	420 (924)	600 (1320)
Lifting cylinder	kg (lb)	30 (66)	
Cylinder for quick coupler	kg (lb)	12 (26)	
Counterweight	kg (lb)	393 (865)	786 (1730)

DIESEL ENGINE

		W50BTC	W80BTC
Iveco model		F5C E9454 B* A003	F5C E9454 G* A001
Operation		4-stroke diesel engine	
Number of cylinders		4	
Bore	mm (in)	99 (3.90)	
Stroke	mm (in)	104 (4.09)	
Total displacement	cm^3 (in^3)	3202 (195.400)	
Maximum torque (at 1400 rpm)	Nm (lbf•ft)	220 (162)	310 (228)
Power ISO 9249	kW/CV	40 / 54	61 / 82
Rated rpm	rpm	2300	2500
Ignition order		1,3,4,2	
Compression ratio		17 ± 0.5: 1	
Weight	kg (lb)	300 (660)	

MidWestTech | New Holland W50BTC, W80BTC Tier 3 Compact Wheel Loader Operator's... Order the manual at mid-west-tech.com >