JX60, JX70, JX80, JX90 and JX95 Tractors

Operator's Manual

87683934 7/07
Replaces 87630724

CASE IH

MidWestTech | Case JX60, JX70, JX80, JX90, JX95 Tractor Operator's Manual | Publication 87683934

Order the manual at mid-west-tech.com >

CONTENTS

Section 1

General Information and Safety 1-1
Notices for the User 1-2
Tractor Identification 1-3
Ecology and the Environment 1-6
Precautionary Statements 1-7
Personal Safety 1-7
Machine Safety 1-7
Information 1-7
Working Safely 1-9
Safety Decals 1-15
Tractor Noise Level Information Sheet 1-20
International Symbols 1-21

Section 2

Controls, Instruments and Operation 2-1
Introduction 2-1
Safety Covers and Guards 2-2
Controls and Instruments - Position and Function 2-4
Instrument Panel 2-5
Controls 2-9
Seats 2-15
Cab 2-18

MidWestTech | Case JX60, JX70, JX80, JX90, JX95 Tractor Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

Section 2 *(continued)*

Cab Ventilation, Heating, and Air-Conditioning Systems 2-24
Transmission with Range Gear and Shuttle - 30 KPH (19 MPH) 2-30
Transmission with Creeper and Shuttle - 30 KPH (19 MPH) 2-32
Mechanically Controlled Four-wheel Drive 2-34
Mechanically Controlled Differential Lock 2-35
LIM-Slip Differential Lock (Optional) 2-36

Section 3

Field Operation 3-1
General Field Operation Information 3-1
Starting and Stopping 3-2
Power Take-off 3-5
Power Take-off Operation 3-6
Hydraulic Lift 3-11
Hydraulic Lift 3-15
Three-point Linkage (Category II) 3-16
Drawbars 3-20
Equipment Mounting Points 3-21
Folding ROPS 3-23
Remote Control Valves 3-24
Wheel Track Adjustment 3-27
Front and Rear Wheel Track Adjustment 3-29
Steering Angle Adjustment 3-32
Steering Angle Adjustment (MFD Models) 3-33
Tires - Use, Maintenance and Replacement 3-34
Loading Information 3-36
Speed Code 3-36
Tire Data and Pressures 3-37
Tire Combinations 3-38
Inflation Pressures 3-41
Ballasting 3-42
Liquid Ballasting 3-43
Maximum Permitted Weight 3-46
MFD Models 3-47

MidWestTech | Case JX60, JX70, JX80, JX90, JX95 Tractor Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

Section 4

Lubrication and Maintenance 4-1
General Lubrication and Maintenance Information 4-1
Tractor Refueling 4-2
Access for Inspection and Maintenance 4-4
Lubrication and Maintenance Table 4-5
Flexible Maintenance 4-7
When the Indicator Light Illuminates On the Dashboard 4-10
Every 10 Hours of Work 4-11
Every 50 Hours of Work 4-16
Every 300 Hours of Work 4-19
Every 600 Hours of Work 4-24
Every 900 Hours of Work 4-24
Every 1200 Hours of Work 4-24
Every 1200 Hours or Every 2 Years 4-27
General Maintenance 4-32
Electrical System 4-33
Recommendations for Bodywork Maintenance 4-41
Lubricants and Fluids 4-42

Section 5

Troubleshooting 5-1
General Troubleshooting Information 5-1

Section 6

Vehicle Storage 6-1

Section 7

Tractor Specifications 7-1
General Tractor Specifications Information 7-1
Dimensions of 2WD Models with Standard Tires 7-1
Dimensions of MFD Models with Standard Tires 7-2
Engine Specification 7-5

Section 8

Delivery Report 8-1
First 50 Hour Service 8-5

Section 9

Index 9-1

MidWestTech | Case JX60, JX70, JX80, JX90, JX95 Tractor Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

JX95 HC Tractor

Operator's Manual Supplement

84134834

CASE

MidWestTech | Case JX60, JX70, JX80, JX90, JX95 Tractor Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >