9030 Excavator

Parts Catalog

8-8951

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX

GENERAL 1



ENGINE 2



FUEL 3



ELECTRICAL 4



STEERING 5



POWER TRAIN 6



HYDRAULICS 8



CHASSIS AND MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10

Bur 8-8951

Issued July, 1994

Printed in U.S.A.

MidWestTech | Case 9030 Excavator Parts Catalog | Publication 8-8951

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D4356734	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-ring - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, machinery item, order form Machinery Price List	1
8	843065C1	HOSE - 132 inch long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 9030 Excavator Parts Catalog | Publication 8-8951 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjuster - track 5-9
Air Cleaner
  Assembly 2-7
  Mounting 2-7
Alarm - backup 4-9
Alternator 4-3
Arm - bucket or mounted tool ..... 9-57 - 9-61

B

Battery, Cables and Mounting ..... 4-7 - 4-11
Bearing - turntable 9-3
Bearings - engine
  Camshaft 2-31
  Rod - connecting 2-39
Belt
  Fan 2-13
  Seat 9-35
Block - cylinder 2-33,2-35
Block Heater 2-35
Boom 9-53,9-55
Boom Lubrication System 9-53,9-55
Brake
  Swing Motor 8-53
  Track Drive 6-9
Buckets ..... 9-73 - 9-85
Bucket Teeth ..... 9-73 - 9-89

C

Cab
  Assembly ..... 9-41 - 9-51
  Door and Door Seal
    Overhead 9-47,9-49
    Side Entrance - cab door 9-51
  Fan 9-39
  Floor 9-41
  Glass ..... 9-45 - 9-51
  Guards - vandal 9-43
  Heater 9-37
  Insulation ..... 9-43 - 9-47
  Mounting 9-41
  Windshield
    Wiper 4-23
    Washer 4-25
Cables - battery 4-7,4-11
Camshaft - engine 2-31
Carrier - final drive 6-5
Carrier Roller - track 5-11
Chain - track 5-5

C

Check Valve - track adjuster 5-9
Cleaner - air
  Assembly 2-7
  Mounting 2-7
Cluster - instrument 4-13
Cold Start System 4-27
Connecting Rod - engine 2-43
Console and Covers
  Left Hand ..... 9-29 - 9-33
  Right Hand 9-25,9-27
Controller - electrical 4-15
Controls
  Auxiliary Hydraulic 6-21
  Foot Pedal - track drive 6-13
  Hand Lever - track drive 6-13
  Shut-down Solenoid - engine 3-7
  Throttle - engine 3-7
Coolant Recovery System 2-5
Cooler
  Engine Oil 2-23
  Hydraulic Oil 2-11,2-11B
Cooling System - hydraulic oil 8-13
Covers
  Engine ..... 9-15 - 9-23
  Instrument Panel 4-13
  Side Panels ..... 9-15 - 9-23
  Upper Structure ..... 9-13 - 9-23
Counterweight 9-11
Coupling - hydraulic pump 8-5
Crankshaft - engine 2-39
Cylinder Assembly - hydraulic
  Arm 8-79
  Boom 8-85
  Bucket 8-81,8-83
  Track Adjustment 5-9
Cylinder Block - engine 2-33,2-35
Cylinder Block Gasket Kit 2-45
Cylinder Head - engine 2-29
Cylinder Head Cover - engine 2-27

D

Decals ..... 9-63 - 9-71
Defroster Fan 9-39
Dipstick - engine oil 2-35
Drive Sprocket 5-3
Drive Transmission ..... 6-3 - 6-11

E

Electrical Circuit - main 4-7,4-9

MidWestTech | Case 9030 Excavator Parts Catalog | Publication 8-8951 Order the manual at mid-west-tech.com >