9050 Excavator

Parts Catalog

Bur 8-90101

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjuster - track 5-9
Air Cleaner System 2-9
Air Compressor 2-53,2-55
Air Lines - compressor 8-89
Air Restriction Indicator Switch 2-9
Alarm - travel 4-19
Alternator 4-3
Arm - bucket or mounted tool 9-55,9-57
Auxiliary Hydraulic Pump 8-5B

B

Batteries, Cables and Mounting 4-9,4-11
Bearing - turntable 9-3,9-3B
Bearings - engine
  Camshaft 2-41
  Rod - connecting 2-51
Belt
  Fan and Alternator 2-17
  Seat 9-35
  Water Pump 2-17
Block - cylinder 2-43,2-45
Boom 9-53
Boom Lubrication System 9-53
Brake
  Swing Motor 8-59
  Track Drive 6-9
Buckets and Teeth ..... 9-59 - 9-73

C

Cab
  Assembly ..... 9-41 - 9-51
  Door and Door Seal
    Overhead 9-47,9-49
    Side Entrance 9-51
  Fan 9-39
  Floor, Mounting and Mats 9-41
  Glass ..... 9-45 - 9-51
  Guards - vandal 9-43
  Heater 9-37
  Insulation ..... 9-43 - 9-47
  Mounting 9-41
  Windshield Washer 4-25
  Windshield Wiper 4-23
Cables - battery 4-9
Camshaft - engine 2-41
Carrier - final drive 6-5
Carrier Roller - track 5-11
Chain - track 5-5
Check Valve - track adjuster 5-9
Cleaner - air, assembly and mounting 2-9
Cluster - instrument 4-13

C

Compressor - air 2-53,2-55
Connecting Rods - engine 2-51
Console and Covers
  Left-Hand ..... 9-27 - 9-33
  Right-Hand 9-23,9-25
Controls
  Foot Pedal - track drive 6-13
  Hand Lever - track drive 6-13
  Shutdown Solenoid - engine 3-7
  Throttle - engine 3-7
Coolant Recovery System 2-5
Cooler
  Engine Oil 2-27
  Hydraulic Oil 2-9
Cooling System - hydraulic oil 8-13
Counterweight 9-11
Coupling - hydraulic pump 8-5
Covers
  Engine ..... 9-13 - 9-23
  Instrument Panel 4-13
  Side Panels ..... 9-17 - 9-21
  Upper Structure ..... 9-13 - 9-21
Crankshaft 2-47
Cylinder Assembly - hydraulic
  Arm 8-85
  Boom 8-83
  Bucket 8-87,8-87B
  Track Adjustment 5-9
Cylinder Block - engine 2-43,2-45
Cylinder Block Gasket Kit 2-43
Cylinder Head 2-33

D

Decals ..... 9-75 - 9-83
Defroster Fan 9-39
Dipstick - engine oil 2-31
Drive Sprocket 5-3
Drive Transmission ..... 6-3 - 6-11

E

Electrical Circuit - main 4-9
Electrical Harnesses
  Horn 4-9
  Instrument Cluster 4-9
  Left-Hand Console 4-17
  Main Electrical 4-9
  Right-Hand Console 4-15
  Windshield Wiper 4-23
  Work Light 4-9

MidWestTech | Case 9050 Excavator Parts Catalog | Publication 8-90101 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

E

Engine and Fuel Injection Components
- Camshaft....2-41
- Compressor - air....2-53,2-55
- Connecting Rods....2-51
- Crankshaft....2-47
- Cylinder Block....2-43,2-45
- Cylinder Head....2-33
- Cylinder Head Cover....2-43
- Flywheel and Housing....2-49
- Front Gear Cover....2-45
- Fuel Filters....3-3,3-17
- Fuel Injection Nozzle....3-15
- Fuel Injection Pump and Drive....3-13
- Fuel Injection System....3-5,3-9,3-11
- Fuel Transfer Pump....3-17
- Gasket Kit....2-43
- Manifolds....2-19
- Muffler and Exhaust System....2-11
- Oil Cooler....2-27
- Oil Filler....2-31
- Oil Filters....2-25
- Oil Lines....2-57
- Oil Pan....2-31
- Oil Pump and Strainer....2-29
- Pistons and Sleeves (Liners)....2-51
- Pully - fan....2-13
- Pump - fuel lift....3-17
- Rocker Cover....2-37
- Sleeve - piston....2-43
- Thermostat and Housing....2-35
- Turbocharger....2-21, 2-23
- Valve Mechanism....2-35
- Water Pump....2-17

Engine Mounting and Adapting Parts....2-3
Equipment Pump - hydraulic....8-15 - 8-23
Exhaust Manifold....2-19
Exhaust System and Muffler....2-3,2-11

F

Fan
- Alternator....4-3
- Defroster....9-39
- Engine Cooling....2-13

Fan Belt....2-17
Fan Lube Lines....2-15
Filler - engine oil....2-31
Filters
- Air - engine....2-7
- Engine Oil....2-25
- Fuel, in Tank....3-3,3-17
- Hydraulic Oil....8-3,8-11,8-33,8-33B

Final Drive Transmission....6-3 - 6-11

F

Floor, Mounting and Mats....9-41
Flywheel and Housing....2-49
Frame
- Track....5-3
- Upper Structure....9-13 - 9-21

Front Gear Cover - engine....2-45
Fuel
- Filter....3-3,3-17
- Gauge....3-3
- Injection Nozzle....3-15
- Injection Pump and Mounting....3-13
- Injection System....3-9,3-11
- Lines - fuel tank to engine....3-5,3-17,3-19
- Motor - throttle....3-7
- Shutdown Solenoid - engine....3-7
- Tank....3-3
- Transfer Pump....3-17

Fuse Box....4-15

G

Gasket Kit - engine....2-45
Gauges
- Fuel Level....3-3
- Instrument Cluster....4-13
- Oil Level - hydraulic....8-3

Gear - timing....2-41
Gearbox - swing....8-63
Guards - track....5-17
Guards - turntable....9-9
Guides - track....5-3

H

Hand Lever Controls....6-13,8-25
Harness - electrical
- Horn....4-9
- Instrument Cluster....4-9
- Left-Hand Console....4-17
- Main Electrical....4-9
- Right-Hand Console....4-15
- Windshield Wiper....4-23
- Work Light....4-23

Head - cylinder....2-33
Head Gasket....2-33
Heater and Hoses - cab....9-37
Hood....9-15,9-21
Horns....4-9
Hoses - radiator....2-3,2-5
Hydraulic Circuits
- Arm Cylinder....8-79 - 8-81
- Auxiliary Pump Suction....8-5B
- Boom Cylinder....8-75
- Bucket Cylinder....8-79,8-81

MidWestTech | Case 9050 Excavator Parts Catalog | Publication 8-90101 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

H

Hydraulic Circuits - cont.
- Controllers to Control Valve 8-27,8-29
- Cooling System 8-13
- Cushion Valve 8-37,8-39
- Drive - track 6-15,6-17
- Equipment Pump to Valve ..... 8-9,8-31 - 8-33B
- Filter, Accumulator and Solenoids . 8-33 - 8-35
- Oil Filter Return Lines 8-11
- Pilot Lines ..... 8-29 - 8-39
- Reservoir to Pump 8-7
- Swing Motor 8-35,8-55
- Track Drive 6-15,6-17

Hydraulic Cooling System 8-13
Hydraulic Oil Cooler 2-27
Hydraulic Oil Filter 8-11,8-33
Hydraulic Pump ..... 8-15 - 8-23
Hydraulic Reservoir 8-3
Hydraulic Swivel 6-19

I

Idler Wheel 5-7
Index - numerical 10-1
Injection Nozzle - fuel 3-15
Injection Pump and Mounting 3-13
Injection System 3-9,3-11
Instrument Cluster and Mounting 4-13
Insulation - cab ..... 9-43 - 9-47

L

Lamps - work 4-21
Lever - control 6-13,8-25
Liners - engine cylinder 2-51
Lines - fuel tank to engine 3-5,3-19
Link - track shoe 5-5
Lubrication System
- Boom 9-53
- Turntable Bearing 9-5

M

Manifolds - intake and exhaust 2-19
Mat - floor 9-41
Mirror - rear view 9-45
Mounting
- Air Cleaner 2-7
- Alternator 4-7
- Battery 4-11
- Engine 2-3
- Main Control Valve 8-65
- Radiator 2-5
- Seat 9-35
- Starter 4-7
- Swing Motor 8-57

M

Motor - track drive 6-9,6-11
Muffler - engine exhaust 2-11

N

Nozzle - fuel injection 3-15
Numerical Index 10-1

O

Oil Cooler
- Engine 2-27
- Hydraulic - transmission oil 2-9

Oil Cooling System - hydraulic 8-13
Oil Filters
- Engine 2-25
- Hydraulic 8-11,8-33

Oil Lines 2-57
Oil Pan - engine 2-31
Oil Pump - engine 2-29

P

Pan - oil 2-31
Panel - instrument and switches 4-13,4-15
Pistons and Connecting Rods 2-51
Platforms - turntable 9-7
Pulley
- Alternator 4-3
- Crankshaft 2-47
- Fan and Water Pump 2-17

Pump
- Auxiliary Hydraulic 8-5B
- Equipment
  - Control Assembly 8-21,8-23
  - Drive Gearing 8-15
  - Pilot Gear Pump 8-19
  - Pressure Reducing Valve 8-19
  - Relief Valve 8-19
  - Valve Section 8-17
- Fuel Injection 3-13
- Fuel Lift 3-17
- Oil - engine 2-29
- Water 2-17

Push Rods - engine 2-35

R

Radiator Assembly 2-7
Radiator Hoses 2-3
Radiator Supports and Coolant Overflow 2-5
Radio 4-15
Rear View Mirror 9-45
Reduction Gear Assembly 8-63
Reservoir - hydraulic oil 8-3
Rings - piston, engine 2-51

MidWestTech | Case 9050 Excavator Parts Catalog | Publication 8-90101 Order the manual at mid-west-tech.com >