621B Wheel Loader
Chargeur Articule 621B
Gelenklader 621B
Pala Cargadora 621B

Parts Catalogue - Catalogue Pièces
Ersatzteilkatalog - Catalogo Repuestos

Don 8-9461

CASE CONSTRUCTION

MidWestTech | Case 621B Multi Lingual Wheel Loader Parts Catalog | Publication 8-9461

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator 8-77
Accumulator Valve 7-21
Accumulators 7-25
Air Conditioning And Condenser ..... 9-79 – 9-85
Air Conditioning Compressor 9-89
Air Conditioning Compressor Mounting 9-87
Air Conditioning System ..... 9-73 – 9-77
Air Filter 2-45
Air Filter And Air Intake Parts 2-43
Alarm Back Up 4-75
Alternator 4-3
Alternator And Mounting 4-45
Auxiliary Steering Motor Assembly 4-39, 4-41
Auxiliary Steering Pump And Motor Assembly 5-23
Auxiliary Steering System 4-35, 4-37, 5-19, 5-21
Axle Assemblies And Mounting 6-37
Axle Housing And Planetary 6-41, 6-43, 6-51, 6-53

B

Battery And Cables 4-43
Battery Covers 9-37
Blower Assembly 4-73
Brake Hydraulic Circuit ..... 1B-23, 1B-25, 7-9 – 7-19
Brake Pedals 7-7
Brake Pump 7-23
Brake Valve 7-27
Bucket - Height Control 9-7, 9-9
Bucket - Return To Dig 9-3, 9-5
Bucket Cylinder 8-59, 8-61
Buckets And Teeth 9-17

C

Cab Door 9-67
Cab Filters And Vents 9-65
Cab Front Wiper 4-69
Cab Interior 9-57, 9-59
Cab Mounting 9-53, 9-55
Camshaft 2-21
Clearance Gauge Lights - Front And Rear 4-57
Control Valve 8-69, 8-71
Coolant Recovery System 2-41
Counterweights - 2000 Lb 9-25
Crankshaft 2-27, 2-29
Cylinder Block 2-23, 2-25
Cylinder Head And Valve Mechanism 2-19
Cylinder Head Covers, Gasket And Thermostat Housing 2-17

D

Decals ..... 9-99 – 9-119
Directional Valve 8-79
Drive Shaft - Centre And Rear 6-61

E

Engine Compartment Light 4-59
Engine Mounting 2-3
Exhaust System 2-47

F

Flow Control Valve 5-25
Flywheel And Housing 2-31
Front Axle Differential 6-47
Front Axle Differential Carrier 6-45
Front Axle Housing 6-39
Front Drive Shaft 6-59
Front Fenders - Tuv 9-47
Front Frame And Fenders 9-43, 9-45
Front Gear Cover 2-7
Front Lights 4-49, 4-51
Front Turn Signal Light 4-53
Fuel Filter And Transfer Pump 3-11
Fuel Injection Pump And Drive 3-13
Fuel Injection System 3-9
Fuel Injector 3-15
Fuel Lines 3-5
Fuel Tank Filler And Sender 3-7

G

Gasket Kits 2-35, 2-37
Gauges And Switches 4-13, 4-15

H

Harness - Cab 4-25, 4-27
Harness - Cab Roof 4-23
Harness - Front 4-17, 4-19
Harness - Pedestal 4-21
Harness - Rear ..... 4-29 – 4-33
Heater And Air Conditioning 9-69
Heater Installation 9-71
Hydraulic Circuit ..... 1B-27 – 1B-31, 8-23 – 8-31
Hydraulic Pump 8-5, 8-7
Hydraulic Reservoir 8-3
Hydraulic System ..... 8-9 – 8-21

I

Instrument Panel 4-7, 4-9
Insulation - Hood 9-35
Insulation - Rear Chassis 9-23

L

License Plate Light 4-61
Lift Cylinder 8-57
Lights - Flood 4-63
Loader Control Valve ..... 8-33 – 8-55
Loader Lift Frame ..... 9-11 – 9-15

MidWestTech | Case 621B Multi Lingual Wheel Loader Parts Catalog | Publication 8-9461 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

N

Number Plate 9-93

O

Oil Filter And Cooler 2-13
Oil Pump, Pan And Heater 2-15

P

Parking Brake 7-3
Parking Brake Controls 7-5
Pistons And Connecting Rods 2-33
Pressure Reducing Valve 8-75

R

Radiator And Connections 2-39
Radiator Guard And Grille 9-31, 9-33
Radio, Speakers And Antenna 4-77
Rear Axle Differential 6-57
Rear Axle Differential Carrier 6-55
Rear Axle Housing 6-49
Rear Chassis 9-19, 9-21
Rear Fenders - Tuv 9-41
Rear Fenders And Steps 9-39
Rear Light 4-55
Rear Lights And Mounting 4-47
Rear Window Wiper 4-71
Reflectors 9-95
Remote Control 8-67
Remote Control Circuit 8-65
Remote Control Valve 8-73
Ride Control 4-11
Rotating Beacon 4-67
Rotating Beacon And Support 4-65

S

Seat 9-51
Seat And Mounting 9-49
Side Doors 9-29
Soundproofing - Cab 9-63
Speedometer 4-79
Starter 4-5
Steering Column Panels 9-61
Steering Control Valve 5-7
Steering Cylinder 5-27
Steering Hydraulic Circuit ..... 1B-21, 5-9 – 5-17
Steering Wheel And Column 5-3, 5-5

T

Throttle Control 3-3
Tooth Guard 9-97
Transmission ..... 6-9 – 6-35
Transmission Hydraulic Circuit 6-3
Transmission Mounting 6-5, 6-7

T

Trunnion 9-27
Turbocharger 2-11
Turbocharger And Manifolds 2-9

V

Valve Controls And Separator 8-63

W

Water Pump 2-5
Wheel Chock 9-91
Wheels 6-63

Don 8-9461 Issued March, 1996 Printed in U.S.A.

MidWestTech | Case 621B Multi Lingual Wheel Loader Parts Catalog | Publication 8-9461 Order the manual at mid-west-tech.com >

INDEX ALPHABETIQUE

A

Accelerateur Au Pied 3-3
Accouplement D'Essieu 6-37
Accumulateur 8-77
Accumulateurs 7-25
Adaptation Transmission 6-5, 6-7
Adhesifs ..... 9-99 – 9-119
Ailes Arrieres - Tuv 9-41
Ailes Arrieres Et Marches 9-39
Ailes Avant - Tuv 9-47
Alarme - Marche Arriere 4-75
Alternateur 4-3
Alternateur Et Supports 4-45
Appareils De Controle 4-13, 4-15
Arbre A Cames 2-21
Arbre De Commande - Coulisant Et Arriere 6-61
Arbre De Commande Avant 6-59

B

Bielles, Pistons Et Chemises 2-33
Bloc Cylindres 2-23, 2-25

C

Cable De Batterie 4-43
Cale Roue 9-91
Capot 9-29
Capot Radiateur 9-31, 9-33
Carter De Distribution 2-7
Carter Du Pont Avant 6-39
Carter D'Essieu Arriere 6-49
Carter Et Moyeux De L'Essieu 6-41, 6-43, 6-51, 6-53
Chassis Arriere 9-19, 9-21
Chassis Avant Et Ailes 9-43, 9-45
Chauffage Et Air Conditionne 9-69
Cinematique ..... 9-11 – 9-15
Circuit De Control Remote 8-65
Circuit Direction ..... 1B-21, 5-9 – 5-17
Circuit Hydraulique Transmission 6-3
Ciruit Hydraulique ..... 1B-27 – 1B-31, 8-23 – 8-31
Clignotant Et Feux De Position Avant 4-53
Commande De Frein De Parking 7-5
Compresseur Air Conditionne 9-89
Compteur De Vitesse 4-79
Condenseur Air Conditionne ..... 9-79 – 9-85
Contrepoids - 2000 Lb 9-25
Controle De Position A Distance 8-67
Couvercle Batteries 9-37
Culasse Et Culbuteurs 2-19
Cylindre De Direction 5-27

D

Demarreur 4-5
Differentiel Portuer De Essieu Avant 6-45, 6-55
Distributeur 8-69, 8-71

D

Distributeur De Commande De La Chargeuse 8-33 – 8-55
Distributeur Rotatif 5-7

E

Eclairage Compartiment Moteur 4-59
Essieu Arriere Differentiel 6-57
Essieu Avant Differentiel 6-47
Essuie Glace Arriere 4-71
Essuie-Glace Avant 4-69

F

Faisceau - Arriere ..... 4-29 – 4-33
Faisceau - Avant 4-17, 4-19
Faisceau - Cabine 4-25, 4-27
Faisceau - Piedestal 4-21
Faisceau - Toit De Cabine 4-23
Feu Indicateur De Charge Gabarit - Avant Et Arriere . 4-57
Feu Rotatiff 4-67
Feu Rotatiff Et Support 4-65
Feux D'Eclairage De Plaque D'Immatriculation 4-61
Filtre A Air 2-45
Filtre A Air Et Raccordements 2-43
Filtre Et Refroidisseur D'Huile 2-13
Filtres Et Grilles Cabine 9-65
Filtres Et Pompe Carburant 3-11
Frein Circuit Hydraulique ..... 1B-23, 1B-25, 7-9 – 7-19
Frein De Parc 7-3

G

Godet - Automatismes 9-3, 9-5
Godet - Bras 9-7, 9-9
Godets Et Dents 9-17

I

Injecteur 3-15
Insonorisation - Cabine 9-63
Installation Chauffage 9-71
Installation Compresseur Air Conditionne 9-87
Installation De Air Conditionne ..... 9-73 – 9-77
Isolateurs - Capot 9-35
Isolateurs - Chassis Arriere 9-23

J

Joint Et Couvercles De Culasse, Thermostat Et Carter 2-17

M

Montage Cabine 9-53, 9-55
Montage Siege 9-49
Moteur Direction Auxiliaire 4-39, 4-41

MidWestTech | Case 621B Multi Lingual Wheel Loader Parts Catalog | Publication 8-9461 Order the manual at mid-west-tech.com >