821B Loader
Includes Rev.1 & 2

Parts Catalog

8-9481

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator Valve 7-21
Accumulators 7-27
Air Conditioning And Condenser ..... 9-73 – 9-79
Air Conditioning Compressor 9-83
Air Conditioning Compressor Mounting 9-81
Air Conditioning System ..... 9-67 – 9-71
Air Filter 2-45
Air Filter And Connections 2-43
Alarm Back Up 4-75
Alternator 4-3
Alternator And Mounting 4-45
Auxiliary Steering Motor Assembly 4-39, 4-41
Auxiliary Steering Pump And Motor Assembly 5-25
Auxiliary Steering System 4-35, 4-37, 5-21, 5-23
Axle Assemblies And Mounting 6-39
Axle Housing And Planetary 6-43, 6-45, 6-55, 6-57

B

Battery And Cables 4-43
Battery Covers 9-33
Blower Assembly 4-73
Brake Hydraulic Circuit ..... 1B-23, 1B-25, 7-9 – 7-19
Brake Pedals 7-7
Brake Pump 7-23, 7-25
Bucket And Teeth 9-9, 9-11
Bucket Cylinder 8-47
Bypass Valve 8-43

C

Cab Door 9-59
Cab Front Wiper 4-69
Cab Interior 9-53, 9-55
Cab Mounting 9-47, 9-49
Cab Roof Harness 4-21
Camshaft 2-23
Clearance Gauge Lights - Front And Rear 4-57
Control Valve 8-55, 8-57, 8-63
Coolant Recovery System 2-41
Counterweights (4400 Lb) 9-19
Crankshaft 2-27, 2-29
Cutting Edges 9-13
Cylinder Block 2-25
Cylinder Head And Valve Mechanism 2-21
Cylinder Head Cover 2-17

D

Decals ..... 9-93 – 9-109
Directional Valve 8-65
Drive Shaft - Centre And Rear 6-65

E

Engine Compartment Light 4-59
Engine Mounting 2-3

E

Exhaust System 2-47

F

Fan And Fan Belt 2-39
Flow Control Valve 5-27
Flywheel And Housing 2-31
Front Axle Differential 6-51
Front Axle Differential Carrier 6-47, 6-49
Front Axle Housing 6-41
Front Chassis 9-41
Front Drive Shaft 6-63
Front Fenders - Tuv 9-39
Front Gear Cover 2-7
Front Lights 4-49, 4-51
Front Turn Signal Light 4-53
Fuel Filter And Transfer Pump 3-13
Fuel Injection Nozzle 3-17, 3-19
Fuel Injection Pump And Drive 3-15
Fuel Injection System 3-11
Fuel Lines And Filter System 3-5, 3-7
Fuel Tank Filler And Sender 3-9

G

Gasket Kits 2-35
Gauges And Switches 4-15

H

Harness - Cab 4-23, 4-25
Harness - Front 4-17
Harness - Pedestal 4-19
Harness - Rear ..... 4-27 – 4-33
Harness - Ride Control 4-13
Heater And Air Conditioning 9-61, 9-63
Heater Installation 9-65
Hood 9-23
Hydraulic Circuit ..... 1B-27, 1B-29, 8-17 – 8-21
Hydraulic Pump 8-5, 8-7
Hydraulic Reservoir 8-3
Hydraulic System ..... 8-9 – 8-15

I

Instrument Panel 4-9, 4-11
Insulation 9-17, 9-31

L

License Plate Light 4-61
Lift Cylinder 8-45
Lights - Flood 4-63
Loader Bucket - Height Control 9-5
Loader Control Valve ..... 8-25 – 8-39
Loader Lift Frame 9-7

MidWestTech | Case 821B Multi Lingual Loader Parts Catalog | Publication 8-9481 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

N

Number Plate 9-87

O

Oil Filter And Cooler 2-13
Oil Pump Pan And Heater 2-15

P

Parking Brake 7-3
Parking Brake Controls 7-5
Pistons And Connecting Rods 2-33
Pressure Reducing Valve 8-61

R

Radiator And Connections 2-37
Radiator Guard And Grille 9-27, 9-29
Radio, Speakers And Antenna 4-77
Rear Axle Differential 6-61
Rear Axle Differential Carrier 6-59
Rear Axle Housing 6-53
Rear Chassis 9-15
Rear Fenders - Tuv 9-37
Rear Fenders And Steps 9-35
Rear Light 4-55
Rear Lights And Mounting 4-47
Rear Window Wiper 4-71
Reflectors 9-89
Remote Control 8-53
Remote Control Circuit 8-51
Remote Control Valve 8-59
Return To Dig - Bucket 9-3
Rotating Beacon 4-67
Rotating Beacon And Support 4-65

S

Seat 9-45
Seat And Mounting 9-43
Side Doors 9-25
Soundproofing - Cab 9-51
Speedometer 4-79
Starter Assembly 4-5, 4-7
Steering Column Panels 9-57
Steering Control Valve 5-7
Steering Cylinder 5-29
Steering Hydraulic Circuit ..... 1B-21, 5-9 – 5-19
Steering Pump (3 Spool) 8-23
Steering Wheel And Column 5-3, 5-5

T

Thermostat And Housing 2-19
Throttle Control 3-3
Tooth Guard 9-91
Transmission ..... 6-9 – 6-37

T

Transmission Hydraulic Circuit 6-3
Transmission Mounting 6-5, 6-7
Trunnion 9-21
Turbocharger 2-11
Turbocharger, Pipes And Connections 2-9

U

Unloading Valve 8-41

V

Valve Controls And Separator 8-49

W

Water Pump 2-5
Wheel Chock 9-85
Wheels 6-67

Don 8-9481 Issued March, 1996 Printed in England

MidWestTech | Case 821B Multi Lingual Loader Parts Catalog | Publication 8-9481 Order the manual at mid-west-tech.com >

INDEX ALPHABETIQUE

A

Accelerateur Au Pied 3-3
Accouplement D'Essieu 6-39
Accumulateurs 7-27
Adaptation Transmission 6-5, 6-7
Adhesifs ..... 9-93 – 9-109
Ailes Arrieres - Tuv 9-37
Ailes Arrieres Et Marches 9-35
Ailes Avant - Tuv 9-39
Alarme - Marche Arriere 4-75
Alternateur 4-3
Alternateur Et Supports 4-45
Appareils De Controle 4-15
Arbre A Cames 2-23
Arbre De Commande - Coulisant Et Arriere 6-65
Arbre De Commande Avant 6-63
Automatismes - Bras 9-5
Automatismes - Godet 9-3

B

Bielles, Pistons Et Chemises 2-33
Bloc Cylindres 2-25

C

Cable De Batterie 4-43
Cale Roue 9-85
Capot 9-23, 9-25
Capot Radiateur 9-27, 9-29
Carter De Distribution 2-7
Carter Du Pont Avant 6-41
Carter D'Essieu Arriere 6-53
Carter Et Moyeux De L'Essieu 6-43, 6-45, 6-55, 6-57
Chassis Arriere 9-15
Chassis Avant 9-41
Chauffage Et Air Conditionne 9-61, 9-63
Cinematique 9-7
Circuit De Control Remote 8-51
Circuit Direction ..... 1B-21, 5-9 – 5-19
Circuit Hydraulique Transmission 6-3
Ciruit Hydraulique ..... 1B-27, 1B-29, 8-17 – 8-21
Clapet By-Pass Refroidisseur 8-43
Clignotant Et Feux De Position Avant 4-53
Commande De Frein De Parking 7-5
Compresseur Air Conditionne 9-83
Compteur De Vitesse 4-79
Condenseur Air Conditionne ..... 9-73 – 9-79
Contrepoids (4400 Lb) 9-19
Controle De Position A Distance 8-53
Couvercle Batteries 9-33
Culasse 2-17
Culasse Et Culbuteurs 2-21
Cylindre De Direction 5-29

D

Differentiel Portuer De Essieu Avant 6-47, 6-49, 6-59
Distributeur 8-55, 8-57, 8-63
Distributeur De Commande De La Chargeuse 8-25 – 8-39
Distributeur Rotatif 5-7

E

Eclairage Compartiment Moteur 4-59
Ensemble De Demarreur 4-5, 4-7
Essieu Arriere Differentiel 6-61
Essieu Avant Differentiel 6-51
Essuie Glace Arriere 4-71
Essuie-Glace Avant 4-69

F

Faisceau - Arriere ..... 4-27 – 4-33
Faisceau - Avant 4-17
Faisceau - Cabine 4-23, 4-25
Faisceau - Piedestal 4-19
Faisceau - Systeme Anti-Tangage 4-13
Faisceau Toit De Cabine 4-21
Feu Indicateur De Charge Gabarit - Avant Et Arriere 4-57
Feu Rotatiff 4-67
Feu Rotatiff Et Support 4-65
Feux D'Eclairage De Plaque D'Immatriculation 4-61
Filtre A Air 2-45
Filtre Air Et Raccordments 2-43
Filtre Et Refroidisseur D'Huile 2-13
Filtres Et Pompe Carburant 3-13
Frein Circuit Hydraulique ..... 1B-23, 1B-25, 7-9 – 7-19
Frein De Parc 7-3

G

Godets Et Dents 9-9, 9-11

I

Injecteur De Carburant 3-17, 3-19
Insonorisation - Cabine 9-51
Installation Chauffage 9-65
Installation Compresseur Air Conditionne 9-81
Installation De Air Conditionne ..... 9-67 – 9-71
Isolateurs 9-17, 9-31

L

Lames 9-13

M

Montage Cabine 9-47, 9-49
Montage Siege 9-43
Moteur Direction Auxiliaire 4-39, 4-41

P

Paneaux De Controle 9-57

MidWestTech | Case 821B Multi Lingual Loader Parts Catalog | Publication 8-9481 Order the manual at mid-west-tech.com >