590 Super L Construction King Loader Backhoe

Parts Catalog

Bur 8-9951

MidWestTech | Case 590 Super L Construction King Loader Backhoe Parts Catalog | Publication 8-9951

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator, Ride Control....8-143
Air Cleaner....2-9
Air Cleaner Mounting....2-7
Air Conditioner
- Blower....9-121
- Compressor and Mounting....9-131
- Condenser....9-129,9-129B
- Controls....9-111
- Drain Lines....9-121
- Evaporator Core....9-127
- Filter - air....9-119
- Receiver-Drier....9-129,9-129B
- Ventilation Ducts....9-121

Air Filter - cab....9-119
Alarm - backup....4-41
Alarm - warning, engine oil pressure....4-19
Alarm - warning, engine water temp....4-19
Alarm - warning, parking brake....4-19
Alternator - electrical....4-7
Alternator Mounting....4-9
Antenna - radio....4-45
Antirollback - loader....9-11
Armrests - seat....9-97
Auxiliary Hydraulics
- Backhoe....8-63 - 8-67
- Basic....8-45 - 8-61
- Hand Held....8-69,8-71
- High Flow Upgrade....8-73

Axle - Front - four wheel drive
- Differential....6-15
- Drive Shaft....6-19
- Housing....6-5
- Mounting....6-3
- Planetary....6-13
- Ring and Pinion....6-17
- Shafts....6-11
- Steering Cylinder....6-9
- Swivel Housing....6-7

Axle - Front - two wheel drive....5-15
Axle - Rear Drive
- Differential....6-55
- Differential Brake....7-3,7-3B
- Differential Lock....6-51,6-59
- Drive Shaft....6-63
- Housing....6-53
- Mounting....6-49
- Parking Brake....7-5
- Planetary....6-61
- Ring and Pinion Gear Set....6-57

B

Backhoe
- Boom....9-39,9-41
- Boom Latch....9-43
- Boom Lock....8-75,8-77
- Buckets....9-53 - 9-61
- Controls (See Controls)
- Control Tower Support and Covers....9-19,9-21
- Coupler - bucket....9-45 - 9-49
- Dipper....9-45,9-47
- Extendable Dipper....9-49,9-51
- Frost Point Assembly....9-63
- Hydraulics (See Hydraulic Systems)
- Stabilizers....9-35
- Swing Tower....9-37
- Valves (See Valves)

Backhoe Auxiliary Hydraulics....8-63 - 8-67
Backup Alarm....4-41
Baffle Plates - front covers....9-73 - 9-73D
Battery - with cold start....4-15
Battery - without cold start....4-13
Battery Box....9-69
Beacon - rotating....4-43
Bearings - front wheel....5-17
Belts - fan, alternator, and compressor....2-3,2-3B,4-9,9-131
Belts - seat....9-87
Block - cylinder....2-37
Blower - air conditioner....9-121
Boom Latch....9-43
Boom Lock....8-75,8-77
Boots
- Accelerator Pedal....3-7
- Backhoe Levers....9-21
- Boom Latch Lever....9-43
- Brake Master Cylinder....7-11
- Lamp Socket, instrument cluster....4-27
- Loader Lever....4-21,9-3,9-5,9-7
- Suspension Seat....9-91
- Transmission Gear Shift Lever....6-23
- Transmission Shifter Mechanism....6-33
- Transmission Shuttle Shift Lever - FNR....4-17

Box - battery....9-69
Box - tool....9-69B
Brake - differential, rear axle....7-3,7-3B
Brake - parking, lever....7-13
Brake - parking, rear axle....7-5
Brake Alarm - parking....4-19
Brake Master Cylinder
- Assembly....7-11
- Hydraulic Circuit....7-9
- Mounting....7-7

MidWestTech | Case 590 Super L Construction King Loader Backhoe Parts Catalog | Publi... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

B

Brake Pedals 7-7
Buckets - backhoe ..... 9-53 - 9-61
Buckets - loader 9-15,9-17

C

Cab
- Air Conditioner ..... 9-127 - 9-131
- Air Filter 9-119
- Blower Housing 9-121
- Condenser - air conditioning 9-129,9-129B
- Covers - interior 9-101
- Doors and Windows ..... 9-103 - 9-109
- Drain Lines - air conditioning 9-121
- Electrical and Lighting 4-31,9-111
- Evaporator Core 9-127
- Frame 9-101
- Glass 9-99
- Headliner, Louvers, and Dome Lamp 9-117
- Heater ..... 9-121 - 9-125
- Insulation 9-101
- Panel - cab control 9-111
- Receiver-Drier - A/C 9-129,9-129B
- Ventilation Ducts 9-121
- Windshield Wipers 9-113,9-115

Cables - battery 4-13,4-15
Camshaft - engine 2-35
Canopy - ROPS 9-133
Chaff Screen 9-77
Chassis - tractor 9-67
Cluster - instrument 4-27
Clutch Cutout 4-11,4-21
Cold Start - dual battery 4-15
Cold Start System - ether 2-13
Column - steering 5-9
Compressor and Mounting 9-131
Controls
- Antirollback - loader 9-11
- Backhoe
  - Excavator Control Pattern 9-31B
  - Foot Swing ..... 9-23 - 9-27
  - Hand Swing ..... 9-29 - 9-33
- Backhoe Auxiliary 8-67,8-73
- Boom Latch 9-43
- Boom Lock 8-75,8-77
- Brake 7-7,7-13
- Clutch Cutout 4-11,4-21
- Differential Lock - rear axle 6-51
- Extendable Dipper 9-27,9-33
- Hand Held Auxiliary 8-71
- Loader
  - Bucket 9-3

C

Controls-Cont.
- Loader-Cont.
  - Clam 9-5,9-7
  - Lift 9-3
  - Self-Leveling 9-9
- Parking Brake 7-13
- Return-to-Dig - loader 9-11
- Ride Control 8-79,8-81
- Self-Leveling - loader 9-9
- Steering 5-3
- Throttle 3-5,3-7
- Transmission Gear Shift 6-23
- Transmission Shifter Mechanism 6-33,6-33B
- Transmission Shuttle Shift (F/N/R) 4-17

Control Tower - backhoe 9-19,9-21
Cooler - hydraulic oil 6-21,6-21B,8-9
Cooling Systems
- Engine 2-3,2-3B
- Engine Oil 2-27
- Hydraulic Oil 8-9
- Transmission 6-21,6-21B

Core - evaporator, air conditioner 9-127
Counterweight - front 9-65
Coupler - backhoe bucket ..... 9-45 - 9-49
Couplings - auxiliary hydraulics 8-63,8-69
Couplings - hydraulic line disconnect 8-3
Couplings - hydraulic pump to engine 8-3
Covers
- Anti-Vandalism
  - Instrument Panel - front 4-23
  - Instrument Panel - side 4-25
- Auxiliary Hydraulic Control 8-67
- Backhoe Control Tower 9-21
- Baffle Plates - front 9-73B,9-73D
- Battery Box 9-69
- Cab Interior 9-101
- Chassis Upright 9-77
- Cylinder Head 2-31
- Fender - plastic/velcro 9-83
- Front Gear 2-19
- Instrument Panel 4-23,4-25
- Loader Control 4-25
- Loader Lift Frame Tubing 3-3,9-69
- Pump Guard - front 9-73
- Rear Closure Panel - canopy 9-81
- ROPS Canopy Post 9-133
- Steering Column 4-23

Crankshaft 2-41
Cylinder - brake master 7-11
Cylinder Block 2-37
Cylinder Head 2-31

MidWestTech | Case 590 Super L Construction King Loader Backhoe Parts Catalog | Publi... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

C

Cylinders - hydraulic
- Boom - backhoe 8-159
- Bucket - backhoe 8-163,8-165
- Bucket - loader 8-149
- Clam - loader 8-151
- Dipper - backhoe 8-161
- Dipper Extension - backhoe 8-167
- Lift - loader 8-147
- Stabilizer - backhoe 8-153
- Steering - 2WD 5-13
- Steering - 4WD 6-9
- Swing - backhoe 8-155,8-157

D

Decals ..... 9-139 - 9-145
Defroster ..... 9-121 - 9-125
Differential and Differential Lock - rear axle 6-51,6-55,6-59
Differential - front axle 6-15
Dipper 9-45,9-47
Dipper - extendable 9-49,9-51
Dipsticks
- Oil Level - engine 2-39
- Transmission 6-23

Dome Lamp 9-117
Drive Shaft
- Front Drive Axle to Transmission 6-19
- Rear Drive Axle to Transmission 6-63

E

Electrical Circuits and Components
- Alternator 4-7
- Backup Alarm 4-41
- Battery 4-13,4-15
- Blower - cab 9-121
- Boom Lock 8-75,8-77
- Cold Start System 2-13,4-15
- Compressor - air conditioner 9-131
- Control Panel - cab 9-111
- Harness - engine 4-11
- Harness - front console 4-17
- Harness - lamp, cab 4-31
- Harness - lamp, canopy 4-29
- Harness - side console 4-19,4-21
- Horn 4-41
- Instrument Cluster 4-27
- Lamp - cab 4-35,4-39
- Lamp - ROPS canopy 4-33,4-37
- Radio 4-45
- Return-to-Dig 9-11
- Ride Control 8-79,8-81
- Rotating Beacon 4-43

E

Electrical Circuits and Components-Cont.
- Starter 4-3,4-5
- Wipers 9-113,9-115

Engine and Fuel Injection Components
- Camshaft 2-35
- Crankshaft 2-41
- Cylinder Block/Block Heater 2-37,2-39
- Cylinder Head and Cover/Thermostat 2-31
- Flywheel and Housing 2-43
- Fuel Filter 3-9
- Fuel Injection Nozzle 3-13
- Fuel Injection Pump and Drive 3-11
- Fuel Injection System 3-9
- Gasket Kits 2-47
- Gear Cover 2-19
- Heater - engine oil 2-29
- Manifolds 2-21
- Oil Filter and Cooler 2-27
- Oil Pump and Pan 2-29
- Pistons/Connecting Rods 2-45
- Turbocharger Assembly 2-25
- Turbocharger System 2-23
- Valve Mechanism 2-33
- Water Pump Systems 2-17

Engine Mounting 2-15
Equipment Pump
- Assembly 8-83
- Mounting 8-3

Evaporator - core, air conditioner 9-127
Exhaust/Intake Manifolds 2-21
Exhaust System and Muffler 2-11

F

Fans
- Alternator 4-7
- Engine Cooling 2-3,2-3B

Fenders - cab 9-83
Fenders - ROPS canopy, rear 9-81
Filters
- Air - engine 2-9
- Cab Air 9-119
- Engine Oil 2-27
- Fuel 3-9
- Fuel - In-line 3-3
- Hydraulic Oil 8-145
- Precleaner 2-9
- Transmission Oil 6-25

Floor Plates and Mats 9-79
Flywheel and Housing 2-43
Frame
- Backhoe (See Backhoe)
- Cab 9-101

MidWestTech | Case 590 Super L Construction King Loader Backhoe Parts Catalog | Publi... Order the manual at mid-west-tech.com >