Nutri-Tiller 955 (8, 12, 16-Row) Applicator

PIN YHD083158 and after

OPERATOR'S MANUAL

Part number 903885l8
3rd edition English
June 2020
Replaces part number 48191141

CASE IH AGRICULTURE

MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388518
Order the manual at mid-west-tech.com >

Contents

1 GENERAL INFORMATION

Note to the owner 1-1
Electro-Magnetic Compatability (EMC) 1-2
Product Identification Number (PIN) 1-3
Operator's manual storage on the machine 1-4
Machine orientation 1-5
Machine components 1-6

2 SAFETY INFORMATION

Safety rules and signal word definitions 2-1
Safety information 2-2
Anhydrous ammonia (NH_3) safety 2-9
Safety Features 2-11
Ecology and the environment 2-13
Hand signals 2-14
Safety signs 2-15

3 TRANSPORT OPERATIONS

PREPARING FOR ROAD TRANSPORT

Before operating 3-1
Attaching the implement to the tractor 3-3
Connecting to the tractor 3-5
Jack stand 3-9
Hydraulic connections 3-10
Bleeding air from hydraulic circuits 3-11
Transport lighting 3-13
Disconnecting the implement 3-15

4 WORKING OPERATIONS

Preparing for work

Hydraulic system 4-1
Transport stops 4-4
Single point depth control adjustment 4-5
Single point depth control setting 4-6
Level the implement fore and aft 4-7
Leveling the implement side to side 4-8
High Clearance Shank (HCS)™ spring pack adjustment 4-10
Knife assembly to High Clearance Shank (HCS)™ 4-12
Knife assembly to formed High Clearance Shank (HCS)™ 4-14
Row cleaner lock up 4-15
Berm Build'r™ adjustments 4-17
Berm Condition'r™ adjustments 4-19
Disk sealer setting 4-20

MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388... Order the manual at mid-west-tech.com >

Coulter setting 4-22
Rear hitch lock out pin 4-24

5 MAINTENANCE

GENERAL INFORMATION

General information 5-1
Consumables 5-3
Torque 5-4
Special bolt torque 5-9
Tire pressure 5-10
Transport stops 5-11

MAINTENANCE CHART

Lubrication and maintenance chart 5-12
Grease locations 5-13

After first 10 hours and periodically

Frame bolts 5-14
Wheel bolt torque 5-15

Every 50 hours

Depth adjustment tube assembly 5-16
Walking tandem pivot 5-16
Rear hitch drawbar flipper 5-17
Coulter arm 5-17
High Clearance Shank (HCS)™ 5-18
Berm Build'r™ assembly 5-18
Berm Condition'r™ assembly 5-19

Every 100 hours

Wheel Hub 5-20
Coulter hub bearing 5-20

Every 250 hours or yearly

Walking tandem pivot 5-21
Wheel Hub 5-22
Repack wheel bearing 5-23
Repack Berm Build'r™ bearing 5-26
Repack coulter hub bearing 5-28

Yearly

Hydraulic hose connections 5-30
Repack walking tandem pivot bearings 5-31

STORAGE

Preparing for storage 5-37
Removing from storage 5-39

MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388... Order the manual at mid-west-tech.com >

6 TROUBLESHOOTING

ALARM(S)


Field performance 6-1
Component breakage 6-3
Removing air from the hydraulic system 6-5
Rephasing suspension lift cylinders 6-7

7 SPECIFICATIONS

Consumables 7-1
Tractor requirements 7-2
Frame and hitch 7-2
Transport size 7-2
Weight 7-3
Hydraulics 7-3
Wheels and tires 7-4
Shanks and coulters 7-4


MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388... Order the manual at mid-west-tech.com >

Single point depth control setting



GOIL15TIL0302AA 1

Valve actuator pin misaligned



GOIL15TIL0304AA 2

Valve actuator pin aligned

Reference	Description
1	Depth control valve plunger
2	Valve actuator pin
3	Single point depth control guide

NOTICE: *The center lines of the valve actuator pin and the depth control valve plunger must be parallel for proper operation.*

1. To adjust the alignment, loosen the **10 mm** (**3/8 in**) hardware on single point depth control guide **(3)**.
2. Rotate the single point depth control guide and depth control valve assembly until the valve actuator pin **(2)** and depth control valve plunger **(1)** are parallel with each other.
3. Tighten the **10 mm** (**3/8 in**) lock nuts to the specifications listed in "Torque" starting on **5-4**.

MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388... Order the manual at mid-west-tech.com >

MAINTENANCE CHART

Lubrication and maintenance chart

Maintenance action	Grease		Lubricate		Page no.
	Check			Cleaning	
After first 10 hours and periodically					
Frame bolts	x				5-14
Wheel bolt torque	x				5-15
Every 50 hours					
Depth adjustment tube assembly		x			5-16
Walking tandem pivot		x			5-16
Rear hitch drawbar flipper		x			5-17
Coulter arm		x			5-17
High Clearance Shank (HCS)™			x		5-18
Berm Build'r™ assembly			x		5-18
Berm Condition'r™ assembly			x		5-19
Every 100 hours					
Wheel Hub		x			5-20
Coulter hub bearing			x		5-20
Every 250 hours or yearly					
Walking tandem pivot	x				5-21
Wheel Hub				x	5-22
Repack wheel bearing			x		5-23
Repack Berm Build'r™ bearing			x		5-26
Repack coulter hub bearing			x		5-28
Yearly					
Hydraulic hose connections	x				5-30
Repack walking tandem pivot bearings	x				5-31

MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388... Order the manual at mid-west-tech.com >

Tractor requirements

Engine horsepower	
8-row	**112 – 149 kW** (**150 – 200 Hp**)
12-row	**168 – 224 kW** (**225 – 300 Hp**)
16-row	**224 – 298 kW** (**300 – 400 Hp**)
Remote hydraulic valves	Two hydraulic remote valves
Tractor hydraulic pressure	**16547 kPa** (**2400 psi**) minimum
Tractor electrical system	**12 V** with seven-pin connector
Operating speed	**8 – 11.3 km/h** (**5 – 7 mph**) recommended
Operating depth	
Knives	**127 – 203 mm** (**5 – 8 in**)
Coulters	**51 – 104 mm** (**2 – 4 in**)

Frame and hitch

NOTE: *Category III, IV and V hitches are interchangeable on the implement hitch. Contact your dealer for more information.*

Hitch	
Category III clevis for 8-row	**44 mm** (**1-3/4 in**) hitch pin max
Category IV clevis for 12-row and 16-row	**51 mm** (**2 in**) hitch pin max
Pull frame	**102 x 203 mm** (**4 x 8 in**) rectangular tubes
Main frame	**102 x 152 mm** (**4 x 6 in**) rectangular tubes
Wing frame	**102 x 152 mm** (**4 x 6 in**) rectangular tubes

Transport size

Implement size	Shank spacing	Working width	Transport width	Transport height
8 row	**762 mm** (**30 in**)	**6.1 m** (**20 ft**)	**5.0 m** (**16-1/2 ft**)	**4.1 m** (**13-1/2 ft**)
12 row	**762 mm** (**30 in**)	**9.9 m** (**32-1/2 ft**)	**5.6 m** (**18-1/2 ft**)	**4.1 m** (**13-1/2 ft**)
16 row	**762 mm** (**30 in**)	**11.4 m** (**37-1/2 ft**)	**5.6 m** (**18-1/2 ft**)	**4.1 m** (**13-1/2 ft**)

MidWestTech | Case Nutri Tiller 955 Applicator Operator's Manual | Publication 90388... Order the manual at mid-west-tech.com >