1450B Crawler

Operators Manual

9-11200

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 1450B Crawler Operator's Manual | Publication 9-11200

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
Safety 4
Roll-Over Protective Structure 22
Location of Product Identification Number (PIN) and Serial Numbers ... 27
Specifications 30
Operating Instructions 40
- Fast Reference for Instruments and Controls 40
- Instrument Panel 44
- Controls 46
- Cab Controls 50
- Seats 52
- Operator's Seat Belt 54
- Run-In Period 55
- Engine Operation 56
  - Service and Checks Before Starting Engine 56
  - Starting the Engine 57
  - Stopping the Engine 58
  - Starting Aids 59
- Crawler Operation 64
  - Adjusting the Seat 64
  - Starting 64
  - Transmission Controls 65
  - Steering 66
  - Stopping the Crawler 69
  - When Operating on a Hill 70
  - Procedure to Move a Disabled Machine 70
  - Procedure to Transport the Machine ..71
  - Operating in Cold Temperatures ... 73
  - Operating in Hot Temperatures 73
- Loader Operation 74
  - Safety When You Work 74
  - Loader Control Levers 75
  - Raising and Lowering the Bucket ... 75
  - Rolling Back or Dumping the Bucket 75
  - Filling the Bucket 76
  - Return-To-Dig 77
  - Bucket Level Indicator 77
  - Bucket Height Control 77
  - 4-In-1 Bucket 78
  - Positioning the Bucket and Clam ... 79
- Dozer Operation 82
  - Safety When You Work 82
  - Engine Speed and Transmission Range Control 83
  - Control Levers 83
- Ripper Operating Instructions 89
- Dual Pull-Behind Hydraulics Operations .90
- Winch Operating Instructions 91
- Operating in Cold Temperatures 95

Fuels and Lubricants 96
- Diesel Fuel Specifications 96
- Fuel, Fluids and Lubricants Chart 97

Maintenance and Lubrication 98
- Introduction 98
- Run-In Maintenance Chart 99
- Maintenance Chart for Regular Intervals .99
- Safety Before Servicing 102
- Grease Fittings 105
- Engine Lubrication System 113
  - Oil Level 113
  - Oil Change 113
  - Engine Oil Filters 114
- Air Cleaner System 116
  - Restriction Indicator 116
  - Cap for the Air Cleaner 116
  - Precleaner 117
  - Air Cleaner (With Dust Cup) 117
  - Strata Air Cleaner (If Equipped) ... 119
- Engine Cooling System 124
  - Coolant Level 124
  - Ethylene Glycol Coolant 124
  - Procedure to Clean the Cooling System 125
- Fuel System 127
  - Fuel Tank 127
  - Checking and Servicing the Fuel System 128
  - Replacing Fuel Filters 130
  - Removing Air From the Fuel System .132
- Electrical System 133
  - Fluid Level of the Batteries 135
  - Lamps 137
- Hydraulic System 139
  - Oil Level 139
  - Hydraulic Oil Filter 139
  - Hydraulic Oil Screen 139
  - Hydraulic Reservoir Breather 140
  - Oil Change 141
- Transmission Hydraulic System 142
  - Oil Level 142
  - Transmission Oil Filter 142
  - Transmission Oil Screen 143
  - Transmission Breather 143
  - Transmission Oil Change 145
- Final Drives 146
  - Oil Level 146
  - Oil Change 148
- Track System 149
- Parking Brake and Manual Brake ... 152
- Drive Belts 153
- Loader Service 155
- Winch Service 158
- Seat Belt and Suspension Seat 161
- Procedure to Put the Machine in Storage 161
- Procedure to Remove the Machine from Storage 163
- After Delivery check of a New Machine 165

MidWestTech | Case 1450B Crawler Operator's Manual | Publication 9-11200 Order the manual at mid-west-tech.com >