680L
Loader Backhoe

Operators Manual

9-12791

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 680L Loader Backhoe Operator's Manual | Publication 9-12791

Order the manual at mid-west-tech.com >

TO THE OWNER

TABLE OF CONTENTS

Introduction 4

After Delivery Check 5

Right, Left, Front, and Rear Sides of the Machine 5

Identification of Machine Components 6

Product Identification and Serial Numbers 7

MidWestTech | Case 680L Loader Backhoe Operator's Manual | Publication 9-12791 Order the manual at mid-west-tech.com >

SAFETY

TABLE OF CONTENTS

Safety Rules 10

Before Operation 11

Machine Operation 12

Parking the Machine 13

Maintenance 13

Burn Prevention 14

Fire or Explosion Prevention 15

Safety Decals 16-22

Hand Signals 23-26

MidWestTech | Case 680L Loader Backhoe Operator's Manual | Publication 9-12791 Order the manual at mid-west-tech.com >

SPECIFICATIONS

TABLE OF CONTENTS

Capacities 28

Engine 29

Electrical System 29

Tire Air Pressures 30

Travel Speeds 30

Operating Weights 31

Loader Buckets 31

Backhoe Buckets 31

Bolt Torques 31

Loader Dimensions 32

Standard Backhoe Operating Data 34

Extendahoe Operating Data 36

Standard Backhoe Lift Capacity 38

Extendahoe Lift Capacity - Dipper Retracted 39

Extendahoe Lift Capacity - Dipper Extended 40

MidWestTech | Case 680L Loader Backhoe Operator's Manual | Publication 9-12791 Order the manual at mid-west-tech.com >