W36 Loader

Pin 17754000 and After

Operator's Manual

Bur 9-12890

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W36 Loader Operator's Manual | Publication 9-12890

Order the manual at mid-west-tech.com >

SAFETY

TABLE OF CONTENTS

Safety Rules 10

Before Operation 11

Machine Operation 12

Parking the Machine 12

Maintenance 13

Burn Prevention 14

Fire or Explosion Prevention 14

Safety Decals 16-20

Hand Signals 21-23

MidWestTech | Case W36 Loader Operator's Manual | Publication 9-12890 Order the manual at mid-west-tech.com >

SPECIFICATIONS

TABLE OF CONTENTS

Engine 26

Capacities 27

Electrical System 27

Operating Data and Dimensions 28,29

Loader Buckets 29

Travel Speeds 30

Tire Air Pressures 30

MidWestTech | Case W36 Loader Operator's Manual | Publication 9-12890 Order the manual at mid-west-tech.com >

INSTRUMENTS AND CONTROLS

TABLE OF CONTENTS

Instrument Panel 32

Control Panel 34

Transmission Range and Transmission Direction Controls 36

Foot Pedals 37

Turn Signals and Flashers 38

Loader Control Levers 38-41

- Lift Arm and Bucket Control Levers (Single Levers) 39
- Lift Arm and Bucket Control Lever (Dual Levers) 40
- 4-In-1 Bucket Clam or Auxiliary Control 41

Cab Controls 42

Suspension Seat 45

Seat Belts 46,47

MidWestTech | Case W36 Loader Operator's Manual | Publication 9-12890 Order the manual at mid-west-tech.com >