680K Loader Backhoe

Includes 12 Volt and 24 Volt Electrical Systems

Operators Manual

9-12900

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 680K Loader Backhoe, 12 Volt and 24 Volt Electrical Systems Loader... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To The Owner 2
Delivery of the New Machine 2
After Delivery Check 3
Right, Left, Front, and Rear Sides of Machine 3
Identification of Machine Components 4
Safety 5
Safety Decals 6
Personal 10
Before Starting the Engine 11
Starting the Engine 12
Machine Operation 12
Loader Operation 15
Backhoe Operation 16
Parking the Machine 19
Maintenance 20
Controls and Instruments 26
Instrument Panel 32
Machine Controls 34
Loader Lift Arm and Bucket Control 39
4-In-1 Bucket Clam Control 40
Backhoe Controls with Foot Swing 41
Backhoe Controls with Hand Swing 42
Extendahoe Control with Foot Swing 43
Extendahoe Control with Hand Swing 44
Operators Seats 45
Cab Controls 47
Cab Control Settings and Air Flow 49
Operators Seat Belts 53
Engine Operation 55
Walk-Around Inspection 55
Starting the Engine 55
Engine Speed 56
Parking the Machine and Stopping the Engine 56
Methods to Help Start Engine During Cold Weather 57
Machine Operation 62
Adjusting the Seat 62
Starting 62
Shifting Transmission 63
Operating on a Hill 63
Moving a Disabled Machine 64
Transporting Machine on a Trailer 66
Operating in Cold Weather 68
Operating in Hot Weather 68
Loader Operation 69
Safety When You Work 69
Bucket Level Indicator 69
Return-To-Dig 70
4-In-1 Bucket 70
Clutch Cutout 71
Loose Material 72
Preparation for the Job 72
Filling the Bucket 73
Backhoe Operation 76
Safety When You Work 76
Stabilizer Pads 76
Backhoe Bucket Digging Positions 77
Before You Dig with the Backhoe 78
Moving the Backhoe Out of Transport Position 79
Digging with the Backhoe 80
Procedure to Move the Machine Forward When Trenching 85
Putting the Backhoe in the Transport Position 86
Lifting with the Backhoe 87
Digging Next to a Fence 89
Maintenance and Lubrication 90
Support Strut for Loader Lift Arms 91
Fluids and Lubricants Chart 92
Engine Oil Recommendation 93
Axle Oil Recommendations 93
Systemgard Lubricant Analysis Service 95
Run-In Period 96
Run-In Maintenance Schedule 96
Maintenance Schedule 97
Grease Fitting 100
Engine Lubrication System 105
Engine Cooling System 107
Air Cleaning System 109
Engine Fuel System 112
Batteries 115
Instrument Lamps and Warning Lamps 116
Hydraulic System 117
Transmission Hydraulic System 121
Rear Axle 123
Brake System 125
Replacing the Starting Fluid Container 128
Wheels and Tires 129
Front Wheel Bearings 131
Spark Arrester Muffler 133
Loader Return-To-Dig Adjustment 134
Air Compressor Drive Belt 135
Air Conditioner Drive Belt 136
Cab Service 137
Machine Storage 141
Seat Belts 142
Decals 143
Roll-Over Protective Structure (ROPS) 147
Specifications 152
Product Identification and Serial Numbers 162
Index 164
After Delivery Check 167

MidWestTech | Case 680K Loader Backhoe, 12 Volt and 24 Volt Electrical Systems Loader... Order the manual at mid-west-tech.com >