Illustrated Parts Manual

Model

TF6-42

SN 0192001 through 0192007
& 0160000052 to Present

91504001

Revised
September 29, 2017

An Oshkosh Corporation Company

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 11

FIGURE 1-1. FRAME SHROUDING AND TRIM (SN 0192001 through 0192007, SN 0160000052 through 0160006622, Excluding 0160000198 and 0160006286) 12
FIGURE 1-2. FRAME SHROUDING AND TRIM (SN 0160006707 to Present, Including 0160000198 and 0160006286) 16
FIGURE 1-3. AXLE MOUNTING (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 20
FIGURE 1-4. AXLE MOUNTING (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 22

SECTION 2 - BOOM 25

FIGURE 2-1. FIRST BOOM SECTION 26
FIGURE 2-2. BEARING PADS, SPACERS, AND SHIMS, (FIRST BOOM SECTION) 28
FIGURE 2-3. SECOND BOOM SECTION 30
FIGURE 2-4. BEARING PADS, SPACERS AND SHIMS, (SECOND BOOM SECTION) 32
FIGURE 2-5. THIRD BOOM SECTION 34
FIGURE 2-6. BEARING PADS, SPACERS AND SHIMS, (THIRD BOOM SECTION) 36
FIGURE 2-7. PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY 38
FIGURE 2-8. QUICK SWITCH ASSEMBLY 40

SECTION 3 - ATTACHMENTS 43

FIGURE 3-1. 48IN AND 72IN CARRIAGE ASSEMBLY 44
FIGURE 3-2. 50IN AND 72IN CARRIAGE ASSEMBLY 46
FIGURE 3-3. 60IN CARRIAGE ASSEMBLY 48
FIGURE 3-4. BUCKETS 50
FIGURE 3-5. 48IN AND 72IN SLOPE PILER CARRIAGE 52
FIGURE 3-6. 10FT AND 15FT TRUSS BOOM ASSEMBLY 54
FIGURE 3-7. 10FT AND 15FT TRUSS BOOM ASSEMBLY W/WINCH 56
FIGURE 3-8. 100,SWING FORK ASSEMBLY 58
FIGURE 3-9. DRYWALL CARRIAGE ASSEMBLY 62
FIGURE 3-10. 100, DRYWALL SWING CARRIAGE ASSEMBLY 64
FIGURE 3-11. PERSONNEL PLATFORM ASSEMBLY 68
FIGURE 3-12. TRANSFORMER PLATFORM 70
FIGURE 3-13. FORKS 74
FIGURE 3-14. FORK MOUNTED LIFTING HOOK (PRIOR TO SN 2005134-01) 76
FIGURE 3-15. FORK MOUNTED LIFTING HOOK (SN 2005134-01 TO PRESENT) 78
FIGURE 3-16. 6 FT MAST WITH 42 IN AND 72 IN CARRIAGE 80
FIGURE 3-17. 100, SWING CARRIAGE WITH SIDE SHIFT 82

SECTION 4 - ENGINE AND ATTACHING PARTS 87

FIGURE 4-1. ENGINE ASSEMBLY, L.H. VIEW (SN 0192001 through 0192007, SN 0160000052 through 0160002686) 88
FIGURE 4-2. ENGINE ASSEMBLY, L.H. VIEW (SN 0160003136 to Present) 92
FIGURE 4-3. ENGINE ASSEMBLY, R.H. VIEW (SN 0192001 through 0192007, SN 0160000052 through 0160002686) 96
FIGURE 4-4. ENGINE ASSEMBLY, R.H. VIEW (SN 0160003136 to Present) 98
FIGURE 4-5. DEERE ENGINE (SN 0192001 through 0192007, SN 0160000052 through 0160002686, Excluding 0160000198) 100
FIGURE 4-6. DEERE ENGINE (SN 0160003136 through 0160006622, Excluding 0160006286) 102
FIGURE 4-7. DEERE ENGINE (SN 0160006707 to Present, Including 0160000198 and 0160006286) 106
FIGURE 4-8. FUEL TANK AND LINES 110
FIGURE 4-9. RADIATOR ASSEMBLY (SN 0192001 through 0192007, SN 0160000052 through 0160002686) 112
FIGURE 4-10. RADIATOR ASSEMBLY (SN 0160003136 to Present) 114
FIGURE 4-11. AIR CLEANER AND INSTALLATION (SN 0192001 through 0192007, SN 0160000052 through 0160002686) 116
FIGURE 4-12. AIR CLEANER AND INSTALLATION (SN 0160003136 to Present) 118
FIGURE 4-13. EXHAUST INSTALLATION (SN 0192001 through 0192007, SN 0160000052 through 0160002686) 120
FIGURE 4-14. EXHAUST INSTALLATION (SN 0160003136 to Present) 122
FIGURE 4-15. TRANSMISSION - CONVERTER HOUSING GROUP 124
FIGURE 4-16. TRANSMISSION - TRANSMISSION CASE AND PLATE GROUP 126
FIGURE 4-17. TRANSMISSION - TORQUE CONVERTER GROUP 128
FIGURE 4-18. TRANSMISSION - GEAR GROUP THREE SPEED 130
FIGURE 4-19. TRANSMISSION - GEAR GROUP FOUR SPEED 132
FIGURE 4-20. TRANSMISSION - PUMP DRIVE GROUP 134
FIGURE 4-21. TRANSMISSION - CHARGING PUMP GROUP 136
FIGURE 4-22. TRANSMISSION - REVERSE IDLER GROUP 138

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 4-23. TRANSMISSION - FORWARD AND REVERSE SHAFT GROUP 140
FIGURE 4-24. TRANSMISSION - 3RD SHAFT GROUP THREE SPEED 142
FIGURE 4-25. TRANSMISSION - 3RD SHAFT GROUP FOUR SPEED 144
FIGURE 4-26. TRANSMISSION - FIRST AND SECOND SHAFT GROUP 146
FIGURE 4-27. TRANSMISSION - OUTPUT SHAFT GROUP 148
FIGURE 4-28. TRANSMISSION - ELECTRIC CONTROL GROUP THREE SPEED 150
FIGURE 4-29. TRANSMISSION - ELECTRIC CONTROL GROUP FOUR SPEED 152
FIGURE 4-30. TRANSMISSION - DRIVE PLATE GROUP 154
FIGURE 4-31. TRANSMISSION - DROP BOX GROUP 156

SECTION 5 - DRIVE TRAIN 159

FIGURE 5-1. FRONT AXLE ASSEMBLY - CARRARO (SN 0192001 through 01920007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 160
FIGURE 5-2. FRONT AXLE - CARRARO (SN 0192001 through 01920007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 162
FIGURE 5-3. FRONT AXLE HOUSING ASSEMBLY - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 164
FIGURE 5-4. FRONT STEERING COMPONENTS - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 166
FIGURE 5-5. FRONT GEAR COMPONENTS - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 168
FIGURE 5-6. FRONT DIFFERENTIAL - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 170
FIGURE 5-7. FRONT DOUBLE JOINT - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 172
FIGURE 5-8. FRONT BRAKES - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 174
FIGURE 5-9. FRONT WHEEL HUB - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 176
FIGURE 5-10. FRONT REDUCTION GEARS - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 178
FIGURE 5-11. REAR AXLE ASSEMBLY - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 180
FIGURE 5-12. REAR AXLE - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 182
FIGURE 5-13. REAR AXLE HOUSING - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 184
FIGURE 5-14. REAR STEERING COMPONENTS - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 186
FIGURE 5-15. REAR GEAR COMPONENTS - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 188
FIGURE 5-16. REAR DIFFERENTIAL - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 190
FIGURE 5-17. REAR DOUBLE JOINT - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 192
FIGURE 5-18. REAR WHEEL HUB - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 194
FIGURE 5-19. REAR REDUCTION GEARS - CARRARO (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 196
FIGURE 5-20. FRONT AXLE ASSEMBLY - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 198
FIGURE 5-21. FRONT AXLE - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 200
FIGURE 5-22. FRONT AXLE HOUSING ASSEMBLY - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 202
FIGURE 5-23. FRONT STEERING COMPONENTS - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 204
FIGURE 5-24. FRONT GEAR COMPONENTS - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 206
FIGURE 5-25. FRONT DIFFERENTIAL - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 208
FIGURE 5-26. FRONT DOUBLE JOINT - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 210
FIGURE 5-27. FRONT BRAKES - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 212

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J Order the manual at mid-west-tech.com >

FIGURE 5-28. FRONT WHEEL HUB - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 214
FIGURE 5-29. FRONT REDUCTION GEARS - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 216
FIGURE 5-30. REAR AXLE ASSEMBLY - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 218
FIGURE 5-31. REAR AXLE - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 220
FIGURE 5-32. REAR AXLE HOUSING ASSEMBLY - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 222
FIGURE 5-33. REAR STEERING COMPONENTS - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 224
FIGURE 5-34. REAR GEAR COMPONENTS - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 226
FIGURE 5-35. REAR DIFFERENTIAL - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 228
FIGURE 5-36. REAR DOUBLE JOINT - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 230
FIGURE 5-37. REAR BRAKES - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 232
FIGURE 5-38. REAR WHEEL HUB - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 234
FIGURE 5-39. REAR REDUCTION GEARS - DANA (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 236
FIGURE 5-40. DRIVE SHAFT ASSEMBLY (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 238
FIGURE 5-41. DRIVE SHAFT ASSEMBLY (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 240
FIGURE 5-42. TIRES AND RIMS 242

SECTION 6 - CAB 245

FIGURE 6-1. OPEN CAB 246
FIGURE 6-2. CAB ENCLOSURE W/HEATER OPTION (SN 0192001 through 0192007, SN 0160000052 through 0160013828) 248
FIGURE 6-3. CAB ENCLOSURE W/HEATER OPTION (SN 0160013983 to Present) 250
FIGURE 6-4. CAB ENCLOSURE 254
FIGURE 6-5. CAB ENCLOSURE 256
FIGURE 6-6. CAB 258
FIGURE 6-7. SUSPENSION SEAT (SN 0160013983 to Present) 260
FIGURE 6-8. INSTRUMENT PANEL 262

SECTION 7 - CONTROLS 265

FIGURE 7-1. ACCELERATOR PEDAL ASSEMBLY 266
FIGURE 7-2. STEERING COLUMN AND ATTACHING PARTS 268
FIGURE 7-3. BRAKE PEDAL ASSEMBLY (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 270
FIGURE 7-4. BRAKE PEDAL ASSEMBLY (SN 0160000170 through 0160017549, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 272
FIGURE 7-5. BRAKE PEDAL ASSEMBLY (SN 0160019117 to Present) 274
FIGURE 7-6. TRANSFORMER PLATFORM SWING AND LIFT CONTROLLER ASSEMBLY 276
FIGURE 7-7. TRANSFORMER PLATFORM DRIVE/STEER CONTROLLER ASSEMBLY (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 016000338 and 0160000718) 278
FIGURE 7-8. BOOM JOYSTICK (SN 0160000170 to Present, Excluding 0160000198, 0160000206, 0160000338 and 0160000718) 280
FIGURE 7-9. BOOM JOYSTICK 282
FIGURE 7-10. R.H. TILT/SWAY JOYSTICK 284
FIGURE 7-11. L.H. AUXILIARY JOYSTICK 286

SECTION 8 - HYDRAULIC CIRCUITS 289

FIGURE 8-1. SUPPLY CIRCUIT 290
FIGURE 8-2. DUMP CIRCUIT 292
FIGURE 8-3. STEER SELECT 296
FIGURE 8-4. SERVICE/PARKING BRAKE (SN 0192001 through 0192007, SN 0160000052 through 0160000157, Including 0160000198, 0160000206, 0160000338 and 0160000718) 298

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J Order the manual at mid-west-tech.com >

FIGURE 3-12. TRANSFORMER PLATFORM

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	91503055	1	TRANSFORMER PLATFORM, (includes all items except items 52 thru 58)	F
1	4712000	12	WASHER, 5/8	
2	0642010	14	HEX HD CAPSCREW, 5/8-11X1-1/4	
3	4846265	2	GATE WELDMENT	
4	2940074	2	LATCH	
5	2600216	4	HINGE	
6	2080064	5	NYLON LOCKNUT, 5/16-18	
7	4711500	8	WASHER, 5/16	
8	0641524	4	HEX HD CAPSCREW, 5/16-18X3	
9	3911428	20	ROUND HEAD CAPSCREW, 1/4-20X1-3/4	
10	4711400	20	WASHER, 1/4	
11	2080063	20	NYLON LOCKNUT, 1/4-20	
12	3539685	2	LATCH PLATE	
13	3911008	8	ROUND HEAD SCREW	
14	4751000	8	WASHER, #10	
15	4761000	8	LOCKWASHER, #10	
16	3311001	8	HEX NUT, #10-24	
17	4846541	1	BASKET SUPPORT WELD	
18	4846342	1	QUICK SWITCH WELD	
19	4711600	4	WASHER, 3/8	
20	3311601	8	HEX LOCKNUT, 3/8-16	
21	3573157	1	VALVE MOUNT PLATE	
22	0641422	2	HEX HD CAPSCREW, 1/4-20X2-3/4	
23	4711400	2	WASHER, 1/4	
24		Ref	DOUBLE PILOTCHECK VALVE, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
25	3311405	7	HEX LOCKNUT, 1/4-20	
26	3841258	2	KEEPER, 5/8	
27	3422967	2	HITCH-PIVOT PIN	
28	0962036	2	COMPOSITE BUSHING	
29	4740256	2	THRUST WASHER	
30	0641610	4	HEX HD CAPSCREW, 3/8-16X1-1/4	
31	3422995	2	ROTATE PIN	
32	3841143	2	KEEPER, 3/8	
33	4846358	2	BEARING CAP	
34		Ref	ROTATE CYLINDER, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
35	0961621	4	ALUMINUM BRONZE BUSHING	
36	4740307	4	THRUST WASHER	
37		Ref	PLATFORM CONTROL BOX ASSY, (See ELECTRICAL SECTION for Breakdown)	
38	3380434	1	DECAL MOUNT PANEL	
39	0860520	1	MANUAL STORAGE BOX	
40	1060279	1	LANYARD CABLE	
41	4751400	6	WASHER, 1/4	
42	0641408	1	HEX HD CAPSCREW, 1/4-20X1	
43	1580012	1	STORAGE TRAY CONTAINER	
44	4751500	6	WASHER, 5/16	
45	0641516	3	HEX HD CAPSCREW, 5/16-18X2	

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
50	4460790	2	TERMINAL	
51	4460789	1	SEAL	
52	80963067	2	SEAL	
53	80963060	1	SHROUD	
54	80963070	1	PLUG, DUST CAP	
55	8220524	1	CONNECTOR	
56	8220525	1	WEDGELOCK	
57	4460942	1	SOCKET	
58	77363229	6	CONTACT	
59	4460466	1	PLUG	
60	4460613	1	CONNECTOR	
61	83481286	1	NUT	
62	83481285	1	LOCKWASHER	
63	77363228	16	TERMINAL	
64	77363345	2	CONTACT	
65	4460466	3	PLUG	
66	91504105	1	BOOT	
67	4460938	1	CONNECTOR	
68	83481286	1	NUT	
69	83481285	1	LOCKWASHER	
70	77363229	16	CONTACT	
71	77363347	2	CONTACT	
72	4460466	3	PLUG	
73	91504105	1	BOOT	
74	80963057	1	CONNECTOR	
75	80963068	2	TERMINAL	
76	4460789	2	SEAL	
77	80963057	1	CONNECTOR	
78	80963068	2	TERMINAL	
79	4460789	2	SEAL	
80	80963057	1	CONNECTOR	
81	80963068	2	TERMINAL	
82	4460789	2	SEAL	
83	80963057	1	CONNECTOR	
84	80963068	2	TERMINAL	
85	4460789	2	SEAL	
86	80963057	1	CONNECTOR	
87	80963068	2	TERMINAL	
88	4460789	2	SEAL	
89	80963057	1	CONNECTOR	
90	80963068	2	TERMINAL	
91	4460789	2	SEAL	
92	80963057	1	CONNECTOR	
93	80963068	2	TERMINAL	
94	4460789	2	SEAL	
95	80963057	1	CONNECTOR	
96	80963068	2	TERMINAL	
97	4460789	2	SEAL	
98	80963057	1	CONNECTOR	
99	80963068	2	TERMINAL	
100	4460789	2	SEAL	

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	91404257	1	GASKET, VALVE COVER	
	91404258	1	FILLER CAP, VALVE COVER	

MidWestTech | JLG TF6-42 Telehandler Parts Manual | Publication 91504001_Rev_J Order the manual at mid-west-tech.com >