Illustrated Parts Manual

Models

G9-43A

G10-43A

SN 0193001 through 0193007
& 0160000008 through
0160048670 including
0160048773

91514001

Revised
September 6, 2017

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 13

FIGURE 1-1. FRAME SHROUDING AND TRIM (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 14
FIGURE 1-2. FRAME SHROUDING AND TRIM (SN 0160040675 to Present, Including 0160040468 and 0160040672) 20
FIGURE 1-3. AXLE MOUNTING 26
FIGURE 1-4. OUTRIGGER MOUNTING G10-43A 28

SECTION 2 - BOOM 31

FIGURE 2-1. FIRST BOOM SECTION 32
FIGURE 2-2. BEARING PADS, SPACERS AND SHIMS, (FIRST BOOM SECTION) 34
FIGURE 2-3. SECOND BOOM SECTION 36
FIGURE 2-4. BEARING PADS, SPACERS AND SHIMS, (SECOND BOOM SECTION) 38
FIGURE 2-5. THIRD BOOM SECTION 40
FIGURE 2-6. BEARING PADS, SPACERS AND SHIMS, (THIRD BOOM SECTION) 42
FIGURE 2-7. PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY (Prior to SN 0160037671) 44
FIGURE 2-8. PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY (SN 0160037671 to Present) 46
FIGURE 2-9. MANUAL QUICK SWITCH ASSEMBLY (Prior to SN 0160037671) 48
FIGURE 2-10. MANUAL QUICK SWITCH ASSEMBLY (SN 0160037671 to Present) 50

SECTION 3 - ATTACHMENTS 53

FIGURE 3-1. TILT CARRIAGE (Prior to SN 0160028566) 54
FIGURE 3-2. TILT CARRIAGE (SN 0160028566 to Present) 56
FIGURE 3-3. BUCKETS 60
FIGURE 3-4. SIDE TILT CARRIAGE (Prior to SN 0160037671) 62
FIGURE 3-5. SIDE TILT CARRIAGE (SN 0160037671 to Present) 64
FIGURE 3-6. TRUSS BOOM (Prior to SN 0160037671) 66
FIGURE 3-7. TRUSS BOOM (SN 0160037671 to Present) 68
FIGURE 3-8. TRUSS BOOM WITH WINCH (Prior to SN 0160037671) 70
FIGURE 3-9. TRUSS BOOM WITH WINCH (SN 0160037671 to Present) 72
FIGURE 3-10. ADJUSTABLE TRUSS BOOM 74
FIGURE 3-11. SWING CARRIAGE (Prior to SN 0160037671) 76
FIGURE 3-12. SWING CARRIAGE (SN 0160037671 to Present) 80
FIGURE 3-13. SHEET MATERIAL HANDLER (Prior to SN 0160037671) 82
FIGURE 3-14. SHEET MATERIAL HANDLER (SN 0160037671 to Present) 84
FIGURE 3-15. WINCH INSTALLATION 86
FIGURE 3-16. 100, DRYWALL SWING CARRIAGE ASSEMBLY (Prior to SN 0160037671) 88
FIGURE 3-17. PERSONNEL PLATFORM (Prior to SN 0160037671) 92
FIGURE 3-18. FORK MOUNTED PLATFORM 94
FIGURE 3-19. 100, SWING CARRIAGE WITH SIDE SHIFT (Prior to SN 0160037671) 98
FIGURE 3-20. FORKS 102
FIGURE 3-21. FORK MOUNTED LIFTING HOOK PRIOR TO SN 2005134-01 104
FIGURE 3-22. FORK MOUNTED LIFTING HOOK SN 2005134-01 TO PRESENT 106
FIGURE 3-23. GRAPPLE BUCKET 108
FIGURE 3-24. FORK PIN LOCK INSTALLATION (SN 0160037671 to Present) 110
FIGURE 3-25. DUAL FORK POSITIONING CARRIAGE ASSEMBLY (SN 0160037671 to Present) 112
FIGURE 3-26. 6 FT MAST WITH 72 IN CARRIAGE (Prior to SN 0160037671) 114
FIGURE 3-27. 8 FT STANDARD MAST (SN 0160037671 to Present) 116
FIGURE 3-28. 8 FT SIDE TILT ELECTRIC MAST (SN 0160037671 to Present) 120
FIGURE 3-29. 50 IN SIDE SHIFT CARRIAGE (SN 0160037671 to Present) 126

SECTION 4 - ENGINE AND ATTACHING PARTS 129

FIGURE 4-1. ENGINE ASSEMBLY, LH VIEW - JOHN DEERE ENGINE (SN 0193001 through 0193007, SN 0160000008 through 0160003121, Excluding 0160002658) 130
FIGURE 4-2. ENGINE ASSEMBLY, LH VIEW - JOHN DEERE ENGINE (SN 0160003210 through 0160040674, Including 0160002658, Excluding 0160040468 and 0160040672) 134
FIGURE 4-3. ENGINE ASSEMBLY, RH VIEW - JOHN DEERE ENGINE (SN 0193001 through 0193007, SN 0160000008 through 0160003121, Excluding 0160002658) 138
FIGURE 4-4. ENGINE ASSEMBLY, RH VIEW - JOHN DEERE ENGINE (SN 0160003210 through 0160040674, Including 0160002658, Excluding 0160040468 and 0160040672) 140
FIGURE 4-5. ENGINE ASSEMBLY - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 142
FIGURE 4-6. ENGINE ASSEMBLY - CUMMINS (SN 0160040675 to Present, Including 0160040468 and 0160040672) 146

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 4-7. DEERE ENGINE (SN 0193001 through 0193007, SN 0160000008 through 0160003121, Excluding 0160002658) 150
FIGURE 4-8. DEERE ENGINE (SN 0160003210 through 0160006663, Including 0160002658, Excluding 0160006594, 0160006599, 0160006617 and 0160006621) 154
FIGURE 4-9. DEERE ENGINE (SN 0160006686 through 0160040674, Including 0160006594, 0160006599, 0160006617 and 0160006621, Excluding 0160040468 and 0160040672) 158
FIGURE 4-10. PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 162
FIGURE 4-11. CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 164
FIGURE 4-12. FUEL TANK AND LINES (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 166
FIGURE 4-13. FUEL TANK AND LINES (SN 0160040675 to Present, Including 0160040468 and 0160040672) 170
FIGURE 4-14. RADIATOR ASSEMBLY - JOHN DEERE ENGINE (SN 019001 through 0193007, SN 0160000008 through 0160000240) 172
FIGURE 4-15. RADIATOR ASSEMBLY - JOHN DEERE ENGINE (SN 0160000246 through 0160040674, Excluding 0160040468 and 0160040672) 174
FIGURE 4-16. RADIATOR ASSEMBLY - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 176
FIGURE 4-17. RADIATOR ASSEMBLY - CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 178
FIGURE 4-18. AIR CLEANER AND INSTALLATION - JOHN DEERE ENGINE (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 182
FIGURE 4-19. AIR CLEANER AND INSTALLATION - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 184
FIGURE 4-20. AIR CLEANER AND INSTALLATION - CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 186
FIGURE 4-21. EXHAUST INSTALLATION - JOHN DEERE ENGINE (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 188
FIGURE 4-22. EXHAUST INSTALLATION - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 190
FIGURE 4-23. EXHAUST INSTALLATION - CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 192
FIGURE 4-24. DANA TRANSMISSION - CONVERTER HOUSING GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 194
FIGURE 4-25. DANA TRANSMISSION - CASE AND PLATE GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 196
FIGURE 4-26. DANA TRANSMISSION - TORQUE CONVERTER GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 198
FIGURE 4-27. DANA TRANSMISSION - GEAR GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 200
FIGURE 4-28. DANA TRANSMISSION - PUMP DRIVE GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 202
FIGURE 4-29. DANA TRANSMISSION - CHARGING PUMP GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 204
FIGURE 4-30. DANA TRANSMISSION - REVERSE IDLER GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 206
FIGURE 4-31. DANATRANSMISSION - FORWARD AND REVERSE SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 208
FIGURE 4-32. DANA TRANSMISSION - 3RD SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 210
FIGURE 4-33. DANA TRANSMISSION - FIRST AND SECOND SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 212
FIGURE 4-34. DANA TRANSMISSION - OUTPUT SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 214
FIGURE 4-35. DANA TRANSMISSION - ELECTRIC CONTROL GROUP (SN 0193001 through 0193007, SN 0160000008 through 0160011036) 216
FIGURE 4-36. DANA TRANSMISSION - ELECTRIC CONTROL GROUP (SN 0160011061 through 0160040675, Excluding 0160040468 and 0160040672) 218
FIGURE 4-37. DANA TRANSMISSION - DRIVE PLATE GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 220
FIGURE 4-38. DANA TRANSMISSION - DROP BOX GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 222
FIGURE 4-39. ZF TRANSMISSION (SN 0160040675 to Present, Including 0160040468 and 0160040672) 224
FIGURE 4-40. ZF TRANSMISSION - TRANSMISSION CONVERTER AND INPUT (SN 0160040675 to Present, Including 0160040468 and 0160040672) 226
FIGURE 4-41. ZF TRANSMISSION - GEARBOX HOUSING (SN 0160040675 to Present, Including 0160040468 and 0160040672) 228

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001 Order the manual at mid-west-tech.com >

FIGURE 4-42. ZF TRANSMISSION - REVERSING GEAR (SN 0160040675 to Present, Including 0160040468 and 0160040672) 230
FIGURE 4-43. ZF TRANSMISSION - REVERSE GEAR GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 232
FIGURE 4-44. ZF TRANSMISSION - 1ST SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 234
FIGURE 4-45. ZF TRANSMISSION - 2ND SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 236
FIGURE 4-46. ZF TRANSMISSION - 3RD SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 238
FIGURE 4-47. ZF TRANSMISSION - 4TH SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 240
FIGURE 4-48. ZF TRANSMISSION - POWER TAKE-OFF (SN 0160040675 to Present, Including 0160040468 and 0160040672) 242
FIGURE 4-49. ZF TRANSMISSION - CONTROL UNIT AND PRESSURE REGULATOR (SN 0160040675 to Present, Including 0160040468 and 0160040672) 244
FIGURE 4-50. ZF TRANSMISSION - GEARSHIFT SYSTEM (SN 0160040675 to Present, Including 0160040468 and 0160040672) 246
FIGURE 4-51. ZF TRANSMISSION - OIL PUMP, FILTER AND DIPSTICK (SN 0160040675 to Present, Including 0160040468 and 0160040672) 248
FIGURE 4-52. ZF TRANSMISSION - TRANSFER BOX (SN 0160040675 to Present, Including 0160040468 and 0160040672) 250
FIGURE 4-53. AIR CLEANER INSTALLATION 252
FIGURE 4-54. AIR CLEANER INSTALLATION 254

SECTION 5 - DRIVE TRAIN 257

FIGURE 5-1. FRONT AXLE ASSEMBLY 258
FIGURE 5-2. FRONT AXLE (Prior to SN 0160048624) 260
FIGURE 5-3. FRONT AXLE HOUSING ASSEMBLY (Prior to SN 0160048624) 262
FIGURE 5-4. FRONT STEERING COMPONENTS (Prior to SN 0160048624) 264
FIGURE 5-5. FRONT GEAR COMPONENTS (Prior to SN 0160048624) 266
FIGURE 5-6. FRONT DIFFERENTIAL (Prior to SN 0160048624) 268
FIGURE 5-7. FRONT DOUBLE JOINT (Prior to SN 0160048624) 270
FIGURE 5-8. FRONT BRAKES (Prior to SN 0160048624) 272
FIGURE 5-9. FRONT WHEEL HUB (Prior to SN 0160048624) 274
FIGURE 5-10. FRONT REDUCTION GEARS (Prior to SN 0160048624) 276
FIGURE 5-11. FRONT AXLE (SN 0160048624 to Present) 278
FIGURE 5-12. CENTRAL HOUSING AND STEERING (SN 0160048624 to Present) 280
FIGURE 5-13. DIFFERENTIAL (SN 0160048624 to Present) 282
FIGURE 5-14. HUB REDUCTION (SN 0160048624 to Present) 284
FIGURE 5-15. BRAKES (SN 0160048624 to Present) 288
FIGURE 5-16. REAR AXLE ASSEMBLY 290
FIGURE 5-17. REAR AXLE 292
FIGURE 5-18. REAR AXLE HOUSING ASSEMBLY (Prior to SN 0160048624) 294
FIGURE 5-19. REAR STEERING COMPONENTS (Prior to SN 0160048624) 296
FIGURE 5-20. REAR GEAR COMPONENTS (Prior to SN 0160048624) 298
FIGURE 5-21. REAR DIFFERENTIAL (Prior to SN 0160048624) 300
FIGURE 5-22. REAR DOUBLE JOINT (Prior to SN 0160048624) 302
FIGURE 5-23. REAR BRAKES (Prior to SN 0160035189, Excluding 0160035166) 304
FIGURE 5-24. REAR BRAKES (SN 0160035189 through 0160048624, Including 0160035166) 306
FIGURE 5-25. REAR WHEEL HUB (Prior to SN 0160048624) 308
FIGURE 5-26. REAR REDUCTION GEARS (Prior to SN 0160048624) 310
FIGURE 5-27. REAR AXLE (SN 0160048624 to Present) 312
FIGURE 5-28. CENTRAL HOUSING AND STEERING (SN 0160048624 to Present) 314
FIGURE 5-29. DIFFERENTIAL (SN 0160048624 to Present) 316
FIGURE 5-30. HUB REDUCTION (SN 0160048624 to Present) 318
FIGURE 5-31. BRAKES (SN 0160048624 to Present) 322
FIGURE 5-32. DRIVE SHAFT ASSEMBLY 324
FIGURE 5-33. TIRES AND RIMS G9-43A 326
FIGURE 5-34. TIRES AND RIMS G10-43A 330

SECTION 6 - CAB 333

FIGURE 6-1. OPEN CAB 334
FIGURE 6-2. CAB ENCLOSURES 336
FIGURE 6-3. CAB COMPONENTS 340

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001 Order the manual at mid-west-tech.com >

FIGURE 2-3. SECOND BOOM SECTION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1	91516010	1	SECOND BOOM SECTION **(Prior to SN 0160037671)**	
1	1001102967	1	SECOND BOOM SECTION **(SN 0160037671 to Present)**	
2	91141128	2	PUSH BEAM PIN	
3	0641832	2	HEX HD CAPSCREW, 1/2-13X4	
4	4761600	2	LOCKWASHER, 1/2	
5	91515002	1	HOSE RETAINER, (includes the following items)	
5	91511050	1	LH HOSE RETAINER	
5	91513026	1	PAD	
5	88241023	4	SOCKET FLAT HD CAPSCREW, #10-24X5/8	
5	88501612	4	HEX NUT, #10-24	
6	91513013	1	RETRACTION SHEAVE PIN **(Prior to SN 0160037671)**	
6	91513110	1	RETRACTION SHEAVE PIN **(SN 0160037671 to Present)**	
7	88671001	1	LUBE FITTING, STRAIGHT, 1/8	
8	90028932	1	RETAINING RING	
9	91513035	1	LEAF CHAIN 834	
10	91513177	2	CHAIN PIN	
11	88581112	4	COTTER PIN, 1/16X3/4	
12	1360294	1	CHAIN ANCHOR	
13		Ref	ANCHOR PLATE, (See FIRST BOOM SECTION, item 13 for Breakdown)	
14		Ref	THIRD BOOM SECTION, (See THIRD BOOM SECTION for Breakdown)	
15		Ref	EXTENSION CHAIN 1066, (See PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY, item 1 for Breakdown)	
16		Ref	CLEVIS 1066-834, (See PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY, item 8 for Breakdown)	
17	88551011	1	LOCKWASHER, 3/8 **(Prior to SN 0160037671)**	
17	4761600	1	LOCKWASHER, 3/8 **(SN 0160037671 through 0160040674, Excluding 0160040468 and 0160040672)**	
18	0641634	1	HEX HD CAPSCREW, 3/8-16X4-1/4, GR5	
19	91403126	AR	THRUST WASHER	
19	91403127	AR	THRUST WASHER	
20	91403053	2	SEAL	
21	91513242	1	RETRACT ROLLER ASSY, (includes items 20 & 22)	
22	91513011	1	BUSHING	
23	3580346	1	HOSE SHEAVE	

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001 Order the manual at mid-west-tech.com >

FIGURE 4-12. FUEL TANK AND LINES (Prior to SN 0160040675, Excluding 0160040468 and 0160040672)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	91405042	Ref	FUEL TANK ASSY, (not available to order, see items 4 thru 9, 15, 20 & 22 for service) **(Prior to SN 0160020150)**	K
	4400496	Ref	FUEL TANK ASSY, (not available to order, see items 103, 107, 108, 115 & 120 for service) **(SN 0160020150 to Present)**	E
1	77143003	4	WHIZ-LOCK BOLT, 5/16-18X5/8	
2		Ref	FUEL LINE, 5/16 ID, (See ENGINE ASSEMBLY, LH VIEW - JOHN DEERE ENGINE or ENGINE ASSEMBLY, RH VIEW - JOHN DEERE ENGINE for Breakdown)	
3	91403254	1	FUEL SENDER COVER	
4	88261014	4	SOCKET BUTTON HD CAPSCREW, 1/4-20X1/2	
5	91403513	Ref	FUEL TANK CAP WITH CHAIN, (non-locking)	
5	91403514	1	LOCKING FUEL TANK CAP, (optional), (includes key)	
5	91404443	1	KEY	
6	91403524	1	FILLER NECK	
7	91403609	1	FUEL LEVEL SENDER, (gaskets included)	
8	88301191	5	ROUND HD MACHINE SCREW, #10-32X3/8	
9	91401581	1	JUMPER WIRE **(Prior to SN 0160002036)**	
10	88201036	3	HEX HD CAPSCREW, 3/8-16X1-1/4, GR5	
11	88561004	5	FLAT WASHER, 3/8	
12	88551011	5	LOCKWASHER, 3/8	
13	91401198	NLA	FUEL TANK HOLD DOWN, (no longer available, use 1001150364 for replacement)	
13	1001150364	3	BRACKET, TANK FUEL HOLD	
14	86883106	2	HOSE CLAMP	
15	91403176	1	FUEL TANK, (includes items 16, 17 & 21)	
16	88711283	1	HEX SOCKET PIPE PLUG, 1/2	
17	1001113251	2	ELBOW, 90	
18	88201035	2	HEX HD CAPSCREW, 3/8-16X1, GR5	
19	91416014	1	FUEL TANK STRAP WELDMENT	
20	91403437	1	FUEL GAUGE HARNESS, (jumper wire included) **(SN 0160002036 to Present)**	
21	91404068	2	PICK-UP TUBE, 6IN	
22	3960616	1	GASKET, FILLER NECK	
23	91511215	1	FUEL TANK STRAP, (not shown) **(Prior to SN 0160033655)**	
102		Ref	FUEL LINE, (See ENGINE ASSEMBLY, RH VIEW - JOHN DEERE ENGINE or ENGINE ASSEMBLY - PERKINS ENGINE for Breakdown)	
103	1671313	1	FUEL SENDER COVER	
105	1120590	NLA	FUEL CAP, (non-locking), (no longer available, order 1001093641)	
105	1001093641	1	FUEL CAP, (non-locking)	
105	2902446	NLA	FUEL CAP ADAPTER KIT, LOCKING, (no longer available, order 1001102657 or see items 301 thru 304 for service)	
105	1001102657	1	FUEL CAP, LOCKING, (includes items 401 thru 403), (padlock not included)	
107	1001093388	NLA	FUEL LEVEL SENDER (no longer available, use 1001148837 for replacement)	
107	1001148837	1	FUEL LEVEL SENDER, (gaskets included)	
108	88302192	5	ROUND HD MACHINE SCREW, #10-32X3/8	
110	88201036	3	HEX HD CAPSCREW, 3/8-16X1-1/4, GR5	
111	88561004	3	FLAT WASHER, 3/8	

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001 Order the manual at mid-west-tech.com >

FIGURE 11-4. CAB AND FRAME DECALS (SN 0160040675 to Present, Including 0160040468 and 0160040672)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001115110	Ref	DECAL INSTALLATION, (G9-43A), (ANSI), (not available to order, see items 2 thru 33, 38, 39, 40 See CAB AND FRAME DECALS and items 1, 7, 22, 24, 27 & 34 thru 37 See BOOM DECALS)	C, 5
	1001115111	Ref	DECAL INSTALLATION, (G9-43A), (ISO), (not available to order, see items 2 thru 33, 38, 39, 40 See CAB AND FRAME DECALS and items 1, 7, 22, 24, 27 & 34 thru 37 See BOOM DECALS)	D, 5
	1001163581	Ref	DECAL INSTALLATION, (G9-43A), (FRENCH), (not available to order, see items 2 thru 26, 31, 32, 33, 40 thru 44 & See CAB AND FRAME DECALS and items 1, 7, 22, 24 & 34 thru 37 See BOOM DECALS)	B
	1001115112	Ref	DECAL INSTALLATION, (G10-43A), (ANSI), (not available to order, see items 2 thru 33, 38, 39, 40 & 401 See CAB AND FRAME DECALS and items 1, 7, 22, 24, 27 & 34 thru 37 See BOOM DECALS)	C, 5
	1001115113	Ref	DECAL INSTALLATION, (G10-43A), (ISO), (not available to order, see items 2 thru 33, 38, 39, 40 & 401 See CAB AND FRAME DECALS and items 1, 7, 22, 24, 27 & 34 thru 37 See BOOM DECALS)	D, 5
	1001163582	Ref	DECAL INSTALLATION, (G10-43A), (FRENCH), (not available to order, see items 2 thru 26, 31, 32, 33, 40 thru 44 & See CAB AND FRAME DECALS and items 1, 7, 22, 24 & 34 thru 37 See BOOM DECALS)	B
2	1706296	1	BATTERY DECAL, (ANSI)	
2	1706281	1	BATTERY DECAL, (ISO)	
2	1001163174	1	BATTERY DECAL, (FRENCH)	
3	1706301	1	ROTATING PARTS DECAL, (ANSI)	
3	1706285	1	ROTATING PARTS DECAL, (ISO)	
3	1001163222	1	ROTATING PARTS DECAL, (FRENCH)	
4	1001130782	1	LUBRICATION CHART DECAL, (G9-43A)	
4	1001130792	1	LUBRICATION CHART DECAL, (G10-43A)	
5	1001130802	1	MAINTENANCE CHART DECAL	
6	1706851	1	DO NOT JUMP WARNING DECAL, (ANSI)	
6	1706283	1	DO NOT JUMP WARNING DECAL, (ISO)	
6	1001163321	1	DO NOT JUMP WARNING DECAL, (FRENCH)	
8	1706304	1	RUN OVER DECAL, (ANSI)	
8	1706293	1	RUN OVER DECAL, (ISO)	
8	1001163276	1	RUN OVER DECAL, (FRENCH)	
9	1706303	1	READ MANUAL DECAL, (ANSI)	
9	1706287	1	READ MANUAL DECAL, (ISO)	
9	1001163273	1	READ MANUAL DECAL, (FRENCH)	
10	1706767	1	MACHINE ROLL DECAL, (ANSI)	
10	1706289	1	MACHINE ROLL DECAL, (ISO)	
10	1001163291	1	MACHINE ROLL DECAL, (FRENCH)	
11	4109801	4	TIE-DOWN DECAL	
11	1702300	4	TIE-DOWN DECAL, (FRENCH)	
12	1706306	1	TIP OVER DECAL, (ANSI)	
12	1706288	1	TIP OVER DECAL, (ISO)	
12	1001163285	1	TIP OVER DECAL, (FRENCH)	
13	1706299	1	ELECTROCUTION HAZARD DECAL, (ANSI)	
13	1706284	1	ELECTROCUTION HAZARD DECAL, (ISO)	
13	1001163210	1	ELECTROCUTION HAZARD DECAL, (FRENCH)	

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001 Order the manual at mid-west-tech.com >