Illustrated Parts Manual

Models

G9-43A

G10-43A

SN 0193001 through 0193007
& 0160000008 through
0160048670 including
0160048773

91514001

Revised
February 22, 2016

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 13

FIGURE 1-1. FRAME SHROUDING AND TRIM (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 14
FIGURE 1-2. FRAME SHROUDING AND TRIM (SN 0160040675 to Present, Including 0160040468 and 0160040672) 20
FIGURE 1-3. AXLE MOUNTING 26
FIGURE 1-4. OUTRIGGER MOUNTING 28

SECTION 2 - BOOM 31

FIGURE 2-1. FIRST BOOM SECTION 32
FIGURE 2-2. BEARING PADS, SPACERS AND SHIMS, (FIRST BOOM SECTION) 34
FIGURE 2-3. SECOND BOOM SECTION 36
FIGURE 2-4. BEARING PADS, SPACERS AND SHIMS, (SECOND BOOM SECTION) 38
FIGURE 2-5. THIRD BOOM SECTION 40
FIGURE 2-6. BEARING PADS, SPACERS AND SHIMS, (THIRD BOOM SECTION) 42
FIGURE 2-7. PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY (Prior to SN 0160037671) 44
FIGURE 2-8. PUSH BEAM/EXTEND CHAIN AND ROLLER ASSEMBLY (SN 0160037671 to Present) 46
FIGURE 2-9. MANUAL QUICK SWITCH ASSEMBLY (Prior to SN 0160037671) 48
FIGURE 2-10. MANUAL QUICK SWITCH ASSEMBLY (SN 0160037671 to Present) 50

SECTION 3 - ATTACHMENTS 53

FIGURE 3-1. TILT CARRIAGE (Prior to SN 0160028566) 54
FIGURE 3-2. TILT CARRIAGE (SN 0160028566 to Present) 56
FIGURE 3-3. BUCKETS 58
FIGURE 3-4. SIDE TILT CARRIAGE (Prior to SN 0160037671) 60
FIGURE 3-5. SIDE TILT CARRIAGE (SN 0160037671 to Present) 62
FIGURE 3-6. TRUSS BOOM (Prior to SN 0160037671) 64
FIGURE 3-7. TRUSS BOOM (SN 0160037671 to Present) 66
FIGURE 3-8. TRUSS BOOM WITH WINCH (Prior to SN 0160037671) 68
FIGURE 3-9. TRUSS BOOM WITH WINCH (SN 0160037671 to Present) 70
FIGURE 3-10. SWING CARRIAGE (Prior to SN 0160037671) 72
FIGURE 3-11. SWING CARRIAGE (SN 0160037671 to Present) 76
FIGURE 3-12. SHEET MATERIAL HANDLER (Prior to SN 0160037671) 78
FIGURE 3-13. SHEET MATERIAL HANDLER (SN 0160037671 to Present) 80
FIGURE 3-14. WINCH INSTALLATION 82
FIGURE 3-15. 100, DRYWALL SWING CARRIAGE ASSEMBLY (Prior to SN 0160037671) 84
FIGURE 3-16. PERSONNEL PLATFORM (Prior to SN 0160037671) 88
FIGURE 3-17. FORK MOUNTED PLATFORM 90
FIGURE 3-18. 100, SWING CARRIAGE WITH SIDE SHIFT (Prior to SN 0160037671) 94
FIGURE 3-19. FORKS 98
FIGURE 3-20. FORK MOUNTED LIFTING HOOK PRIOR TO SN 2005134-01 100
FIGURE 3-21. FORK MOUNTED LIFTING HOOK SN 2005134-01 TO PRESENT 102
FIGURE 3-22. GRAPPLE BUCKET 104
FIGURE 3-23. FORK PIN LOCK INSTALLATION (SN 0160037671 to Present) 106
FIGURE 3-24. DUAL FORK POSITIONING CARRIAGE ASSEMBLY (SN 0160037671 to Present) 108
FIGURE 3-25. 6 FT MAST WITH 72 IN CARRIAGE (Prior to SN 0160037671) 110
FIGURE 3-26. 8 FT STANDARD MAST (SN 0160037671 to Present) 112
FIGURE 3-27. 8 FT SIDE TILT ELECTRIC MAST (SN 0160037671 to Present) 116
FIGURE 3-28. 50 IN SIDE SHIFT CARRIAGE (SN 0160037671 to Present) 122

SECTION 4 - ENGINE AND ATTACHING PARTS 125

FIGURE 4-1. ENGINE ASSEMBLY, LH VIEW - JOHN DEERE ENGINE (SN 0193001 through 0193007, SN 0160000008 through 0160003121, Excluding 0160002658) 126
FIGURE 4-2. ENGINE ASSEMBLY, LH VIEW - JOHN DEERE ENGINE (SN 0160003210 through 0160040674, Including 0160002658, Excluding 0160040468 and 0160040672) 130
FIGURE 4-3. ENGINE ASSEMBLY, RH VIEW - JOHN DEERE ENGINE (SN 0193001 through 0193007, SN 0160000008 through 0160003121, Excluding 0160002658) 134
FIGURE 4-4. ENGINE ASSEMBLY, RH VIEW - JOHN DEERE ENGINE (SN 0160003210 through 0160040674, Including 0160002658, Excluding 0160040468 and 0160040672) 136
FIGURE 4-5. ENGINE ASSEMBLY - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 138
FIGURE 4-6. ENGINE ASSEMBLY - CUMMINS (SN 0160040675 to Present, Including 0160040468 and 0160040672) 142
FIGURE 4-7. DEERE ENGINE (SN 0193001 through 0193007, SN 0160000008 through 0160003121, Excluding 0160002658) 146

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001_R... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 4-8. DEERE ENGINE (SN 0160003210 through 0160006663, Including 0160002658, Excluding 0160006594, 0160006599, 0160006617 and 0160006621) 150
FIGURE 4-9. DEERE ENGINE (SN 0160006686 through 0160040674, Including 0160006594, 0160006599, 0160006617 and 0160006621, Excluding 0160040468 and 0160040672) 154
FIGURE 4-10. PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 158
FIGURE 4-11. CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 160
FIGURE 4-12. FUEL TANK AND LINES (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 162
FIGURE 4-13. FUEL TANK AND LINES (SN 0160040675 to Present, Including 0160040468 and 0160040672) 166
FIGURE 4-14. RADIATOR ASSEMBLY - JOHN DEERE ENGINE (SN 019001 through 0193007, SN 0160000008 through 0160000240) 168
FIGURE 4-15. RADIATOR ASSEMBLY - JOHN DEERE ENGINE (SN 0160000246 through 0160040674, Excluding 0160040468 and 0160040672) 170
FIGURE 4-16. RADIATOR ASSEMBLY - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 172
FIGURE 4-17. RADIATOR ASSEMBLY - CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 174
FIGURE 4-18. AIR CLEANER AND INSTALLATION - JOHN DEERE ENGINE (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 178
FIGURE 4-19. AIR CLEANER AND INSTALLATION - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 180
FIGURE 4-20. AIR CLEANER AND INSTALLATION - CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 182
FIGURE 4-21. EXHAUST INSTALLATION - JOHN DEERE ENGINE (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 184
FIGURE 4-22. EXHAUST INSTALLATION - PERKINS ENGINE (SN 0160020943 through 0160040674, Including 0160020803, 0160020823 and 0160020824, Excluding 0160040468 and 0160040672) 186
FIGURE 4-23. EXHAUST INSTALLATION - CUMMINS ENGINE (SN 0160040675 to Present, Including 0160040468 and 0160040672) 188
FIGURE 4-24. DANA TRANSMISSION - CONVERTER HOUSING GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 190
FIGURE 4-25. DANA TRANSMISSION - CASE AND PLATE GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 192
FIGURE 4-26. DANA TRANSMISSION - TORQUE CONVERTER GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 194
FIGURE 4-27. DANA TRANSMISSION - GEAR GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 196
FIGURE 4-28. DANA TRANSMISSION - PUMP DRIVE GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 198
FIGURE 4-29. DANA TRANSMISSION - CHARGING PUMP GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 200
FIGURE 4-30. DANA TRANSMISSION - REVERSE IDLER GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 202
FIGURE 4-31. DANATRANSMISSION - FORWARD AND REVERSE SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 204
FIGURE 4-32. DANA TRANSMISSION - 3RD SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 206
FIGURE 4-33. DANA TRANSMISSION - FIRST AND SECOND SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 208
FIGURE 4-34. DANA TRANSMISSION - OUTPUT SHAFT GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 210
FIGURE 4-35. DANA TRANSMISSION - ELECTRIC CONTROL GROUP (SN 0193001 through 0193007, SN 0160000008 through 0160011036) 212
FIGURE 4-36. DANA TRANSMISSION - ELECTRIC CONTROL GROUP (SN 0160011061 through 0160040675, Excluding 0160040468 and 0160040672) 214
FIGURE 4-37. DANA TRANSMISSION - DRIVE PLATE GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 216
FIGURE 4-38. DANA TRANSMISSION - DROP BOX GROUP (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 218
FIGURE 4-39. ZF TRANSMISSION (SN 0160040675 to Present, Including 0160040468 and 0160040672) 220
FIGURE 4-40. ZF TRANSMISSION - TRANSMISSION CONVERTER AND INPUT (SN 0160040675 to Present, Including 0160040468 and 0160040672) 222
FIGURE 4-41. ZF TRANSMISSION - GEARBOX HOUSING (SN 0160040675 to Present, Including 0160040468 and 0160040672) 224
FIGURE 4-42. ZF TRANSMISSION - REVERSING GEAR (SN 0160040675 to Present, Including 0160040468 and 0160040672) 226
FIGURE 4-43. ZF TRANSMISSION - REVERSE GEAR GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 228

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001_R... Order the manual at mid-west-tech.com >

FIGURE 4-44. ZF TRANSMISSION - 1ST SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 230
FIGURE 4-45. ZF TRANSMISSION - 2ND SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 232
FIGURE 4-46. ZF TRANSMISSION - 3RD SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 234
FIGURE 4-47. ZF TRANSMISSION - 4TH SHAFT GROUP (SN 0160040675 to Present, Including 0160040468 and 0160040672) 236
FIGURE 4-48. ZF TRANSMISSION - POWER TAKE-OFF (SN 0160040675 to Present, Including 0160040468 and 0160040672) 238
FIGURE 4-49. ZF TRANSMISSION - CONTROL UNIT AND PRESSURE REGULATOR (SN 0160040675 to Present, Including 0160040468 and 0160040672) 240
FIGURE 4-50. ZF TRANSMISSION - GEARSHIFT SYSTEM (SN 0160040675 to Present, Including 0160040468 and 0160040672) 242
FIGURE 4-51. ZF TRANSMISSION - OIL PUMP, FILTER AND DIPSTICK (SN 0160040675 to Present, Including 0160040468 and 0160040672) 244
FIGURE 4-52. ZF TRANSMISSION - TRANSFER BOX (SN 0160040675 to Present, Including 0160040468 and 0160040672) 246

SECTION 5 - DRIVE TRAIN 249

FIGURE 5-1. FRONT AXLE ASSEMBLY 250
FIGURE 5-2. FRONT AXLE 252
FIGURE 5-3. FRONT AXLE HOUSING ASSEMBLY 254
FIGURE 5-4. FRONT STEERING COMPONENTS 256
FIGURE 5-5. FRONT GEAR COMPONENTS 258
FIGURE 5-6. FRONT DIFFERENTIAL 260
FIGURE 5-7. FRONT DOUBLE JOINT 262
FIGURE 5-8. FRONT BRAKES 264
FIGURE 5-9. FRONT WHEEL HUB 266
FIGURE 5-10. FRONT REDUCTION GEARS 268
FIGURE 5-11. REAR AXLE ASSEMBLY 270
FIGURE 5-12. REAR AXLE 272
FIGURE 5-13. REAR AXLE HOUSING ASSEMBLY 274
FIGURE 5-14. REAR STEERING COMPONENTS 276
FIGURE 5-15. REAR GEAR COMPONENTS 278
FIGURE 5-16. REAR DIFFERENTIAL 280
FIGURE 5-17. REAR DOUBLE JOINT 282
FIGURE 5-18. REAR BRAKES (Prior to SN 0160035189, Excluding 0160035166) 284
FIGURE 5-19. REAR BRAKES (SN 0160035189 to Present, Including 0160035166) 286
FIGURE 5-20. REAR WHEEL HUB 288
FIGURE 5-21. REAR REDUCTION GEARS 290
FIGURE 5-22. DRIVE SHAFT ASSEMBLY 292
FIGURE 5-23. TIRES AND RIMS 294
FIGURE 5-24. TIRES AND RIMS 298

SECTION 6 - CAB 301

FIGURE 6-1. OPEN CAB 302
FIGURE 6-2. CAB ENCLOSURES 304
FIGURE 6-3. CAB COMPONENTS 306
FIGURE 6-4. CAB DOOR ASSEMBLY 308
FIGURE 6-5. CAB GLASS 310
FIGURE 6-6. SUSPENSION SEAT (SN 0160015460 to Present) 312
FIGURE 6-7. DASH PANEL (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 314
FIGURE 6-8. DASH PANEL (SN 0160040675 to Present, Including 0160040468 and 0160040672) 316
FIGURE 6-9. INSTRUMENT PANEL (Prior to SN 0160040675, Excluding 0160040468 and 0160040672) 318
FIGURE 6-10. INSTRUMENT PANEL (SN 0160040675 to Present, Including 0160040468 and 0160040672) 320
FIGURE 6-11. TOP CAB GLASS SHIELD 324
FIGURE 6-12. FRONT CAB GLASS SHIELD 326

SECTION 7 - CONTROLS 329

FIGURE 7-1. TILT AND FRAME LEVEL JOYSTICK INSTALLATION 330
FIGURE 7-2. TILT AND SWAY JOYSTICK ASSEMBLY 332
FIGURE 7-3. ACCELERATOR PEDAL INSTALLATION (Prior to SN 0160001378, Excluding 0160001280) 334
FIGURE 7-4. ACCELERATOR PEDAL INSTALLATION (SN 0160001378 through 0160038394, Including 0160001280) 336

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001_R... Order the manual at mid-west-tech.com >

FIGURE 6-10. INSTRUMENT PANEL (SN 0160040675 to Present, Including 0160040468 and 0160040672)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001101666	1	INSTRUMENT PANEL ASSY, (includes items 1 thru 6)	M
1	1001099378	1	INSTRUMENT PANEL	
2	1001102815	1	INSTURMENT PANEL HARNESS, (includes items 101 thru 115)	B
3	1001099163	1	3 IN 1 GAUGE ASSY	
4	7026440	1	HORN SWITCH	
5	91474465	1	PARK BRAKE SWITCH	
6	91473127	1	STEER SELECT SWITCH	
101	91503105	1	8 PIN RECEPTACLE	
102	91503106	1	WEDGELOCK	
103	77363228	1	TERMINAL	
104	4460466	1	PLUG	
105	N.S.S.	1	CONNECTOR	
106	70022691	1	WEDGE LOCK	
107	4460944	1	CONTACT	
108	N.S.S.	1	CONNECTOR	
109	N.S.S.	1	DOUBLE LOCK PLATE	
110	N.S.S.	1	SOCKET	
111	N.S.S.	1	WIRE SEAL	
112	N.S.S.	1	PLUG	
113	7026437	6	BULB BASE	
114	7026438	6	TERMINAL	
115	80484088	6	BULB	
212	0740605	2	FLAT HD CAPSCREW, #6-32X0.62, (if equipped)	
216	3310601	2	HEX NUT, #6-32, GR2, (if equipped)	
231	80363069	1	KNOB, (if equipped)	
232	80365027	1	POTENTIOMETER ASSY, (8k ohms), (if equipped), (includes items 301 & 302)	
237	80963101	1	WIPER SWITCH	
238	80964001	1	BLOWER SWITCH, (if equipped)	
246	88691387	1	TUBING CLIP	
251	91033317	1	IGNITION SWITCH	
251	77384578	1	KEY	
266		Ref	ACCELERATOR PEDAL BRACKET, (See CONTROLS SECTION for Breakdown)	
269		Ref	ENCLOSED CAB HARNESS, (See ELECTRICAL SECTION for Breakdown)	
270	91563191	1	RH INSTRUMENT PANEL	
290		Ref	CAB HARNESS, (See ELECTRICAL SECTION for Breakdown)	
291		Ref	CAB DASH HARNESS, (See ELECTRICAL SECTION for Breakdown)	
294	1001115891	Ref	POWER DISTRUTION INSTALLATION, (not available to order, see items 401 thru 406 for service)	A
301	80363208	1	POTENTIOMETER HARNESS, (if equipped)	
302	80363067	1	POTENTIOMETER, 8k ohms, (if equipped)	
401	0641412	4	HEX HD CAPSCREW, 1/4-20X1-1/2, GR5	
402	3311401	4	HEX NUT, 1/4-20, GR2	
403	4751200	4	FLAT WASHER, 1/4	
404	1001092849	1	VEC BOX ASSY, (includes items 501 thru 508)	C
405		Ref	VEC BOX HARNESS, (See ELECTRICAL SECTION for Breakdown)	

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001_R... Order the manual at mid-west-tech.com >

FIGURE 12-2. ENCLOSED CAB HEATER COMPONENTS (SN 0160015460 through 0160040674, Excluding 0160040468 and 0160040672)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	91475108	Ref	CAB ENCLOSURE KIT INSTALLATION, (not available to order, see items 1 thru 55 for service)	B
1		Ref	FITTING, (See ENGINE HEATER COMPONENTS for Breakdown)	
2		Ref	TRUCK VALVE, (See ENGINE HEATER COMPONENTS for Breakdown)	
3		Ref	COOLANT RESTRICTOR ORIFICE, (See ENGINE HEATER COMPONENTS for Breakdown)	
4		Ref	HEATER HOSE, 5/8IN, (See ENGINE HEATER COMPONENTS for Breakdown)	
5		Ref	HEATER HOSE CLAMP, (See ENGINE HEATER COMPONENTS for Breakdown)	
6	86683122	1	TIE WRAP	
7		Ref	STRAIGHT FITTING, (See ENGINE HEATER COMPONENTS for Breakdown)	
8		Ref	BARBED FITTING, 90, (See ENGINE HEATER COMPONENTS for Breakdown)	
9		Ref	RH CONSOLE, (See CAB SECTION for Breakdown)	
10	86683193	4	HOSE CLAMP	
11	83683182	1	WATER VALVE	
12	91413038	1	HEATER CABLE	
14	80964001	1	BLOWER SWITCH	
15	80363069	2	KNOB, 3/16 SHAFT	
16	80363028	1	ROTARY CONTROL	
17	80963058	1	WEATHER PACK SHROUD	
18	80963069	2	WEATHER PACK PINS	
19	80963065	2	WEATHER PACK SEALS	
20	91403351	1	WIPER/WASHER HARNESS	
21	91403352	1	HEATER HARNESS	
22	91403350	1	WIPER/HEATER HARNESS	
23	83683085	1	WASHER BOTTLE	
24	77363265	1	RELAY	
25	8229262	2	AUTO FUSE, 25 AMP	
27	80963101	1	WIPER SWITCH	
28	88201005	3	HEX HD CAPSCREW, 1/4-20X1	
29	88561002	9	FLAT WASHER, 1/4	
30	88551009	8	LOCKWASHER, 1/4	
31	88501004	2	HEX NUT, 1/4-20	
32	91413036	2	SELF TAPPING SCREW, #6X1/2	
33	24861170	2	CLAMP	
34	88561105	2	FLAT WASHER, #10	
35	71492150	10 ft	VENT HOSE, 2IN DIAMETER	
36	71492152	10.5 ft	VENT HOSE, 2 1/2IN DIAMETER	
37	84231107	18	HOSE CLAMP	
38	91403539	2	3 WAY CONNECTOR	
39		Ref	CAB ENCLOSURE, (See CAB SECTION for Breakdown)	
40	91403445	1	HEATER CONTROL PANEL	
41	91403329	1	HEAT/AC PLENUM	
42	88201011	1	HEX HD CAPSCREW, 1/4-20X2 1/2	
43	77133279	1	CLAMP SET	
44	77133137	1	COVER PLATE	

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001_R... Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
44	91514236	1	VALVE SECTION ASSY, (sway), (includes one of items 6, 11 thru 14 & 36 thru 39, two of items 34, 35, 41, 42 & 43 and three of items 7 & 40)	
45	91514238	1	VALVE SECTION ASSY, (aux), (includes one of items 6, 11 thru 14 & 37 thru 39, two of items 34, 35, 41, 42 & 43 and three of items 7 & 40)	
46	91514237	1	OUTLET COVER ASSY	
47	N.S.S.	1	SPRING	
48	91514240	1	END CAP ASSY, (includes one of items 23, 49, 50, 53 & 55,two of items 51, 52 & 56 and four of item 54)	
49	N.S.S.	2	END CAP	
50	N.S.S.	2	RETAINER SEAL	
51	N.S.S.	4	LOCKWASHER	
52	N.S.S.	4	CAPSCREW, 1/4-20X0.88	
53	N.S.S.	2	O-RING	
54	N.S.S.	8	EXPANDER PLUG	
55	N.S.S.	2	SOLENOID	
56	N.S.S.	4	CAPSCREW	
57	91514241	1	END CAP ASSY, (includes items 47,58 & 59, one of items 23, 25, 26, 49, 50, 53 & 55, two of items 51, 52 & 56 and four of item 54)	
58	N.S.S.	2	SPRING GUIDE	
59	N.S.S.	1	SPRING	
60	88411074	3	ROUND HD CARRIAGE BOLT, 3/8-16X4	
61	88551011	3	LOCKWASHER, 3/8	
62	88501006	3	HEX NUT, 3/8-16	
K1	91514220	6	VALVE SECTION SEAL KIT, (includes one of item 6 & three of item 7)	
K2	91514221	1	RELIEF SEAL KIT, (includes items 3, 4 & 5)	
K3	91514247	1	STUD KIT, (includes items 32 & 33)	
K4	91514226	2	SPOOL SEAL KIT, (includes one of items 6 & 14, two of items 41 & 42 and three of item 7)	
K5	91514227	2	REMOTE SEAL KIT, (includes one of items 6 & 14, two of item 17, three of item 7 & four of item 23)	

MidWestTech | JLG G10-43A, G9-43A Telehandler Parts Manual | Publication 91514001_R... Order the manual at mid-west-tech.com >