W14C LOADER

OPERATOR MANUAL

9-16470

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W14C Loader Operator's Manual | Publication 9-16470

Order the manual at mid-west-tech.com >

SPECIAL BOLT TORQUES

	pound-feet	(Nm)
Steering wheel nut	30 - 35	40 - 50
Engine mounting bracket to engine	66 - 79	90 - 105
Transmission mounting brackets to transmission	200 - 220	270 - 300
Flexplate to flywheel	25 - 30	34 - 41
Front and rear axle mounting bolts	385 - 405	552 - 550
Universal jounts	55 - 60	75 - 80
Trunnion mounting pin nuts	400 - 500	540 - 680
Front drive shaft yoke nut	580 - 620	785 - 840
Fan mounting bolts	38 - 45	52 - 60
ROPS cab and ROPS canopy mounting bolts	400 - 500	540 - 568
A/C compressor bracket to intake manifold	54 - 64	73 - 85
Transmission to flywheel housing	35 - 42	47 - 60
Transmission shock mounting nuts	220 - 264	300 - 355
Articulation pivot bolts	1360 - 1500	1845 - 2035
Engine shock mounting nut	135 - 165	180 - 225
Alternator pulley nut	60 - 70	80 - 95
Bellcrank to lift arm	160 - 200	215 - 270
Wheel nut torque		See page 73
Hydraulic reservoir cover bolt	15 - 20	20 - 27

MidWestTech | Case W14C Loader Operator's Manual | Publication 9-16470 Order the manual at mid-west-tech.com >

SECTION INDEX

Cab Controls
- Cab Door and Window Controls....46
- Control Panel....38
- Overhead Controls....40
- Seats
  - Seat Belts....44
  - Standard Seat....42
  - Suspension Seat....43

Control Panel - Left Side
- Cold Start Button....29
- Direction Control Lever....29
- Flasher Switch....29
- Range Control Lever....29
- Turn Signal Lever....29

Control Panel - Right Side
- Engine Oil Pressure Gauge....31
- Hourmeter....30
- Lighter - cigar....30
- Test Switch - Warning Lamps....30

Control Tower
- Clutch Cutout Switch....37
- Light Switch....36
- Loader Controls....36
- Loader Detent Switch....36

Floor Controls and Pedals
- Brake Pedal....35
- Bucket Height Control....35
- Foot Throttle....35
- Parking Brake....35

Instrument Panel....32

Loader Controls
- Dual Lever Controls
  - Bucket Control....49
  - Clam or Grapple Control....49
  - Lift Arm Control....50
- Single Lever Control
  - Bucket and Lift Arm Control....47
  - Clam or Grapple Control....48

MidWestTech | Case W14C Loader Operator's Manual | Publication 9-16470 Order the manual at mid-west-tech.com >