W24
Articulated Loader

Operators Manual

9-2263

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case W24 Articulated Loader Operator's Manual | Publication 9-2263

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

To the Case Loader Owner 1
Safety Precautions 2
Serial Number Location 5
Specifications 6
Operating Instructions 13
- Run-In Procedure 13
- Indicators and Controls 14
- Loader Controls 19
- Return-To-Dig Feature 20
- Bucket Height Control 21
- Bucket Position Indicator 22
- Engine Operation 22

Operating Tips 27
Fuel and Lubricants 31
- Fuel 31
- Lubricants 33

Maintenance/Lubrication 34
- Maintenance Chart 34
- Lubrication Points 36
- Engine Oil and Filter 38
- Fuel System 40
- Air Intake System 43
- Cooling System 45
- Hydraulic and Steering System 49
- Transmission Service 51
- Front and Rear Axle 54
- Brakes 55
- Drive Belts 57
- Electrical System 60

MidWestTech | Case W24 Articulated Loader Operator's Manual | Publication 9-2263 Order the manual at mid-west-tech.com >