# 2144 /2166 Axial Flow Combine

## Operators Manual

Pac 9-25703

CASE IH AGRICULTURE

MidWestTech | Case 2144, 2166 Axial Flow Combine Operator's Manual | Publication 9-25703

Order the manual at mid-west-tech.com >

# GENERAL TABLE OF CONTENTS


TO THE OWNER . . . . . 1

IDENTIFICATION NUMBERS . . . . . 3
PRODUCT IDENTIFICATION AND SERIAL NUMBERS . . . . . 3

SAFETY/DECALS . . . . . 5
FIRE EXTINGUISHER . . . . . 8
DECALS . . . . . 9
INFORMATIONAL DECALS . . . . . 16

INSTRUMENTS/CONTROLS . . . . . 17
INSTRUMENT PANEL . . . . . 17
DIGITAL TACHOMETER . . . . . 20
OPERATING CONTROLS . . . . . 24
OPERATORS SEAT . . . . . 45
COMBINE CALIBRATION . . . . . 47
COMBINE DIAGNOSTICS . . . . . 54

OPERATING INSTRUCTIONS . . . . . 57
BEFORE STARTING THE ENGINE . . . . . 57
INDICATOR LAMP AND ALARM TEST . . . . . 58
RUN-IN PROCEDURE . . . . . 59
NORMAL STARTING PROCEDURE . . . . . 61
STOPPING THE ENGINE . . . . . 63
COLD TEMPERATURE OPERATION . . . . . 64
TRANSPORTING THE COMBINE . . . . . 69
TOWING . . . . . 71
AMBER WARNING LAMPS, DIRECTIONAL TURN SIGNAL AND SMV SYMBOL . . . . . 73
DIGITAL TACHOMETER . . . . . 74
COMBINE OPERATION . . . . . 76
HEADER CONTROLS . . . . . 82
SHAFT SPEED MONITOR . . . . . 90
GRAIN SCAN MONITOR . . . . . 92
FEEDER OPERATION . . . . . 97
UNLOADER OPERATION . . . . . 104
OPERATORS LADDER . . . . . 106
FIELD TRACKER (IF EQUIPPED) . . . . . 110

FIELD OPERATION . . . . . 115
TROUBLESHOOTING . . . . . 118
THRESHING AND SEPARATING SYSTEM . . . . . 118
CUTTING AND FEEDING . . . . . 121
ROTOR . . . . . 136
CONCAVE . . . . . 143
GRATES . . . . . 148


TRIM THIS EDGE



MidWestTech | Case 2144, 2166 Axial Flow Combine Operator's Manual | Publication 9-25... Order the manual at mid-west-tech.com >

GRAIN CLEANING ..... 150
AUGER BED ..... 154
CLEANING FAN ..... 155
CHAFFER SIEVE ..... 158
SHOE SIEVES ..... 163
GRAIN HANDLING AND MATERIAL DISTRIBUTION ..... 169
ELEVATORS ..... 171
GRAIN TANK AND UNLOADER ..... 173
DISCHARGE BEATER ..... 176
STRAW SPREADERS AND STRAW/CHAFF SPREADERS ..... 177
STRAW CHOPPER (IF EQUIPPED) ..... 181
BALING STRAW ..... 184
SEED LOSS ..... 185

TIRES/WHEELS/SPACING/BALLAST ..... 190
TIRE INFLATION ..... 190
TIRE PRESSURE CHART ..... 191
DRIVE WHEELS ..... 192
STEERING WHEELS ..... 196
DRIVE AXLE ..... 199
STEERING AXLE ..... 201
POWER GUIDE WHEEL DRIVE (IF EQUIPPED) ..... 205
STEERING AXLE WEIGHTS ..... 207

LUBRICATION/FILTERS/FLUIDS ..... 208
ENGINE HOURMETER ..... 210
GREASE FITTINGS - TOP ..... 214
GREASE FITTINGS - LEFT SIDE ..... 218
GREASE FITTINGS - RIGHT SIDE ..... 221
GREASE FITTINGS - REAR AXLE ..... 227
CHAIN LUBRICATION ..... 232
ENGINE LUBRICATION ..... 234
COOLING SYSTEM ..... 240
FUEL SYSTEM ..... 250
AIR INDUCTION SYSTEM ..... 259
TRANSMISSION ..... 264
FINAL DRIVE ..... 265
HYDRAULIC OIL RESERVOIR AND FILTERS ..... 266
PROPULSION SYSTEM AIR REMOVAL ..... 270
PTO HOUSING ..... 274
FEEDER AND CLEANING FAN GEAR CASE ..... 276
LOWER UNLOADER GEAR CASE ..... 277
ROTOR GEAR CASE ..... 278
STRAW CHOPPER (IF EQUIPPED) ..... 279
STEERING WHEEL BEARING LUBRICATION ..... 280

TRIM THIS EDGE



MidWestTech | Case 2144, 2166 Axial Flow Combine Operator's Manual | Publication 9-25... Order the manual at mid-west-tech.com >

OPERATORS CAB ..... 281

MAINTENANCE/ADJUSTMENTS ..... 283
ENGINE FAN AND ALTERNATOR BELT ..... 283
AIR CONDITIONER COMPRESSOR BELT ..... 286
ROTOR DRIVE BELT ..... 289
SEPARATOR DRIVE BELT ..... 294
AUXILIARY PUMP DRIVE BELT ..... 298
GRAIN TANK UNLOADER DRIVE BELT ..... 301
FEEDER JACKSHAFT DRIVE BELT ..... 307
FEEDER DRIVE BELT ..... 310
CLEANING FAN DRIVE BELT ..... 314
CLEANING FAN JACKSHAFT BELT ..... 317
ELEVATOR DRIVE BELT ..... 319
STRAW SPREADER DRIVE BELT ..... 325
STRAW CHOPPER DRIVE BELT ..... 327
GRAIN TANK UNLOADER CHAIN ..... 329
REAR HORIZONTAL AUGER DRIVE CHAIN ..... 330
ELEVATOR DRIVE SLIP CLUTCH ADJUSTMENT ..... 331
TAILINGS ELEVATOR DRIVE CHAIN ..... 333
TAILINGS ELEVATOR CONVEYOR CHAIN ..... 334
CLEAN GRAIN ELEVATOR DRIVE CHAIN ..... 336
CLEAN GRAIN ELEVATOR CONVEYOR CHAIN ..... 337
FEEDER REVERSER DRIVE CHAIN ..... 339
FEEDER CONVEYOR CHAIN ..... 342
BRAKE PEDAL ADJUSTMENT ..... 344
PROPULSION CONTROL CABLE ADJUSTMENT ..... 345
ENGINE HIGH IDLE SPEED ..... 347
THROTTLE CABLE ..... 348
GEAR SHIFT CABLE ADJUSTMENT ..... 350
FOOT-N-INCH PEDAL ADJUSTMENT ..... 352
NEUTRAL START SWITCH ADJUSTMENT ..... 353
FEEDER ADJUSTMENTS ..... 354
STRAW SPREADER ..... 357
CONCAVES AND GRATES ..... 358
STRAW CHOPPER (IF EQUIPPED) ..... 363
COOLING SYSTEM ..... 365
ROCKER ARM TO VALVE CLEARANCE ADJUSTMENT ..... 366

ELECTRICAL SYSTEM ..... 367
ELECTRICAL SPECIFICATIONS ..... 367
ALTERNATOR CHARGING SYSTEM ..... 374
BATTERIES ..... 376
HEAD LAMP ADJUSTMENT ..... 380
LAMP BULB REPLACEMENT ..... 381

STORAGE ..... 386



TRIM THIS EDGE

MidWestTech | Case 2144, 2166 Axial Flow Combine Operator's Manual | Publication 9-25... Order the manual at mid-west-tech.com >