9030B
EXCAVATOR

Operator's Manual

Bur 9-25831NA

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 9030B Excavator Operator's Manual | Publication 9-25831NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 3
MACHINE COMPONENTS 4, 5

SAFETY / DECALS / HAND SIGNALS 7
SAFETY MESSAGE 7
BEFORE OPERATION 8
MACHINE OPERATION 10
PARKING THE MACHINE 12
BURN PREVENTION 12
FIRE OR EXPLOSION PREVENTION 13
MAINTENANCE 14
SAFETY DECALS 16
HAND SIGNALS 25, 26

INSTRUMENTS AND CONTROLS 27
LOCATION OF COMPONENTS (Operator's Cab) 27
HAND AND FOOT CONTROLS 28
STANDARD CONTROLS (Control Pattern D When Quick Change Kit Is Installed) 29
OPTIONAL CONTROLS (Control Pattern C When Quick Change Kit Is Installed) 30
RIGHT FRONT CONTROL PANEL 32, 34
LEFT FRONT CONTROL PANEL 36
SYSTEMS DISPLAY PANEL 38, 41, 42
RIGHT REAR CONTROL PANEL 44
LEFT REAR CONTROL PANEL 45
OPERATION OF HEATING AND AIR CONDITIONING (If Equipped) 46
AM / FM RADIO 48
OPERATOR'S SEAT (Units With Non-Retracting Seat Belts) 49
OPERATOR'S SEAT (Units With Retractable Seat Belts) 50
SEAT BELT (Units With Non-Retracting Seat Belts) 51
SEAT BELT (Units With Retractable Seat Belts) 52
CAB WINDOW AND DOOR CONTROLS 53
ANTI-VANDAL GUARD 56

MidWestTech | Case 9030B Excavator Operator's Manual | Publication 9-25831NA Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

OPERATING INSTRUCTIONS 57
RUN-IN PERIOD OF A NEW MACHINE 57
ENGINE OPERATION 58
ENGINE STARTING AIDS 62
ETHER COLD START AID 63
BOOSTER BATTERY CONNECTION TO MACHINE BATTERY 64
MACHINE OPERATION 66
DRIVING THE MACHINE 67
LONG REACH EXCAVATOR 73
AUXILIARY ATTACHMENT OPERATION 76
AUXILIARY HYDRAULIC SYSTEMS 77
LIFTING LOADS WITH THE MACHINE 84
TRANSPORTING THE MACHINE ON A TRAILER 85
DISABLED MACHINE 85
OPERATING IN HOT WEATHER 87
MACHINE LIFTING EYES 87
OPERATING IN COLD WEATHER 88

LUBRICATION / FILTERS / FLUIDS 89
GENERAL SAFETY BEFORE YOU SERVICE 89
ENVIRONMENT 89
LUBRICATION CHART 90
PLASTIC AND RESIN PARTS 92
ENGINE HOURMETER 92
FLUIDS AND LUBRICANTS 93
ENGINE OIL RECOMMENDATIONS 94
HYDRAULIC FLUID CHART 95
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 96
ACCESS DOORS 97, 98
GREASE FITTINGS 98
ENGINE LUBRICATION SYSTEM 101
AIR FILTER SYSTEM 103
ENGINE COOLING SYSTEM 106
DIESEL FUEL SYSTEM 110
HYDRAULIC SYSTEM 114
SWING GEARBOX 121
FINAL DRIVE GEARBOXES 123

TRIM THIS EDGE

MidWestTech | Case 9030B Excavator Operator's Manual | Publication 9-25831NA Order the manual at mid-west-tech.com >

MAINTENANCE AND ADJUSTMENTS 125
DRIVE BELT 125
WINDSHIELD WASHER RESERVOIR 125
BUCKET INSTALLATION 126
WELDING ON THE MACHINE 126
SEAT BELT 127
FIRE EXTINGUISHER 127
ETHER STARTING FLUID 128
TRACKS 129
TRACK SHOE BOLTS 132
ELECTRICAL SYSTEM 133
BATTERIES 133, 134,135
ELECTRICAL SYSTEM CONTROLLER 135
FUSES 136
MACHINE STORAGE 137

SPECIFICATIONS 139
ENGINE DATA (Prior to P.I.N. DAC0302001) 139
EMISSION ENGINE DATA (P.I.N. DAC0302001 and After) 140
WEIGHTS 141
DIMENSIONS 142, 144, 146
OPERATING DATA 148,150
LIFTING CAPACITES FOR STANDARD AND NARROW MACHINES 152
LIFTING CAPACITY CHARTS 153
LIFTING CAPACITIES FOR LONG REACH MACHINE 165
BUCKETS (Central Fabricators) 170
BOLT TORQUES 172

INDEX 175

AFTER DELIVERY CHECK 185, 187

TRIM THIS EDGE

MidWestTech | Case 9030B Excavator Operator's Manual | Publication 9-25831NA Order the manual at mid-west-tech.com >