L Series Loader Backhoe

Operators Manual

9-25886

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 580L, 580 Super L, 590 Super L Loader Backhoe Operator's Manual |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
RIGHT, LEFT, FRONT AND REAR OF MACHINE 2
IDENTIFICATION NUMBERS 3
MACHINE COMPONENTS ..... 6 through 9

SAFETY / DECALS / HAND SIGNALS 11
SAFETY RULES 11
BEFORE OPERATION 12
MACHINE OPERATION 14
PARKING THE MACHINE 16
BURN PREVENTION 16
FIRE OR EXPLOSION PREVENTION 17
MAINTENANCE 18
WHEELS AND TIRES MAINTENANCE 19
ROLL-OVER PROTECTIVE STRUCTURE 19
CAST DUCTILE IRON 20
SAFETY DECALS 21
HAND SIGNALS 30

INSTRUMENTS AND CONTROLS 35
MACHINE CONTROLS 37
LOADER CONTROLS 49
BACKHOE CONTROLS WITH FOOT SWING 51
BACKHOE CONTROLS WITH HAND SWING 52
EXTENDAHOE CONTROL WITH FOOT SWING 53
EXTENDAHOE CONTROLS WITH HAND SWING 54
AUXILIARY ATTACHMENT CONTROL FOR BACKHOES 55
STANDARD SEAT 56
SUSPENSION SEAT 57
SEAT BELTS 59
CAB CONTROLS (If Equipped) 60

OPERATING INSTRUCTIONS 65
RUN-IN PERIOD OF A NEW MACHINE 65
ENGINE OPERATION 66
ENGINE STARTING AIDS 69
MACHINE OPERATION 73
TOWING A DISABLED MACHINE 78
OPERATING IN COLD WEATHER 81
OPERATING IN HOT WEATHER 82
LOADER OPERATION 83
BACKHOE OPERATION 89

MidWestTech | Case 580L, 580 Super L, 590 Super L Loader Backhoe Operator's Manual |... Order the manual at mid-west-tech.com >

WHEELS/TIRES 111

LUBRICATION / MAINTENANCE CHARTS 115
GENERAL SAFETY BEFORE YOU SERVICE 115
ENGINE HOURMETER 115
SUPPORT STRUT FOR LOADER LIFT ARMS 116
FLUIDS AND LUBRICANTS 117
LUBRICATION/MAINTENANCE CHART 118, 119
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 120
ENVIRONMENT 120

LUBRICATION/FILTERS/FLUIDS 121
OPENING THE ENGINE HOOD 121
LOADER GREASE FITTINGS 122
BACKHOE GREASE FITTINGS 124, 126, 128
FLUID LEVELS 133
AMBIENT AIR TEMPERATURE RANGES 135
ENGINE OIL RECOMMENDATIONS 135
ENGINE SERVICE SPECIFICATIONS 136
AIR FILTER SYSTEM 139
ENGINE COOLING SYSTEM 143
DIESEL FUEL SYSTEM 146
HYDRAULIC SYSTEM 150
TRANSMISSION 153
REAR AXLE 155
FRONT FOUR WHEEL DRIVE AXLE 158
CAB AIR FILTER 160

MAINTENANCE AND ADJUSTMENTS 163
LOADER RETURN-TO-DIG ADJUSTMENT 163
ETHER STARTING AID 164
FAN DRIVE BELT REPLACEMENT 165
PLASTIC AND RESIN PARTS 165
SPARK ARRESTER MUFFLER (IF EQUIPPED) 166
RIDE CONTROL ACCUMULATOR 167
CAB AIR CONDITIONING 168
ROLL-OVER PROTECTIVE STRUCTURE 169
FIRE EXTINGUISHER 173

ELECTRICAL SYSTEM 175
BATTERIES 175
LAMP REPLACEMENT 177
INSTRUMENT CLUSTER 179
FUSES 180

MidWestTech | Case 580L, 580 Super L, 590 Super L Loader Backhoe Operator's Manual |... Order the manual at mid-west-tech.com >

MACHINE STORAGE 181
REMOVAL FROM STORAGE 182

SPECIFICATIONS 183
TABLE OF CONTENTS 183
580L SPECIFICATIONS 183
ENGINE DATA - 580L 183
BOLT TORQUES 183
MAIN RELIEF VALVE PRESSURES - 580L 184
TRAVEL SPEEDS - 580L 184
OPERATING WEIGHTS - 580L 184
LOADER BUCKETS - 580L 185
BACKHOE BUCKETS - 580L 185
BASIC MACHINE DIMENSIONS - 580L 186
LOADER OPERATING DATA AND DIMENSIONS - 580L 187, 188
BACKHOE OPERATING DATA AND DIMENSIONS - 580L 190
BACKHOE LIFT CAPACITY - 580L 192
BACKHOE LIFT CAPACITY - 580L (2WD) 194
EXTENDAHOE OPERATING DATA AND DIMENSIONS - 580L 196
EXTENDAHOE LIFT CAPACITY - RETRACTED 580L 198
EXTENDAHOE LIFT CAPACITY - EXTENDED 580L 200
EXTENDAHOE LIFT CAPACITY - 580L (2WD) 202, 204
SPECIFICATIONS - 580 SUPER L 207
ENGINE DATA - 580 SUPER L 207
BOLT TORQUES 207
MAIN RELIEF VALVE PRESSURES - 580 SUPER L 207
TRAVEL SPEEDS - 580 SUPER L 208
OPERATING WEIGHTS - 580 SUPER L 208
LOADER BUCKETS - 580 SUPER L 209
BACKHOE BUCKETS - 580 SUPER L 209
BASIC MACHINE DIMENSIONS - 580 SUPER L 210
LOADER OPERATING DATA AND DIMENSIONS - 580 SUPER L 211, 212
BACKHOE OPERATING DATA AND DIMENSIONS - 580 SUPER L 214
BACKHOE LIFT CAPACITY - 580 SUPER L 216
BACKHOE LIFT CAPACITY - 580 SUPER L (2WD) 218
EXTENDAHOE OPERATING DATA AND DIMENSIONS - 580 SUPER L 220
EXTENDAHOE LIFT CAPACITY - RETRACTED 580 SUPER L 222
EXTENDAHOE LIFT CAPACITY - EXTENDED 580 SUPER L 224
EXTENDAHOE LIFT CAPACITY - 580 SUPER L (2WD) 226, 228
SPECIFICATIONS - 590 SUPER L 231
ENGINE DATA - 590 SUPER L 231
BOLT TORQUES 231
MAIN RELIEF VALVE PRESSURES - 590 SUPER L 231
TRAVEL SPEEDS - 590 SUPER L 232
OPERATING WEIGHTS - 590 SUPER L 232
LOADER BUCKETS - 590 SUPER L 233
BACKHOE BUCKETS - 590 SUPER L 233

MidWestTech | Case 580L, 580 Super L, 590 Super L Loader Backhoe Operator's Manual |... Order the manual at mid-west-tech.com >