570LXT Loader/ Loader Landscaper

Operators Manual

Bur 9-25895

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 570LXT Loader Landscaper Operator's Manual | Publication 9-25895

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
- AFTER DELIVERY CHECK 2
- RIGHT, LEFT, FRONT AND REAR OF MACHINE 2
- IDENTIFICATION NUMBERS 3
- MACHINE COMPONENTS ..... 6 through 9

SAFETY / DECALS / HAND SIGNALS 11
- SAFETY RULES 11
- BEFORE OPERATION 12
- MACHINE OPERATION 14
- PARKING THE MACHINE 16
- BURN PREVENTION 16
- FIRE OR EXPLOSION PREVENTION 17
- MAINTENANCE 18
- WHEEL AND TIRE MAINTENANCE 20
- ROLL-OVER PROTECTION STRUCTURE 20
- CAST DUCTILE IRON 21
- SAFETY DECALS 22
- HAND SIGNALS 29

INSTRUMENTS AND CONTROLS 33
- MACHINE CONTROLS 35
- LOADER CONTROLS 46
- THREE-POINT HITCH CONTROLS 48
- STANDARD SEAT 50
- SUSPENSION SEAT 51
- SEAT BELTS 53
- CAB CONTROLS (If Equipped) 54

OPERATING INSTRUCTIONS 59
- RUN-IN PERIOD OF A NEW MACHINE 59
- ENGINE OPERATION 60
- ENGINE STARTING AIDS 63
- MACHINE OPERATION 67
- TOWING A DISABLED MACHINE 72
- OPERATING IN COLD WEATHER 75
- OPERATING IN HOT WEATHER 76
- LOADER OPERATION 77
- THREE POINT HITCH OPERATION 83

WHEELS/TIRES 85

TRIM THIS EDGE

MidWestTech | Case 570LXT Loader Landscaper Operator's Manual | Publication 9-25895 Order the manual at mid-west-tech.com >