921B Loader

Operators Manual

Rac 9-26555

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 921B Loader Operator's Manual | Publication 9-26555

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1
- AFTER DELIVERY CHECK 2
- RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 2

IDENTIFICATION NUMBERS/MACHINE COMPONENTS 3

SAFETY/DECALS/HAND SIGNALS 7
- SAFETY RULES 7
- BEFORE OPERATION 8
- MACHINE OPERATION 9
- PARKING THE MACHINE 9
- MAINTENANCE 10
- BURN PREVENTION 11
- FIRE OR EXPLOSION PREVENTION 11
- WHEELS AND TIRES SAFETY 12
- SAFETY DECALS 13
- HAND SIGNALS 18
- HAZARDOUS CHEMICALS 20

INSTRUMENT/CONTROLS 21
- FRONT CONSOLE 21
- LOADER CONTROL LEVERS 30
- RIDE CONTROL 31
- INSTRUMENT PANEL 32
- LOADER FUNCTION SWITCHES 35
- CAB CONTROLS AND LIGHTS 39

OPERATING INSTRUCTIONS 49
- BEFORE STARTING THE ENGINE 49
- RUN-IN PROCEDURE 49
- SEAT BELT 50
- STARTING THE ENGINE 51
- STOPPING THE ENGINE AND 53
- PARKING THE MACHINE 53
- MACHINE OPERATION 58
- LOADER CONTROL LEVERS 60
- LOADER FUNCTION SWITCHES 65
- BUCKET LEVEL INDICATOR 67
- AUXILIARY HYDRAULIC CONNECTION 68
- INTERMITTENT LIGHT (IF EQUIPPED) 69

JOB SITE OPERATIONS 70
- LOADER OPERATING TIPS 70
- TOWING THE MACHINE 72
- TRANSPORTING THE MACHINE 73

MidWestTech | Case 921B Loader Operator's Manual | Publication 9-26555 Order the manual at mid-west-tech.com >

OPERATING IN COLD WEATHER 75
OPERATING IN HOT WEATHER 77

WHEELS/TIRES/BALLAST 78
BALLAST 78
WHEELS AND TIRES 78

LUBRICATION/MAINTENANCE 82
GENERAL SAFETY BEFORE YOU SERVICE 82
PLASTIC AND RESIN PARTS 83
ENVIRONMENT 83
TRANSPORT/SERVICE LINK 83
ENGINE HOURMETER 84
ACCESS DOORS 88
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 89
GREASE FITTINGS - 50 HOURS 90
GREASE FITTINGS - 100 HOURS 91
GREASE FITTINGS - 100 HOURS 91
GREASE FITTINGS - 1000 HOURS 92
FLUID LEVELS 93
ENGINE LUBRICATION 95
AIR FILTER SYSTEM 99
ENGINE COOLING SYSTEM 103
DIESEL FUEL SYSTEM 106
HYDRAULIC/BRAKE SYSTEM 110
TRANSMISSION 118
AXLES 121
CAB AIR FILTER (IF EQUIPPED) 124
WINDSHIELD WASHER RESERVOIR (IF EQUIPPED) 126

MAINTENANCE/ADJUSTMENTS 127
ETHER CONTAINER 127
CAB SERVICE 128
LOADER ADJUSTMENTS 131
ROLL-OVER PROTECTIVE STRUCTURE 141
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 143
FAN, BELT, ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT 144
LOADER CONTROL ACCUMULATOR 148
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 149
SECONDARY STEERING CHECK 150

ELECTRICAL SYSTEM 151
FUSES 153

MidWestTech | Case 921B Loader Operator's Manual | Publication 9-26555 Order the manual at mid-west-tech.com >

REPLACEMENT BULBS 154

MACHINE STORAGE 155

SPECIFICATIONS 157
OPERATING DATA AND DIMENSIONS 921B 157
OPERATING DATA AND DIMENSIONS 921B XR 160
ENGINE DATA 163
TRAVEL SPEEDS (WITH 26.5 X 25 TIRES) 163
OPERATING WEIGHT ADJUSTMENTS 164
OPTIONAL EQUIPMENT 164
VERTICAL HEIGHT ADJUSTMENT 165
SPECIAL BOLT TORQUES 165
SPECIAL TOOL 166
AFTER DELIVERY CHECK 167

DETAIL INDEX 171

MidWestTech | Case 921B Loader Operator's Manual | Publication 9-26555 Order the manual at mid-west-tech.com >