1825B
UNI-LOADER®
NORTH AMERICAN MODELS

Operators Manual

Bur 9-27650

CASE
CONSTRUCTION

MidWestTech | Case 1825B Uni-Loader Operator's Manual | Publication 9-27650

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
- IDENTIFICATION NUMBERS 3
- RIGHT, LEFT, FRONT AND REAR OF MACHINE 4
- MACHINE FEATURES 5

SAFETY/DECALS/HAND SIGNALS 7
- MAIN SAFETY FEATURES 7
- SAFETY MESSAGE 8
- BEFORE OPERATION 9
- MACHINE OPERATION 10
- FAILURE IN OPERATION 11
- PARKING THE MACHINE 11
- BURN PREVENTION 12
- WHEELS AND TIRE SAFETY 12
- FIRE OR EXPLOSION PREVENTION 12, 13
- MAINTENANCE 14
- SAFETY DECALS ..... 15 through 20
- HAND SIGNALS ..... 21 through 24
- REAR WINDOW - EMERGENCY EXIT 25
- GETTING ON AND OFF THE MACHINE 25

INSTRUMENTS AND CONTROLS 27
- OPERATOR RESTRAINT SYSTEM 27, 28, 29
- INSTRUMENT PANEL 30
- KEY SWITCH, GLOW PLUG INDICATOR AND LAMP SWITCH 32
- HAND THROTTLE AND HORN BUTTON 34
- TRAVEL/STEERING CONTROLS 35, 36
- LOADER CONTROLS 37
- AUXILIARY HYDRAULIC ATTACHMENT CONTROLS 38

OPERATING INSTRUCTIONS 39
- RUN-IN PERIOD 41
- MACHINE OPERATION 44
- TRANSPORTING THE MACHINE 45
- MOVING A DISABLED MACHINE 46
- LIFTING THE MACHINE WITH A CRANE 46
- OPERATING IN COLD WEATHER 47
- OPERATING IN HOT WEATHER 48
- JOB SITE OPERATION 48
- OPERATING THE LOADER 49
- TOOL-COUPLER 51
- BACKHOE OPERATION (IF EQUIPPED) 53

MidWestTech | Case 1825B Uni-Loader Operator's Manual | Publication 9-27650 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

LUBRICATION/FILTERS/FLUIDS 59
SUPPORT STRUT FOR LOADER LIFT ARMS 60
ENGINE HOURMETER 62
MAINTENANCE SCHEDULE 62
FLUIDS AND LUBRICANTS 63
ENVIRONMENT 63
LUBRICATION/MAINTENANCE CHART 64
REAR ACCESS DOOR 65
GREASE FITTINGS (Every 10 Hours) 66
GREASE FITTINGS (Every 100 Hours) 67
ENGINE LUBRICATION 68
ENGINE LUBRICATION SYSTEM 69
AIR FILTER SYSTEM 72
ENGINE COOLING SYSTEM 75
DIESEL FUEL SYSTEM 77
HYDRAULIC SYSTEM 81
DRIVE CHAIN COMPARTMENT 85

MAINTENANCE AND ADJUSTMENTS 87
TIRE AND RIM SERVICE 87
WHEEL NUTS 89
TILTING THE OPERATORS COMPARTMENT FORWARD 90
TILTING OPERATORS COMPARTMENT INTO OPERATING POSITION 91
TESTING THE SEAT BARS 92
DRIVE CHAINS 93
MAINTENANCE OF THE SEAT BELT 97
FAN BELT INSPECTION 97
SPARK ARRESTER MUFFLER 98
ROLL-OVER PROTECTION STRUCTURE 99

ELECTRICAL SYSTEM 103
BATTERY SERVICE 104
WORK LAMPS 107
FUSES AND STARTER RELAY 108

STORAGE 109
REMOVAL FROM STORAGE 110

SPECIFICATIONS 111
OPERATING WEIGHTS 112
LOADER BUCKETS 113
ELECTRICAL SYSTEM 114
OPERATING DATA AND DIMENSIONS 115

ALPHABETICAL INDEX 117

AFTER DELIVERY CHECK 123, 125

MidWestTech | Case 1825B Uni-Loader Operator's Manual | Publication 9-27650 Order the manual at mid-west-tech.com >